RICOH FT6645

MODEL

SERVICE MANUAL

SECTION 1

OVERALL MACHINE INFORMATION

1. SPECIFICATIONS

Configuration:	Console
Copy Process:	Dry electrostatic transfer system
Toner Supply Control:	Fuzzy Control
Photoconductor:	OPC drum
Originals:	Sheet/Book
Original Size:	Maximum A3/11" x 17"
Original Alignment:	Left rear corner
Copy Paper Size:	Maximum A3/11" x 17" Minimum A5/5 1/2" x 8 1/2" (Tray) B5/8 1/2" x 11" (1.5K LCT) A6/5 1/2" x 8 1/2" (By-pass)
Duplex Copying:	Maximum A3/11" x 17" Minimum A5/5 1/2" x 8 1/2" (sideways)
Copy Paper Weight:	Paper tray: 52 ~ 128 g/m^2, 14 ~ 34 lb Bypass feed table: 52 ~ 157 g/m^2, 14 ~ 42 lb Duplex copying: 64 ~ 104 g/m^2, 17 ~ 24 lb
Reproduction Ratios:	4 Enlargement and 6 Reduction

	A4/A3 Version	LT/LDG Version
Enlargement	200% 141% 122% 115%	200% 155% 129% 121%
Full Size	100%	100%
Reduction	93% 82% 75% 71% 65% 50%	93% 85% 77% 74% 65% 50%

Power Source: 115V, 60Hz, more than 20A (for N.A)
220 ~ 240V, 50Hz/60Hz, more than 10A (for EU and AA)

Power Consumption: A095 and A096 copiers

	Copier only	Full system*
Warm-up	0.9 kVA	0.9 kVA
Stand-by	0.25 kVA	0.25 kVA
Copying	1.2 kVA	1.3 kVA
Maximum	1.45 kVA	1.5 kVA

*Full System:

- Mainframe with dual job feeder, compact sorter stapler and 3,500-sheet large capacity tray
- Mainframe with dual job feeder, floor type sorter stapler and 3,500-sheet large capacity tray
- Mainframe with recirculating document handler, finisher and 3,500-sheet large capacity tray

Noise Emission:

sound pressure level: The measurements are made according to ISO7779

	Copier only	Full system*
Copying	55 dB (A)	61 dB (A)

Full System:

- Mainframe with dual job feeder, compact sorter stapler and 3,500-sheet large capacity tray
- Mainframe with dual job feeder, floor type sorter stapler and 3,500-sheet large capacity tray
- Mainframe with recirculating document handler, finisher and 3,500-sheet large capacity tray

Dimensions: 690 x 690 x 980 (W x D x H Mainframe only)
1280 x 690 x 1020 (W x D x H Mainframe with copy tray, platen cover)

Weight: Copier only: (Without the optional platen cover = Approximately 2 kg)
A095 copier: Approximately 151 kg
A096 copier: Approximately 163 kg

Zoom: From 50% to 200% in 1% steps

Copying Speed:

	A4/LT (sideways)	A3/DLT	B4/LG
A095 copier	45	23	27
A096 copier	55	28	35

Warm-up Time: Less than 5 minutes (20°C)

First Copy Time: 3.1 seconds (A4/8 1/2" x 11" sideways from the 1st feed station)

Copy Number Input: Number keys, 1 to 999 (count up or count down)

Manual Image Density Selection: 7 steps

Automatic Reset: 1 minute standard setting; can also be set from 1 second to 999 seconds or no auto reset.

Copy Paper Capacity:

- By-pass feed table: approximately 50 sheets
- Paper tray: approximately 550 sheets
- Tandem tray: approximately 500 sheets
- Large capacity tray: approximately 1500 sheets

Toner Replenishment: 1,100 g/cartridge

Optional Equipment:

- Platen cover
- Dual job feeder
- Recirculating document handler
- 20 bin sorter stapler (Floor type)
- 20 bin compact sorter stapler
- Finisher
- 3500-sheet Large capacity tray
- Receiving Tray

2. MACHINE CONFIGURATION

2.1 COPIER OVERVIEW

There are two types of mainframe.

A095 copier

550-sheet paper trays
nal 3,500-sheet large capacity tray



A096 copier

em paper tray
ding two 500-sheet paper tray)
50-sheet paper tray
-sheet built-in large capacity tray
nal 3,500-sheet large capacity tray



2.2 SYSTEM OVERVIEW

System A

(The mainframe (A095) with dual job feeder and compact sorter stapler)



System B

(Mainframe type (A095/A096) with dual job feeder and floor type sorter stapler. The mainframe in the illustration below is the A096.)



System C

(The mainframe (A096) with recirculating document handler and finisher)



3. COPY PROCESS AROUND THE DRUM



1. OPC DRUM
The organic photo conductive (OPC) drum (100 mm diameter) has high resistance in the dark and low resistance under light.

2. DRUM CHARGE
In the dark, the charge corona unit gives a uniform negative charge to the OPC drum. The charge remains on the surface of the drum. The amount of negative charge on the drum is proportional to the negative grid bias voltage applied to the grid plate on the charge corona unit.

3. EXPOSURE
An image of the original is reflected to the OPC drum surface via the optics section. The charge on the drum surface is dissipated in direct proportion to the intensity of the reflected light, thus producing an electrical latent image on the drum surface.

The amount of charge remaining as a latent image on the drum depends on the exposure lamp intensity controlled by the exposure lamp voltage.

4. ERASE
The erase lamp illuminates the areas of the charged drum surface that will not be used for the copy image. The resistance of drum in the illuminated areas drops and the charge on those areas dissipates.

5. DRUM POTENTIAL SENSOR
The drum potential sensor detects the electric potential on the drum to compensate image processing elements.

6. DEVELOPMENT
Positively charged toner is attracted to the negatively charged areas of the drum, thus developing the latent image. (The positive triboelectric charge of the toner is caused by friction between the carrier and toner particles.)

The development bias voltage applied to the development roller shaft controls two things:

1) The threshold level if toner is attracted to the drum or toner remains on the development roller.
2) The amount of toner to be attracted to the drum.

The higher the negative development bias voltage is, the less toner is attracted to the drum surface.

7. PRE-TRANSFER LAMP (PTL)
The PTL illuminates the drum to remove almost all the negative charge from the exposed areas of the drum. This makes image transfer easier.

8. IMAGE TRANSFER
Paper is fed to the drum surface at the proper timing so as to align the copy paper and the developed image on the drum surface. Then, a negative charge is applied to the reverse side of the copy paper by the transfer belt, producing an electrical force which pulls the toner particles from the drum surface onto the copy paper. At the same time, the copy paper is electrically attracted to the transfer belt.

9. PAPER SEPARATION
Paper separates from the OPC drum by the electrical attraction between the paper and the transfer belt. The pick-off pawls help to separate the paper from the drum.

10. CLEANING
The cleaning brush removes toner remaining on the drum after image transfer and the cleaning blade scrapes off all the remaining toner.

11. QUENCHING
Light from the quenching lamp electrically neutralizes the charge potential of the drum surface.

4. MECHANICAL COMPONENT LAYOUT



1. 3rd Mirror
2. 2nd Mirror
3. 1st Mirror
4. Exposure Lamp
5. Lens
6. Cleaning Brush
7. Cleaning Blade
8. Quenching Lamp
9. Charge Corona Unit
10. OPC Drum
11. 6th Mirror
12. 4th Mirror
13. 5th Mirror
14. Erase Unit
15. Drum Potential Sensor
16. Toner Hopper
17. Development Unit
18. Pre-Transfer Lamp
19. Pick-up Roller
20. Feed Roller
21. Separation Roller
22. Registration Rollers
23. Transfer Belt
24. Vertical Transport Rollers
25. Tandem Tray (A096 copier)
    550-sheet Tray (A095 copier)
26. Universal Tray
27. 1500-sheet LCT (A096 copier)
    550-sheet Tray (A095 copier)
28. Toner Collection Bottle
29. Transfer Belt Cleaning Blade
30. Hot Roller
31. Pressure Roller
32. Jogger Fences
33. Duplex Positioning Roller
34. Duplex Pick-up Roller
35. Duplex Feed Roller
36. Separation Belt
37. Junction Gate
38. Exit Rollers
39. Optics Cooling Fan

5. DRIVE LAYOUT



❶ Main Motor
❷ Scanner Drive Motor
❸ Fusing/Duplex Drive Motor
❹ Paper Feed Motor
❺ Toner Collection Motor
❻ Registration Clutch
❼ By-Pass Feed Motor
❽ BY-Pass Feed Clutch
❾ Development Drive Motor

1. OPC Drum
2. Scanner Unit
3. Transfer Belt Unit
4. Paper Exit Unit
5. Fusing Unit
6. Duplex Unit
7. Paper Trays
8. Paper Feed Units
9. Toner Hopper
10. Development Unit
11. Cleaning Unit

6. PAPER PATH

6.1 STANDARD COPYING



Paper feed begins from the exterior LCT, by-pass feed table or paper feed stations in the paper tray unit. The copy paper then follows one of two paths inside the copier. The path followed depends on which mode the operator has selected. For copy processing, all sheets follow the same paths from the paper feed mechanism [A] through the registration rollers [B], transfer belt [C], and fusing unit [D]. After that, copies are delivered to the sorter bins [E] or proof tray [F], however, 2 sided copies are diverted for further processing.

6.2 MULTIPLE 2-SIDED COPYING

a. Front Side



b. Rear Side



In this mode the junction gate [A] directs sheets exiting the fusing unit to the duplex tray entrance. After that, all sheets follow the path through the duplex entrance rollers [B].

After all front side copying is completed, the sheets on the duplex tray are fed in order from the bottom to the top and follow the path through the duplex feed mechanism and vertical transport rollers [C] to the registration rollers [D]. After that, these sheets follow the same path as standard copying from the registration rollers to the sorter.

7. ELECTRICAL COMPONENT DESCRIPTION

Refer to the electrical component layout on the reverse side of the attached Point to Point for symbols and index numbers.

Symbol	Name	Function	Index No.
Motors			
M 1	Scanner Drive	Drives the 1st and 2nd scanners (dc servo).	42
M 2	Exhaust Fan	Removes the heat from around the fusing unit.	43
M 3	Main	Drives the main unit components.	44
M 4	Development Drive	Drives the development unit.	45
M 5	By-pass Feed	Drives the by-pass feed rollers.	46
M 6	3rd Scanner Drive	Drives the 3rd scanner (dc stepper)	47
M 7	Toner Bottle Drive	Rotates the toner bottle to supply toner to the toner hopper.	48
M 8	Charge Wire Cleaner Drive	Drives the main charge wire cleaner to clean the charge wire.	49
M 9	Jogger	Drives the jogger fences to square the paper stack in the duplex tray (dc stepper).	50
M10	Lens Horizontal Drive	Shifts the lens horizontal position.	51
M11	Lens Vertical Drive	Shifts the lens vertical position.	52
M12	Optic Cooling Fan	Removes heat from the optics unit.	53
M13	Fusing/Duplex Drive	Drives the fusing unit, the duplex unit, and the paper exit rollers.	54
M14	Paper Feed	Drives all feed and transport rollers in the paper tray unit.	90
M15	1st Lift	Raises the bottom plate in the 1st paper tray.	91
M16	2nd Lift	Raises the bottom plate in the 2nd paper tray.	92
M17	Toner Collection	Transports the collected toner to the toner collection bottle.	93

Symbol	Name	Function	Index No.
M18	3rd Lift (A095 copier only)	Raises the bottom plate in the 3rd paper tray.	94
M19	Side Fence Drive (A096 copier only)	Opens and closes the front and the rear side fences of the tandem tray.	95
M20	Rear Fence Drive (A096 copier only)	Moves the papers stacked in the left tandem tray to the right tandem tray.	96
M21	LCT Motor (A096 copier only)	Lifts and lowers the LCT bottom plate to bring paper to the feed position and allow loading of the paper.	127
Magnetic Clutches			
MC1	Toner Supply	Turns the toner supply roller to supply toner to the development unit.	57
MC2	Registration	Drives the registration rollers.	58
MC3	By-pass Feed	Starts paper feed from the by-pass feed table.	60
MC4	Duplex Transport	Drives the duplex transport rollers to transport the paper to the vertical transport rollers.	64
MC5	Duplex Feed	Starts paper feed from the duplex tray to the duplex transport rollers.	65
MC6	1st Feed	Starts paper feed from the 1st feed tray.	99
MC7	2nd Feed	Starts paper feed from the 2nd feed tray.	101
MC8	3rd Feed	Starts paper feed from the 3rd feed tray.	104

Symbol	Name	Function	Index No.
Switches			
SW1	By-pass Table	Detects if the by-pass feed table is open or closed.	25
SW2	Front Door Safety	Cuts the ac power line and detects if the front door is open or not.	29
SW3	1st Tray Set (A095 copier only)	Detects if the 1st tray is set or not.	66
SW4	2nd Paper Size	Determines what size paper is in the 2nd (universal) paper tray.	67
SW5	Toner Overflow	Detects when the toner collection bottle is full.	75
SW6	Toner Collection Bottle Set	Detects if the toner collection bottle is set or not.	77
SW7	Lower Front Door Safety	Detects if the front door is open or not.	83
SW8	3rd Tray Set (A095 copier only)	Detects if the 3rd tray is set or not.	84
SW9	Main	Provides power to the copier	122
SW10	Tray Down (A096 copier only)	Lowers the LCT bottom plate.	126
Solenoids			
SOL 1	Junction Gate	Moves the junction gate to direct copies to the duplex tray or to the paper exit.	55
SOL 2	Duplex Positioning	Controls the up-down movement of the positioning roller.	56
SOL 3	By-pass Pick-up	Controls the up-down movement of the pick-up roller for by-pass feed.	59
SOL 4	Guide Plate	Opens the guide plate when a paper misfeed occurs around this area.	61
SOL 5	Transfer Belt Positioning	Controls the up-down movement of the transfer belt unit.	62

Symbol	Name	Function	Index No.
SOL 6	Pressure Arm	Presses the paper on the duplex tray against the duplex feed rollers.	63
SOL 7	Tandem Lock	Locks the left tandem feed tray and separates the right and left tandem trays.	97
SOL 8	1st Pick-up	Controls the up-down movement of the pick-up roller in the 1st feed station.	98
SOL 9	1st Separation Roller	Controls the up-down movement of the separation roller in the 1st feed station.	100
SOL10	2nd Pick-up	Controls the up-down movement of the pick-up roller in the 2nd feed station.	102
SOL11	2nd Separation Roller	Controls the up-down movement of the separation roller in the 2nd feed station.	103
SOL12	3rd Pick-up	Controls the up-down movement of the pick-up roller in the 3rd feed station.	105
SOL13	3rd Separation Roller	Controls the up-down movement of the separation roller in the 3rd feed station.	106
Sensors			
S 1	Scanner HP	Informs the CPU when the 1st and 2nd scanners are at the home position.	1
S 2	Platen Cover Position–1	Informs the CPU that the platen cover is in the up or down position (related to APS/ARE function).	2
S 3	Platen Cover Position–2	Informs the CPU that the platen cover is in the up or down position to detect if the original has been removed or not.	3

Symbol	Name	Function	Index No.
S 4	Lens Vertical HP	Informs the CPU that the lens is at the full-size position.	4
S 5	Lens Horizontal HP	Informs the CPU that the lens is at the horizontal home position.	5
S 6	3rd Scanner HP	Informs the CPU when the 3rd scanner is at the home position.	6
S 7	By-Pass Paper End	Informs the CPU that there is no paper in the by-pass feed table.	7
S 8	Guide Plate Position	Informs the CPU if the registration guide plate is closed or not.	8
S 9	Jogger HP	Detects if the duplex jogger fences are at the home position or not.	9
S10	Vertical Transport	Detects the leading edge of the paper to determine the paper feed timing of the next sheet.	10
S11	Duplex Exit	Detects the leading edge of the paper to determine the duplex transport clutch on timing.	11
S12	Duplex Entrance Sensor	Detects the leading edge of the paper to determine the duplex feed clutch off timing.	12
S13	Duplex Paper End	Detects paper in the duplex tray.	13
S14	Duplex Transport	Detects the leading edge of the paper to control the jogger motor and the positioning solenoid on timing.	14
S15	Exit	Detects misfeeds.	15
S16	Fusing Exit	Detects misfeeds.	16
S17	Paper Guide	Detects misfeeds.	17
S18	Auto Image Density	Senses the background density of the original.	20
S19	Original Length–1	Detects original length.	21
S20	Original Length–2	Detects original length.	22
S21	Original Width	Detects original width.	23

Symbol	Name	Function	Index No.
S22	By-Pass Paper Size	Informs the CPU what size paper is in the by-pass feed table.	26
S23	Toner Density	Senses the amount of toner in the black developer.	27
S24	Registration	Detects misfeeds and controls registration clutch off-on timing.	28
S25	Toner End	Detects toner end condition.	30
S26	Auto-Response	Returns the display from the screen saver.	34
S27	Drum Potential	Detects the drum surface potential.	39
S28	Image Density	Detects the density of the ID sensor pattern on the drum.	41
S29	1st Paper End	Informs the CPU when the 1st cassette runs out of paper.	68
S30	1st Paper Near End	Informs the CPU when the 1st cassette is in near end condition.	69
S31	1st Paper Feed	Controls the 1st paper feed clutch off/on timing and the 1st pick-up solenoid off timing.	70
S32	2nd Paper Near End	Informs the CPU when the 2nd cassette is in near end condition.	71
S33	1st Lift	Detects the correct feed height of the 1st cassette.	72
S34	2nd Paper End	Informs the CPU when the 2nd cassette runs out of paper.	73
S35	Toner Collection Motor	Detects the toner collection motor operation.	74
S36	2nd Lift	Detects the correct feed height of the 2nd cassette.	76
S37	3rd Lift	Detects the correct feed height of the 3rd cassette.	78
S38	3rd Paper Near End (A095 copier only)	Informs the CPU when the 3rd cassette is in near end condition.	79
S39	3rd Paper End	Informs the CPU when the 3rd cassette runs out of paper.	80

Symbol	Name	Function	Index No.
S40	3rd Paper Feed	Controls the 3rd paper feed clutch off/on timing and the 3rd pick-up solenoid off timing.	81
S41	2nd Paper Feed	Controls the 2nd paper feed clutch off/on timing and the 2nd pick-up solenoid off timing.	82
S42	Base Plate Down (A096 copier only)	Detects when the bottom plate is completely lowered to stop the 1st lift motor.	85
S43	Side Fence Positioning (A096 copier only)	Informs the CPU when the tandem tray side fences are open.	86
S44	Rear Fence Return (A096 copier only)	Informs the CPU when the tandem tray rear fence is in the return position.	87
S45	Rear Fence HP (A096 copier only)	Informs the CPU when the tandem tray rear fence is in the home position.	88
S46	Left Tandem Paper End (A096 copier only)	Informs the CPU when the left tandem tray runs out of paper.	89
S47	LCT Near End (A096 copier only)	Detects the paper near end condition.	123
S48	Tray Down (A096 copier only)	Detects when the tray is completely lowered to stop the LCT motor.	124
S49	Tray Paper Set (A096 copier only)	Informs the CPU when the paper is set on the LCT bottom tray.	125
PCBs			
PCB 1	AC Drive	Provides AC power to the exposure lamp and fusing lamp.	108
PCB 2	Main	Controls all machine functions.	109
PCB 3	Optic Control	Controls all optics components.	110
PCB 4	High Voltage Control	Controls the output of both power packs and development bias.	111

Symbol	Name	Function	Index No.
PCB 5	Paper Feed Control	Controls all components in the paper bank.	112
PCB 6	DC Power Supply Unit	Provides DC power.	113
PCB 7	Guidance	Controls the guidance display.	120
PCB 8	Operation Panel	Controls the LED matrix, and monitors the key matrix.	121
Lamps			
L1	Exposure	Applies high intensity light to the original for exposure.	18
L2	Fusing	Provides heat to the hot roller.	32
L3	Quenching	Neutralizes any charge remaining on the drum surface after cleaning.	37
L4	Erase	Discharges the drum outside the image area.	38
L5	Pre-transfer	Reduces the charge on the drum surface before transfer.	40
Power Packs			
PP1	Transfer	Provides high voltage for the transfer belt and controls the transfer belt positioning solenoid.	117
PP2	Charge	Provides high voltage for the charge corona wires, and the grid plate. Controls QL, PTL, and charge wire cleaner motor functions.	119
Others			
TS1	Optics Thermoswitch	Opens the exposure lamp circuit if the optics unit overheats.	19
TF1	Fusing Thermofuse	Opens the fusing lamp circuit if the fusing unit overheats.	33
TH1	Fusing Thermistor	Senses the temperature of the hot roller.	24

Symbol	Name	Function	Index No.
TH2	Optics Thermistor	Monitors the temperature of the optics cavity.	36
TH3	Drum Thermistor (Located on the ID Sensor Ass'y)	Monitors the temperature of the OPC drum.	41
H1	Transfer Anti-Condensation	Turns on when the main switch is off to prevent moisture from forming on the transfer belt.	31
H2	Optics Anti-Condensation	Turns on when the main switch is off to prevent moisture from forming on the optics.	35
RA1	Main Power Relay	Controls main power.	107
CO1	Total Counter	Keeps track of the total number of copies made.	114
NF1	Noise Filter	Removes electrical noise.	115
CB1	Circuit Breaker	Provides back-up high current protection for the electrical components.	116
LA1	Lightening Arrestor	Removes current surges from the AC input lines.	118

SECTION 2

DETAILED SECTION DESCRIPTIONS

1. PROCESS CONTROL

1.1 OVERVIEW



This model uses two process control methods. One compensates for variation in the drum potential (latent image control) and the other controls the toner concentration and toner supply amount (image density control).

1.1.1 Latent Image Control



The figure shows the changes of the drum potential during the copy process.

Vo:	The drum potential just after charging the drum.
VD (Dark Potential):	The drum potential just after exposing the black pattern (VD pattern)
VL (Light Potential):	The drum potential just after exposing the white pattern (VL pattern)
VR (Residual Voltage):	The drum potential just after the exposure of the erase lamp.

After long usage following installation or a PM, drum potential will gradually increase due to the following factors:

Dirty optics or exposure lamp deterioration

Dirty charge corona wire and grid plate

Change of the drum sensitivity

In this copier, the change in drum potential is detected by the drum potential sensor and the following items are controlled to maintain good copy quality.

The grid bias voltage

The exposure lamp voltage

The development bias voltage.

A drum thermistor detects the drum temperature and this data is also used to control the above voltages. It is impossible to explain simply because it is controlled by methods developed in our laboratories using an artificial neural network.

1.1.2 Image Density Control

Image density is controlled by the following sensors:

Toner density sensor (TD sensor)

Image density sensor (ID sensor)

Data from the TD sensor is used to keep the toner concentration in the developer at a constant level. However, the image on the OPC drum varies due to the variation of toner chargeability (influenced by the environment) even if the toner concentration is constant. By the ID sensor compensation, toner concentration is changed to keep the image density on the OPC drum constant.

The following items are controlled to maintain a constant copy image density:

Toner supply clutch on time

Toner supply level data (VREF) of the TD sensor

1.2 PROCESS CONTROL DATA INITIAL SETTING

The following flow chart shows all the steps that will be performed whenever the machine is turned on while the hot roller temperature is below 100°C. This initializes all the process control settings.



① : See Latent Image Control section (Page 2-5) for details.

② : See Image Density Control section (Page 2-12) for details.

③: See Optics section (Page 2-39) for details.

1.3 LATENT IMAGE CONTROL

1.3.1 Drum Potential Sensor Calibration



The drum potential sensor [A] is located just above the development unit. The sensor has a detector which detects the strength of the electric field from the electric potential on the drum. The output of the sensor depends on the strength of the electric field.

Since the output of the sensor is affected by environmental conditions, such as temperature and humidity, the sensor output is calibrated during process control data initial setting.

The High Voltage Control PCB [B] has two relay contacts. Usually RA602 grounds the drum. However, during the initial setting, the main PCB turns RA601 on and RA602 off and applies the voltage to the drum shaft.

By measuring the output of the drum potential sensor when –100 V and –800 V are applied to the drum, the sensor output is calibrated automatically. (The machine recognizes the relationship between actual drum potential and the potential sensor output.)

1.3.2 Drum Conditioning

When the fusing temperature reaches 180°C, the machine starts the drum conditioning process. In this mode, the main motor, main charge corona, erase lamp and development bias are activated for about 30 seconds and drum sensitivity and residual voltage (V_R) are stabilized, as in continuous copy runs.

1.3.3 V_{SG} Adjustment

During drum conditioning, the ID sensor checks the bare drum's reflectivity and calibrates the output of the ID sensor to 4 ±0.2 V.

1.3.4 V_R Measurement



The above figure shows the relationship between the drum potential and the original density. To get constant copy quality, this relationship must be maintained.

Since this relationship tends to change to the one represented by the dotted line by various factors, compensations are required.

The residual voltage (V_R) cannot be compensated even if the exposure lamp voltage is increased. Therefore, the V_R change has to be compensated by other means.

The main control board checks the drum potential just after the erase lamp exposure by the drum potential sensor after drum conditioning. This measured drum potential is in fact V_R. This V_R is used as the standard for the V_D and V_L corrections.

NOTE: In the figure above, the residual voltage (V_R) for the new drum is 0V. Actually, there is some residual voltage even on the new drum.

1.3.5 VD Correction



The drum potential just after the black pattern (VD Pattern) is exposed (VD: Dark Potential) tends to lower during drum life due to a decrease in the drum's capacity to carry a charge.

To check the actual VD, the first scanner moves to the home position and the VD pattern (Black) stuck on the bottom side of the exposure glass bracket is exposed on the drum.

The main control board measures VD through the drum potential sensor and adjusts it to a target value by adjusting the grid bias voltage (VGRID).

On the other hand, there is a change of the drum residual voltage (VR), so that the target VD voltage is compensated as follows:

Target VD Value: VD = VR + (–770)

The adjusted grid bias voltage (VGRID) is kept in memory until the next process control data initial setting.

1.3.6 VL Correction



Dirty optics and/or exposure lamp deterioration decreases the intensity of the light that reaches the drum. In addition to this, the drum sensitivity also changes during the drum's life. These factors change the drum potential just after white pattern exposure (V_L: Light Potential).

To check the actual V_L, the first scanner moves under the V_L pattern (White) stuck underneath the original scale. The pattern is exposed on the drum.

The main control board measures V_L through the drum potential sensor and adjusts it to a target value by adjusting the exposure lamp voltage (V_{LAMP}).

The residual voltage (V_R) change also affects V_L, so that V_L's target voltage is compensated as follows:

Target V_L Value: $V_L = V_R + (-140)$

The adjusted exposure lamp voltage (V_{LAMP}) is stored in memory until the next process control data initial setting.

1.3.7 V_R Correction



Potentials (V_R, V_D, V_L) are monitored by the potential sensor. (This is done only when the fusing temperature is less than 100°C after the machine is turned on.)
During the check cycle, the V_D and V_L patterns are exposed and the drum potential on the area where exposed by each pattern is checked by the potential sensor.

Compare the curve of the V_D and V_L compensated drum potential with the curve of the new drum, they are parallel but the compensated potential is still higher (V_R) than the new drum potential. To prevent dirty backgrounds due to increased residual potential, development bias (V_{BB}) is applied as follows:

$$V_{BB} = V_R + (-220)$$

1.3.8 Initial Setting Sequence

The following graph shows the sequence of events during process control data initial setting.



1. Potential sensor calibration
   By measuring the output of the drum potential sensor when –100 V and –800 V are applied to the drum, the sensor output (V_{100} and V_{800}) is calibrated automatically (See page 2-5 for details).

2. V_R, V_D, V_L potential detection
   After about 30 seconds of drum conditioning, V_D and V_L Patterns are developed by using the previous grid bias voltage (V_{GRID}) data and exposure lamp voltage (V_{LAMP}) data to detect the V_R, V_D, V_L data.

   The machine calculates the new V_{GRID} and V_{LAMP} data using the detected V_R, V_D, V_L data.

3. V_D and V_L corrections
   Using the calculated V_{GRID} and V_{LAMP} data, V_R, V_D, and V_L patterns are developed again and the new V_R, V_D, and V_L data are detected.

   If both V_D and V_L data are within specifications, the new V_{GRID}, V_{LAMP} and development bias (V_{BB}) are determined based on the new V_D, V_L, and V_R values.

Specifications:

$V_D = -770 + V_R \pm 20$ V

$V_L = -140 + V_R \pm 20$ V

If V_D is outside specifications, V_{GRID} is shifted one step. Then the V_D pattern is measured again and V_D is detected again.
The same is done for V_L and V_{LAMP}.
The above process continues until both V_D and V_L fall within specifications.
The graph on the previous page shows the example when only V_L was outside specifications at the first V_L detection and it became within specifications after one V_L correction (V_{LAMP} is changed 0.5V/step , V_{GRID} is changed 20V/step).

If V_{100} or V_{800} at drum potential sensor calibration is outside specifications or if V_D or V_L do not fall within specifications after V_{GRID} or V_{LAMP} are shifted to the maximum or minimum level, the machine stops V_D or V_L correction and uses the previous V_{GRID} and V_{LAMP} values during copying.
In this case, nothing is indicated on the machine but the SC counter is incremented.

Related SC codes (see troubleshooting section for details):

Code	Condition
361	Incomplete drum potential sensor calibration
364	Abnormal V_D detection
365	Abnormal V_L detection

Development bias is also decided by using V_R as follows.

$V_{BB} = V_R + (-220)$

4. ID sensor pattern potential detection
   This is performed to determine ID Sensor Bias Voltage. The details are explained in the development control section (see page 2-16).

1.4 IMAGE DENSITY CONTROL

1.4.1 Toner Density Sensor



Developer consists of carrier particles (iron) and toner particles (resin and carbon). Inside the development unit, developer passes through a magnetic field created by coils inside the toner density sensor. When the toner concentration changes, the voltage output by the sensor changes accordingly.

<Toner Density Sensor Initial Setting>

When new developer with the standard toner concentration (2.0% by weight, 20 g of toner in 1000 g of developer) is installed, developer initial setting must be performed by using SP mode ([1] SP Adjustment – PAGE 1).

During this setting, the output voltage (VOUT) from the auto gain control circuit (AGC) on the main control board PCB varies to change the output voltage from the toner density (TD) sensor. This is done by changing the gain data, see below.

$$V_{OUT} = V_{IN} \times \frac{\text{Gain Data}}{256} = 12 \times \frac{\text{Gain Data}}{256}$$

If the data is high, VOUT becomes high, and the sensor output voltage becomes high. As a result, the sensor characteristic becomes as illustrated by curve A. If the data is low, VOUT becomes low, and the sensor output voltage becomes low. As a result, the sensor characteristic shifts as illustrated by curve C.

By selecting the proper gain data, the sensor output is set within the targeted control level (V_{REF}, V_{REF} = 2.5 ± 0.1 V). Now, the sensor characteristic is illustrated by curve B and the TD sensor initial setting is completed.

The selected gain data is stored in memory, and V_{OUT} from the auto gain control circuit stays constant during the toner sensor detection cycle.

<Toner Supply Criteria>

At every copy cycle, toner density in the developer is detected once. The sensor output voltage (V_{TD}) during the detection cycle is compared with the toner supply level voltage (V_{REF}).



<Toner Supply Clutch on Time>

To stabilize toner concentration, toner supply amount (toner supply clutch on time) is controlled by referring to V_{REF} and V_{TD}.
The toner supply amount is calculated at every copy. The toner supply amount is determined by using the following factors.

① $V_{REF} - V_{TD}$

② $V_{REF} - V_{TD}'$ (V_{TD}' = V_{TD} of the previous copy cycle)



By referring to these factors, the machine recognizes the difference between the current toner concentration and the target toner concentration. The machine also understands how much toner concentration has changed and predicts how much the toner supply amount will probably change.
By changing the toner supply amount precisely, toner concentration (image density) is kept at a constant level.
Since the toner supply clutch on time updating is under fuzzy control, the relation among V_{TD}, V_{TD}', V_{REF} cannot be expressed by a simple algebraic formula.

<V_{REF} Correction>

The image on the OPC drum changes due to variation of toner chargeability (influenced by the environment) even if the toner concentration is constant. The image density sensor (ID sensor) directly checks the image on the OPC drum and shifts V_{REF} data (under fuzzy control) to keep the image on the OPC drum constant, as explained in the next section.

NOTE: 1. Toner end condition is detected by the toner end sensor (see the development section for details).
2. The toner supply clutch turns on at the intervals between each copy process while image development is not performed.

1.4.2 Image Density Sensor Detection





VSG and VSP are checked by the ID sensor [A]. The ID sensor is located underneath the drum cleaning section.
There is no ID sensor pattern in the optics, however, a pattern image is made on the OPC drum by the charge corona unit [B] and the erase lamp [C].

VSG is the ID sensor output when checking the erased drum surface.
VSP is the ID sensor output when checking the ID sensor pattern image.

To compensate for any variation in light intensity from the sensor LED, the reflectivity of both the erased drum surface and the pattern on the drum are checked.



VSG is detected every time the machine starts copying.
During VSG detection, the development sleeve rollers do not rotate and no development bias is applied.
VSP is detected after copying is completed if 10 or more copies have been made since VSP was last detected. Since the transfer belt must be released when checking VSP, a VSP check cannot be done during continuous copying.



While developing the ID sensor pattern, ID sensor bias is applied. ID sensor bias is determined during process control data initial setting as follows:

Apply charge while grid voltage is –700 V to create the ID sensor pattern.

Check the drum potential (V_P) of the latent image created by the charge with –700 V grid.

Adjust the ID sensor bias (V_{IDB}) so that it satisfies the following formula.

$$V_{IDB} = V_P - (-300)\ (V)$$
$$= V_P + 300\ (V)$$

Change the bias to the calculated V_{IDB} and detect V_{SP}. V_{SG} detected during V_{SG} adjustment sequence in the process control data initial setting and V_{SP} are used to determine V_{REF} data at process control data initial setting. V_{IDB} is not changed until the next process control data initial setting is done.

<V_{REF} correction timing>

After the series of copies is completed in the case that 10 or more copies have been made, V_{REF} is updated by referring to the previous V_{REF} (V_{REF}'), V_{SG}, V_{SP} and the current TD sensor output (V_{TD}).

Since this V_{REF} data updating is under fuzzy control, the relationship among V_{REF}, V_{REF}', V_{SG}, V_{SP} and V_{TD} cannot be expressed by a simple algebraic formula.

V_{REF} is updated not only at the above case. But also during developer initial setting and during process control data initial setting.

1.4.3 Sensor Abnormal Conditions

a. ID sensor (V_{SG},V_{SP}) abnormal

Whenever V_{SG} falls under 2.5 V or V_{SP} rises over 2.5 V, the CPU fixes the V_{REF} data and toner concentration is controlled only by using TD sensor output.

V_{SG} and V_{SP} are still detected as usual during abnormal conditions and if output returns to normal levels ($V_{SG} \geq 2.5$ V, $V_{SP} \leq 2.5$ V), the CPU returns the toner concentration control to normal mode.

b. TD sensor (V_{TD}) abnormal

Whenever V_{TD} rises over 4.0 V or V_{TD} falls under 0.5 V, the CPU shifts the toner supply to the fixed supply mode. In this condition, the CPU never stops the toner supply. The fixed toner supply amount can be changed in four steps (4%, 7%, 11%, 14%) by using SP mode. The default fixed toner supply amount is 4%.

V_{TD} is still detected as usual during the abnormal condition and if its output returns to a normal level, the CPU returns the toner concentration control to normal mode.

c. Drum Potential Sensor abnormal

Whenever V_{100} rises over 1.6 V or V_{100} falls under 0.1 V or whenever V_{800} rises over 5.0 V or V_{800} falls under 2.7 V, the CPU also shifts the toner supply to the fixed supply mode, as for a TD sensor (V_{TD}) abnormal condition.

Related SC codes. (See troubleshooting section of details.):

Code	Condition
351	Abnormal V_{SG} Detection (V_{SG} > 4.2 V)
352	Incomplete TD Sensor Initial Setting
353	Abnormal V_{SP} Detection (V_{SP} > 2.5 V)
354	Abnormal V_{SG} Detection ($V_{SG} \leq$ 2.5 V)
355	Abnormal V_{TD} Detection (V_{TD} > 4 V)
356	Abnormal V_{TD} Detection (V_{TD} < 0.5 V)
357	Abnormal V_{SP}/V_{SG} Detection ($V_{SP}/V_{SG} \geq$ 0.25 V)
358	Abnormal V_{SP}/V_{SG} Detection (V_{SP}/V_{SG} < 0.25 V)
361	Incomplete Drum Potential Sensor Calibration

2. DRUM UNIT

2.1 OVERVIEW



The drum unit consists of the components as shown in the above illustration. An organic photoconductor drum (diameter: 100 mm) is used for this model.

1. OPC Drum
2. OPC Drum Protective Shutter
3. Erase Lamp
4. Drum Potential Sensor
5. Pre-transfer Lamp
6. Pick-off Pawl
7. Image Density Sensor
8. Drum Thermistor
9. Cleaning Brush
10. Toner Collection Coil
11. Cleaning Blade
12. Ozone Filter
13. Cleaning Filter
14. Charge Power Pack
15. Quenching Lamp
16. Main Charge Corona Unit

2.2 OPC DRUM CHARACTERISTICS

An OPC has the characteristics of:

1. Being able to accept a high negative electrical charge in the dark. (The electrical resistance of a photoconductor is high in the absence of light.)
2. Dissipating the electrical charge when exposed to light. (Exposure to light greatly increases the conductivity of a photoconductor.)
3. Dissipating an amount of charge in direct proportion to the intensity of the light. That is, where stronger light is directed to the photoconductor surface, a smaller voltage remains on the OPC.
4. Being less sensitive to changes in temperature (when compared to selenium F type drums).
5. Being less sensitive to changes in rest time (light fatigue). This makes it unnecessary to compensate development bias voltage for variations in rest time.

2.3 DRUM CHARGE

2.3.1 Overview



This copier uses a double corona wire scorotron system for drum charge. Two corona wires are required to give sufficient negative charge on the drum surface because of a rather high drum speed (330 mm/sec.). The stainless steel grid plate makes the corona charge uniform and controls the amount of negative charge on the drum surface by applying the negative grid bias voltage.

The charge power pack [A] gives a constant corona current to the corona wires (1100 μA) and bias voltage to the grid plate is automatically controlled to maintain proper image density according to the change of the OPC drum potential due to dirty grid plate and charge corona casing.

2.3.2 Air Flow Around the Drum



The exhaust fan [A] located above the fusing unit provides an air flow to the charge corona unit to prevent uneven built-up of negative ions that can cause an uneven charge of the drum surface as shown.

An ozone filter [B] absorbs the ozone (O_3) around the drum.

The exhaust fan rotates slowly during stand-by and rotates quickly during copying to keep the temperature inside the machine constant.

2.3.3 Charge Wire Cleaning Mechanism



The flow of air around the charge corona wire may deposit toner particles on the corona wires. These particles may interfere with charging and cause low density bands on copies.

The wire cleaner pads [A] automatically clean the wires to prevent such a problem.

The wire cleaner is driven by a dc motor [B]. Normally the wire cleaner [C] is located at the front end position (home position). After 5000 or more copies are made and fusing temperature is less than 100°C after the main switch is turned on, the wire cleaner motor turns on to bring the wire cleaner to the rear end and then back to the home position.

When the wire cleaner moves from the rear to the home position (black arrow in the illustration), the wire cleaner pads clean the wires.

There are no home position and return position sensors. The CPU monitors the input voltage (5 V). When the wire cleaner reaches the end, it is stopped and the motor is locked. At this time, input voltage slightly decreases (to about 4 V) and the CPU judges to rotate the motor in reverse.

2.4 ERASE

2.4.1 Overview



LE:	Lead edge erase margin	3.5 ± 2.5 mm
SE:	Side erase margin	total of both sides 3 mm or less
Lo:	Original width	
Lc:	Charged width of drum	
EL:	Lead edge erase	
Es:	Side erase	

The erase lamp unit consists of a line of 123 LEDs extending across the full width of the drum, the width of each being about 2.5 mm. In editing mode, the appropriate LED's turn on according to the customer's designation.

2.4.2 Lead Edge and Trail Edge Erase

The entire line of LEDs turns on when the main motor turns on. They stay on until the erase margin slightly overlaps the lead edge of the original image on the drum (lead edge erase margin). It prevents the shadow of the original lead edge from appearing on the copy paper. This lead erase margin is also necessary for the lead edge of the copy paper to separate from the hot roller. The width of the lead edge erase margin can be adjusted by SP mode (1 SP Adjustment mode: PAGE 3).

When the scanner reaches the return position, the charge corona, the grid bias, and the exposure lamp turn off. However, the charged area on the drum surface is a little longer than the actual original length in order to have the entire latent image of the original.
The entire line of LEDs turn on when the trail edge of the latent image has passed under the erase lamp unit. This prevents developing unnecessary parts of the drum surface, reducing toner consumption and drum cleaning load.
The LEDs stay on to erase the lead edge of the latent image in the next copy cycle. After the final copy, the erase lamps turn off at the same time as the main motor.

2.4.3 Side Erase

Based on the combination of copy paper size and the reproduction ratio data, the LEDs turn on in blocks. This prevents the shadow of the original side edge and unexposed front and rear sides of the drum surface in reduction mode from being developed. This reduces toner consumption and drum cleaning load.

In the DJF mode, the horizontal original standard position on the exposure glass is 5 mm away from the rear scale.
In the RDH mode, the horizontal center of the original is aligned with the center of the exposure glass.
On the other hand, the horizontal original standard position on the exposure glass in the platen cover mode is the rear scale edge.
To erase the shadow made by the edge of the rear scale in platen cover mode, one more LED at the front side turns on. This is in addition to the LED's on in DJF and RDH modes.

2.5 CLEANING

2.5.1 Overview



This copier uses the counter blade system for drum cleaning.
The blade [A] is angled against drum rotation. This counter blade system has the following advantages:

- Less wearing of the cleaning blade edge.
- High cleaning efficiency.

Due to the high efficiency of this cleaning system, the pre-cleaning corona and cleaning bias are not used for this copier.

The cleaning brush [B] is used to support the cleaning blade.
The brush collects toner from the drum surface and scraped by the cleaning blade. Toner on the cleaning brush is scraped off by the mylar [C] and falls to the toner collection coil [D]. Toner is transported to the toner collection bottle by the toner collection coil.

To remove the accumulated toner at the edge of the cleaning blade, the drum turns in reverse for about 4 mm at the end of every copy job. The accumulated toner is removed by the cleaning brush by this action.

2.5.2 Drive Mechanism



The drive force from the main motor is transmitted to the cleaning unit drive gear via the timing belt [A] and the cleaning unit coupling [B]. The cleaning unit drive gear [C] then transmits the force to the front side through the cleaning brush [D]. The force at the front side is used for the toner collection coil gear [E].

2.5.3 Cleaning Blade Pressure Mechanism and Side-to-Side Movement



The spring [A] always pushes the cleaning blade against the OPC drum. The cleaning blade pressure can be manually released by pushing up the release lever [B]. To prevent cleaning blade deformation during the transportation, the release lever is locked in the pressure release (upper) position.

The pin [C] at the rear end of the cleaning blade holder touches the cam gear [D] which gives a side-to-side movement to the blade. This movement helps to disperse accumulated toner to prevent early blade edge deterioration.

2.5.4 Toner Collection Mechanism



Toner collected by the cleaning unit is transported to the toner collection bottle [A] through the toner collection tubes. Three helical coils are used for toner transport.

One coil [B] is driven by the main motor via drive belts and the other coil [C] is driven by an independent toner collection drive motor [D].

The actuator disk [E] on the toner collection drive motor monitors the proper rotation of the toner collection coil [C] to prevent the coil from being damaged by toner clogged in the collection tube. The main PCB monitors the sensor output and increases the motor speed if the sensor monitors that the toner collection motor rotates at a speed lower than normal. Also, the CPU will display an SC 342 if no signal changes (ON $\rightarrow$ OFF) are detected for more than 2.55 seconds while the toner collection motor is turning.

When the toner collection bottle [A] become full, the toner pressure in the bottle increases and presses the gear [F] against the toner overflow switch [G]. After the toner overflow switch is activated, the finishing of the copy job, or up to 100 continuous copies, is allowed, then copying is prohibited and the service call "full toner collection bottle" indication is displayed on the LCD.

This condition can be cleared by de-actuating the toner overflow switch while de-actuating then actuating the toner collection bottle switch ([C] in next page).



2.5.5 Pick-off mechanism

The pick-off pawls are always in contact with the drum surface with weak spring pressure. They move side to side during the copy cycle. This movement is made via a shaft [A] and an eccentric cam [B].

2.5.6 Toner Collection Bottle Set Detection

The toner collection bottle set switch [C] prohibits machine operation by indicating SC343 while the toner collection bottle is not set.

2.6 QUENCHING



In preparation for the next copy cycle, light from the quenching lamp (QL) [A] neutralizes any charge remaining on the drum.

The quenching lamp consists of a line of 16 LEDs extending across the full width of the drum.

Yellow colored LEDs are used for QL to reduce ultra violet light which would cause light fatigue on the OPC drum.

3. OPTICS

3.1 OVERVIEW



The optics unit reflects an image of the original on the exposure glass onto the OPC drum. This forms a latent electrical image of the original.

On this model a halogen lamp (85 V 230 W) is used for the exposure lamp [A]. Lamp surface is frosted to ensure even exposure.

Six mirrors are used to make the optics unit smaller and obtain the wide reproduction ratio range (50 ~ 200%).

The lens [B] is driven by two stepping motors for (1) vertical direction (parallel to the paper feed direction) and (2) horizontal direction movements.

To correct focal length change in reduction and enlargement modes, the third scanner unit [C] (4th and 5th mirrors) position is changed by a stepping motor.

The toner shielding filter [D] is green (a green filter partly absorbs red light) to improve red original duplication.

The optic anti-condensation heater [E] (located on the optic base plate) turns on while main switch is turned off to prevent the moisture from forming on the optics.

3.2 SCANNER DRIVE



A dc servo motor is used as the scanner drive motor [A]. Scanner drive speed is 330 mm/sec. during scanning, and 1950 mm/sec. when the scanner goes back.

The scanner drive motor drives the first [B] and second scanners [C] using two scanner drive wires via the timing belt [D] and the scanner drive shaft [E]. The second scanner speed is half of the first scanner speed.

The scanner drive wire is not directly wound around the pulley on the scanner drive motor.

3.3 VERTICAL LENS DRIVE





The lens vertical drive motor [A] changes the lens vertical position in accordance with the selected reproduction ratio.

A stepping motor (approx. 0.095 mm/step) is used to drive the lens through the lens drive belt. The maximum lens vertical shift distance is 290 mm (from the position at 50% to the position at 200%).

The lens vertical home position sensor [B] detects the lens vertical position for full size mode. The optic control PCB keeps track of the lens position based on the number of pulses sent to the lens vertical drive motor.

3.4 HORIZONTAL LENS DRIVE





The original horizontal position on the exposure glass varies depending on the mode (such as platen, DJF and RDH modes) for easy original handling. However, the center is the standard position for paper feed.

Therefore, the lens horizontal position has to be changed according to paper size, reproduction ratio, original feed modes and the edit modes (centering, margin adjust, etc.).

A stepping motor (approx. 0.07 mm/step) is used to drive the lens through the lens drive belt.

The lens horizontal home position sensor [A] is used to detect the lens horizontal position for A4/LT sideways, in full size and platen mode.

The other positions are determined by counting the number of motor drive pulses.

Since this model has a horizontal lens drive mechanism, side-to-side registration adjustment for each feed station can be done easily by using SP mode (1 SP Adjustment mode: PAGE 4).

3.5 HORIZONTAL LENS POSITIONING

3.5.1 For Original Position



There are three standard original positions for the platen, DJF and RDH modes.

In platen mode, the original is aligned with both the rear [A] and the left [B] original scales (rear left corner [C] is the standard position).

In RDH mode, the original position is the center of the left scale [B].

In DJF mode, the original position is 5 mm to front of the platen mode original position to maintain the original transport path (5 mm from the rear scale).

The above figure shows the lens horizontal positions for each original mode when identical size paper is used.

3.5.2 For Paper Size



To keep high paper feed performance, the center is assigned as the paper feed standard position. Therefore, the lens horizontal position is changed according to the paper size.

The figure shows the lens horizontal position for each paper size in full size mode.

3.5.3 For Reproduction Ratio

Original Rear Edge



When the reproduction ratio is changed, the vertical position of the lens is changed. At the same time, the total focal length has to be changed to adjust the image focusing. For this focal length change, the horizontal position of the 3rd scanner is also adjusted. The maximum 3rd mirror shift distance is 50 mm (from the position at 100% to the position at 50, 200%).

The figure shows the lens horizontal position for 50, 100 and 200%.

3.6 3RD SCANNER DRIVE



To compensate the focus for reproduction and lens position changes, the 3rd scanner (4th and 5th mirrors) position is changed.

A stepping motor [A] (approx. 0.095 mm/step) is used for the 3rd scanner drive.

The 3rd scanner home position sensor [B] is used to detect the unit position for full size mode. The optic control PCB keeps track of the unit position based on the number of motor drive pulses.

3.7 OPTICS CONTROL CIRCUIT



The optic control board communicates with the main board through a data bus. The optics control board monitors all the sensor signals, encoder output, thermistor output and controls all motors in the optics.

At the programmed time, the main CPU sends a scanner start signal to the optics control CPU.

The CPU generates a pulse-width modulation (PWM) signal. The PWM signal goes to a driver circuit, which sends drive pulses to the scanner drive motor.

An encoder in the scanner drive motor generates pulse signals.
A speed/direction control circuit monitors the scanner speed and the direction of the signals, and uses this data to regulate the motor speed.

The home position sensor monitors the position of the scanner. When the main switch is turned on, the main CPU confirms the position of the scanner by moving the scanner out of the home position and back again. This data is sent to the optics control CPU.

3.8 AUTOMATIC IMAGE DENSITY CONTROL SYSTEM (ADS)



In ADS mode the original background density is sensed by the ADS sensor [A] and the main CPU determines an appropriate development bias voltage for the original to prevent dirty backgrounds from appearing on copies.

The ADS sensor board is mounted on the rear side of the optics side plate. The sensor board is covered by the sensor housing cover which has a small hole to direct the reflected light from the original to the ADS sensor.

The ADS sensor standard voltage is adjusted to 2.7 V when process control data initial setting is performed. The exposure lamp turns on with ID level 4 at the home position and the light reflected by the ADS pattern [B] (white painted) reaches the ADS sensor. The main CPU adjusts the ADS gain data automatically to make the output 2.7 V. This gain data is stored in the RAM board.



$A = \frac{9.7}{M}$ (mm)

M = 1.0 (m = 50 ~ 100)

$M = \frac{m}{100}$ (m = 101 ~ 200)

$B = \frac{8.25}{m} \times 100$ (mm)

m: reproduction ratio
(50 ~ 200)

For the first scanning of an original in ADS mode, the CPU starts sampling of the ADS sensor output while exposing the ADS pattern at the scanner home position. Then the CPU stores the maximum ADS sensor output as a reference voltage. This means that every ADS check cycle, the first scanning for the original, the ADS reference voltage is renewed by the latest exposure light reflected by the ADS pattern.

In the full size mode, the CPU samples the ADS sensor output when the scanner scans the original from 9.7 mm to 18 mm from the left scale edge. The CPU takes the maximum ADS sensor output during the sampling period and compares it with the ADS reference voltage to determine the proper development bias voltage. (See development bias control section for details.)

The sampling length of ADS sensor output for the original differs depending on the reproduction ratio because the scanner speed is different.

3.9 MANUAL IMAGE DENSITY CONTROL

When the image density is set manually, the voltage applied to the exposure lamp changes as shown in the table below.



VLAMP: Exposure lamp voltage at ID level 4.
This value is determined at process control data initial setting.

VBB: Development bias (negative) voltage at ID level 4.
This value is determined at process control data initial setting.

3.10 UNEVEN LIGHT INTENSITY CORRECTION





The entire exposure lamp surface is frosted to ensure even exposure.

To compensate for reduced light at the edge of the lens, a shading plate is placed in front of the lens. The shading plate is fixed to the lens unit.
The shading plate compensates the light intensity when the lens horizontal position is shifted ([A] to [C]).

Also three shading mylars [D] intercept any diffused reflected light from outside the light path.

3.11 ORIGINAL SIZE DETECTION IN PLATEN MODE



There are three reflective sensors (APS sensors) in the optics cavity for the original size detection. Original width Sensor [A] is used for sensing the original width and Original Length Sensor-1 [B] and Original Length Sensor-2 [C] sense the original length.

Inside each APS sensor, there is an LED [D] and three photoelectric devices [E]. The light generated by the LED is broken up in three beams and each beam scans a different point of the exposure glass. If the original or platen cover is present over the scanning point, the beam is reflected and each reflected beam exposes a photoelectric device and activates it.

While the main switch is on, these sensors are active and the original size data is always sent to the main CPU. However, the main CPU checks the data only when the platen cover is opened.



Original Size		Length Sensor 1			Length Sensor 2			Width Sensor		
A4/A3 version	LT/DLT version	1	2	3	4	5	6	7	8	9
A3	11 x 7	O	O	O	O	O	O	O	O	O
B4	10 x 14	X	O	O	O	O	O	O	O	O
—	8 1/2 x 14	X	O	O	–	O	–	O	O	X
F4	8 x 13	X	X	O	O	O	O	O	O	X
A4–L	8 1/2 x 11	X	X	X	O	O	O	O	O	X
B5–L	—	X	X	X	O	O	O	O	X	X
A5–L	5 1/2 x 8 1/2	X	X	X	O	O	O	X	X	X
B6–L	—	X	X	X	X	O	O	X	X	X
A6–L	—	X	X	X	X	X	O	X	X	X
A4–S	11 x 8 1/2	X	X	X	O	O	O	O	O	O
B5–S	—	X	X	X	X	O	O	O	O	O
A5–S	8 1/2 x 5 1/2	X	X	X	X	X	O	O	X	X
A6–S	—	X	X	X	X	X	X	X	X	X

NOTE: –L: Lengthwise
–S: Sideways
Sensors #4 and #6 are not used for LT/DLT version machines.

The check is done when the platen position sensor [A] turns on. This is when the platen is positioned about 15 cm above the exposure glass. At this time, only the sensor(s) located underneath the original receive the reflected light and are on. Other sensor(s) are off. Through the on/off data of the nine (seven for LT/DLT version machine) sensors, the main CPU can recognize the original size.
In case the copy is made with the platen open, the main CPU decides the original size only through the data when the Print key is pressed.
This original size detection method eliminates the necessity for a pre-scan and increases the machine's productivity.

4. DEVELOPMENT

4.1 OVERVIEW



This copier uses a double roller (diameter 20 mm each) development (DRD) system. This system differs from single roller development systems in that (1) it develops the image in a narrower area, (2) it develops the image twice, and (3) the relative speed of each development roller against the drum is reduced. Also, finer toner (Approx. 9 μm) and developer (Approx. 70 μm) are used. Both the DRD system and new supplies improve the image quality, especially of thin horizontal lines, the trailing edges of the half-tone areas, and black cross points.

The paddle roller [A] picks up developer in its paddles and transports it to the upper development roller [B]. Internal permanent magnets in the development rollers attract the developer to the development roller sleeve. The upper development roller carries the developer past the doctor blade [C]. The doctor blade trims the developer to the desired thickness and creates backspill to the cross mixing mechanism.

The development rollers continues to turn, carrying the developer to the OPC drum [D]. When the developer brush contacts the drum surface, the negatively charged areas of the drum surface attract and hold the positively charged toner. In this way, the latent image is developed.

The development roller is given a negative bias to prevent the toner form being attracted to the non-image areas on the drum surface that may have a slight residual negative charge.

After turning another 100 degrees, the developer is returned to the paddle roller [A].

4.2 DRIVE MECHANISM



The gears of the development unit are driven by the development drive gear [A] when the development motor [B] (dc servomotor) turns.

The gears of the toner hopper are driven by the toner supply roller drive gear [C] when the toner supply clutch [D] activates.

The above gears are helical gears. Helical gears are more quiet than normal gears. The teeth of the development drive gear are chamfered so that they smoothly engage with the development roller gear [E] when the unit is installed.

4.3 CROSSMIXING



This copier uses a standard cross-mixing mechanism to keep the toner and developer evenly mixed. It also helps agitate the developer to prevent developer clumps from forming and helps create the triboelectric charge.

The developer on the turning development rollers [A] is split into two parts by the doctor blade [B]. The part that stays on the development rollers forms the magnetic brush and develops the latent image on the drum. The part that is trimmed off by the doctor blade goes to the backspill plate [C].

As the developer slides down the backspill plate to the agitator [D], the mixing vanes [E] move it slightly toward the rear of the unit. Part of the developer falls into the auger inlet and is transported to the front of the unit by the auger [F].

The agitator moves the developer slightly to the front as it turns, so the developer stays level in the development unit.

4.4 DEVELOPMENT BIAS

4.4.1 Overview



The high voltage control Board [A] applies the negative development bias to the lower sleeve roller through the receptacle [B] and the lower sleeve roller shaft [C]. Then the bias is applied to the upper sleeve roller through the rear sleeve roller holder made of conductive resin.

The development bias prevents toner from being attracted to the background area of the non-image area on the OPC drum where there is residual voltage. Also, the development bias is used to adjust image density according to the conditions the customer selected.

4.4.2 Bias Control In Copy Cycle

The bias output is determined by five factors.

The total bias is described as;

ADS Mode: $V_B = V_{BB} + V_{BU} + V_{BMG} + V_{BA}$
Manual ID Mode: $V_B = V_{BB} + V_{BU} + V_{BMG} + V_{BM}$

V_B: Total bias
V_{BB}: Base bias
V_{BA}: ADS Compensation
V_{BU}: User Tool mode ID Selection Compensation
V_{BMG}: Magnification Compensation
V_{BM}: Manual ID Selection Compensation

1) Base Bias (V_{BB})



As explained in the process control section, the base bias for development is determined by the residual voltage (V_R) measured in process control data initial setting.

$V_{BB} = V_R + (-220)$

2) ADS Compensation (V_{BA})



According to the original background density, the bias is compensated. The compensation value is determined with the voltage measured by the ADS sensor (ADS sensor output: V_{ADS}) as follows:

$V_{BA} = 234 \times (V_{ADS} - 2.3)$

NOTE: V_{BA} has a limited range from 0 V to –300 V.

3) Manual ID Selection Position Compensation (VBM)

According to the manual ID selection position, the bias is compensated as follows:



VLAMP: Exposure lamp voltage at ID level 4. This value is determined at process control data initial setting.

4) User Tool Mode ID Selection Compensation (VBU)

In the User Tool mode, the image density level can be selected from five steps. The VBU is determined by the User Tool ID position setting as follows:



5) Magnification Compensation (V_{BMG})

V_{BMG} is determined by the selected reproduction ratio as follows:



4.4.3 Bias Control Out of Copy Cycle

To hold the toner on the sleeve rollers while the development sleeve rollers are rotating without image development, a constant –300 V bias is applied.

4.4.4 ID Sensor Pattern Bias



While developing the ID sensor pattern, ID sensor bias is applied. ID sensor bias is determined during process control initial setting as follows:

A charge is applied while grid voltage is –700 V to create the ID sensor pattern.

The drum potential (V_P) of the ID sensor pattern is checked.

The ID sensor bias (V_{IDB}) is adjusted so that it satisfies the following formula:

$$V_{IDB} = V_P - (-300)$$
$$= V_P + 300 \ (V)$$

4.5 TONER SUPPLY

4.5.1 Toner Supply Mechanism



When the toner supply clutch [A] turns on, the agitator [B] moves the toner from front to rear and sends the toner to the toner supply roller.

The toner supply clutch [A] located inside the development motor [C] applies the rotation from the development motor to the toner supply roller gear [D], which drives the agitator gear [E]. Toner is caught in the grooves on the toner supply roller [F]. Then, as the grooves turn past the opening, the toner falls into the development unit.

4.5.2 Toner End Detection



The toner end sensor [A] detects if sufficient toner remains in the toner hopper or not. The toner end sensor monitors toner end condition once when the toner supply clutch turns on. When there is little toner inside the toner hopper and toner pressure on the toner end sensor becomes low, the toner end sensor outputs a pulse signal for each (one detection per one copy).

The toner near end indication is displayed on the LCD after receiving the pulse signal 150 times (If no pulse signal is output twice continually, the pulse count is canceled).

Fifty copies are allowed after entering toner near end condition. After fifty copies are made in toner near end condition, the machine enters the toner end condition and copying is prohibited.

When the main switch is turned off and on, or the front door is opened and closed, the machine drives toner supply mechanism and monitors the toner end sensor output. If the toner end sensor does not output the pulse signal twice continually, the toner end condition is canceled.

4.5.3 Toner Supply Control

By using an SP mode (1 Adjustment mode: PAGE 7), the following 3 kinds of toner supply controls can be selected.

- Auto Process Control Mode
- Detect Mode
- Fixed Mode

1) Auto Process Control Mode

Originals have various image proportions and image densities. For the best toner supply control, it is necessary to link the amount of toner supplied on each copy cycle to the amount of toner consumed for each copy.

Fuzzy control is used in this model to provide this kind of toner supply control.

Fuzzy Control 1

According to data of the ID sensor and TD sensor, the CPU checks the following at every copy cycle:

1. The results of toner supply control (TD sensor output) in the previous copy cycle.

2. How quickly the toner density is changing.
   Then the CPU decides the most suitable toner supply amount (toner supply clutch on time) for the next copy cycle by using fuzzy logic.

Fuzzy Control 2

The image on the OPC drum changes due to variations in toner chargeability (influenced by the environment) even if toner concentration is constant.

The ID sensor directly checks the image on the OPC drum and shifts the VREF data under fuzzy control to keep the image on the OPC drum constant.

NOTE: The toner supply amount is changed at every copy cycle.
The target toner density sensor output is updated under the following conditions:

1. During toner density sensor initial setting
2. During process control data initial setting
3. After the copy job is completed in case that 10 or more copies have been made since the last update.

(Refer to section 2.1.4 "Image Density Control" for details.)

2) Detect Mode

In this mode, only the TD sensor is used to control the toner concentration (VREF data is fixed). The machine performs only fuzzy control 1.

In ID sensor abnormal condition or Drum Potential sensor abnormal condition, the machine automatically enter this mode.

3) Fixed Mode

In this mode, a fixed amount of toner is supplied every copy cycle as determined (4%, 7%, 11%, 14%) by SP mode (1 Adjustment mode: PAGE 7). There is no overtoning detection mechanism.

In TD sensor abnormal condition, the machine automatically enters this mode.

4.5.4 Bottle Drive Mechanism



For easy access, the toner bottle is just inside the front cover. The bottle is positioned horizontally.

The bottle drive mechanism transports toner from the bottle to the toner hopper [A]. A worm gear [B] on the bottle drive motor drives this mechanism.

The toner bottle has a spiral groove [C] that helps move the toner to the toner hopper.

To prevent toner from scattering when the toner bottle is removed from the holder, toner shutter [D] which covers the hole [E] is installed on the toner bottle.

When the toner is set on the holder and the lever is lowered, the toner shutter [D] opens to supply toner to the toner hopper.

The bottle drive motor turns on 0.7 seconds when the toner end sensor turns on twice continually.

5. IMAGE TRANSFER

5.1 PRE-TRANSFER LAMP



The pre-transfer lamp [A] located in the drum unit is used to prevent incomplete toner transfer.

After the latent image is developed but before the image is transferred to the copy paper, the drum surface is illuminated by the pre-transfer lamp. This illumination reduces the negative potential on the drum surface charged by the main charge corona and partially discharged by the exposure. This makes image transfer easier.

The pre-transfer lamp is turned on and off by the charge power pack at the same time as when the main motor turns on and off.

5.2 IMAGE TRANSFER AND PAPER SEPARATION OVERVIEW



This model uses a unique transfer belt unit instead of the transfer and separation corona unit. The transfer belt unit consists of the following parts:

[A] Transfer belt
A belt (length: 321 mm) with high electrical resistance which holds a high negative electrical potential and attracts the toner on the OPC drum onto the paper. Also the electrical potential attracts the paper itself and helps paper separation from the OPC drum.

[B] Transfer bias roller
Applies transfer voltage to the transfer belt.

[C] Transfer belt lift lever (driven by a solenoid)
Lifts the transfer belt to contact the transfer belt with the OPC drum.

[D] Transfer power pack
Generates the constant transfer current.

[E] Transfer belt cleaning blade
Removes toner attached on the transfer belt to prevent the rear side of the paper from being stained.

[F] Discharge plate
Helps paper separation from the transfer belt by discharging the remaining negative charge on the transfer belt.

5.3 IMAGE TRANSFER AND PAPER SEPARATION MECHANISM

The registration rollers [A] starts feeding the paper [B] to the gap between the OPC drum [C] and the transfer belt [D] in proper timing.



Immediately when the leading edge of the paper reaches the gap between the transfer belt and the OPC drum, the transfer belt lift lever [E] raises the transfer belt to contact the transfer belt and the OPC drum. The lift lever is driven by a solenoid



Then a negative transfer bias –1.5 K ~ –2.0 KV is applied to the transfer bias roller [F] and attracts the positively charged toner [G] on the OPC drum. It also attracts the paper and separates the paper from the OPC drum.



After the image transfer is completed, the charge on the transfer belt holds the paper to the transfer belt.
Before separating the paper from the transfer belt, the transfer belt is discharged by the discharge plate [A].



The transfer power pack [B] inside the transfer belt unit monitors the current fed back from the discharge plate to adjust the transfer current. This way, the current stays constant even if the paper, environmental conditions, and the transfer belt surface resistance are changed.



5.4 TRANSFER BELT UNIT LIFT MECHANISM



The transfer belt lift solenoid [A] located inside the transfer belt unit turns on to raise the transfer belt to contact the OPC drum at the appropriate timing.
The front lever [B] and the rear lever [C] are connected to the solenoid by links [D] and push up the stays [E] when the solenoid turns on.
The support spring [F] helps the solenoid to raise the transfer belt.
The solenoid turns off after the copy job is finished.
The transfer belt must be released from the OPC drum for the following reasons:

1. To prevent the ID sensor pattern on the OPC drum from being rubbed by the transfer belt because the transfer belt is located between the development unit and the ID sensor.
2. To decrease the load to the transfer belt cleaning blade, it is better to keep toner on the non-image area (for example VD, VL, ID sensor pattern developed during process control data initial setting) from being transferred onto the transfer belt.
3. To prevent change of OPC drum characteristics by the influence of additives inside the rubber belt.

5.5 PAPER TRANSPORTATION AND BELT DRIVE MECHANISM





The transfer belt is driven by the main drive motor [A] through belt and gears. Since the transfer belt electrically attracts the paper [B], the transport fan is not required.

The charge on the transfer belt is discharged by the discharge plate to reduce paper attraction and paper is separated by the paper stiffness above the transfer belt drive roller [C] where the transfer belt is turning.

The tapered parts [D] at both sides of the roller [E] help keep the transfer belt [F] at the center position.

5.6 TRANSFER BELT CLEANING MECHANISM



Some toner may adhere to transfer belt when paper jams occur, or when the by-pass feed table side fences are set in the wrong position causing the erase lamp to miss some toner. The adhered toner must be removed to prevent the rear side of the copy paper from being stained.
The cleaning blade [A] scrapes off any toner remaining on the transfer belt. A counter blade system is used for the transfer belt cleaning. The surface of the transfer belt is coated to make it smooth and so prevent the cleaning blade from being flipped by the transfer belt.

The lever [B] on the front end of the cleaning blade releases the cleaning blade when the transfer belt unit is lowered and the lever is pushed by the transfer belt unit support prop. (The transfer belt unit is lowered when the lever [C] is turned anti-clockwise)

When the cleaning blade is released, the edge of the cleaning blade rubs the seal so that the seal [D] removes the toner or paper dust on the cleaning blade edge.

5.7 TONER COLLECTION MECHANISM



Through idle gears [A], transfer belt drive is transmitted to the toner collection coil [B]. The toner collection coil transports the collected toner to the toner collection bottle. See section 2.2.5 for details.

6. PAPER FEED

6.1 OVERVIEW



This model has three drawer tray paper feed stations.
The following table shows the configuration of each feed stations of the A095 and A096 copiers.

Feed station	A095 copier	A096 copier
1st	550 sheets tray	500 + 500 sheets tandem feed tray
2nd	550 sheets universal tray	550 sheets universal tray
3rd	550 sheets tray	1500 sheets built-in LCT

Paper can also be fed using the by-pass feed table which has an independent feed mechanism. The by-pass feed table can hold 50 sheets of paper.

All feed stations use an FRR feed system. Rotation of the pick-up roller [A] drives the top sheets of paper from each tray to the feed [B] and the separation [C] rollers. The feed and separation rollers then take over paper drive. If more than one sheet is fed by the pick-up roller, the separation rollers rotates in the opposite direction and prevents all but the top sheet from passing through to the registration rollers.

6.2 FRR FEED SYSTEM



This copier uses an FRR paper feed system using three rollers.

6.2.1 Pick-up Roller

The pick-up roller [A] is not in contact with the paper stack before it starts feeding paper. Shortly after the Start key is pressed, the pick-up roller drops down and feeds the top sheet between the feed [B] and the separation rollers [C]. At almost the same time that the paper's leading edge arrives at the feed roller, the pick-up roller lifts off the paper stack so that it does not interfere with the operation of the feed and separation rollers. The feed and separation rollers then take over the paper feed process.

6.2.2 Feed and Separation Rollers

There is a one-way bearing inside the feed roller so it can turn only in one direction. The separation roller is driven in the opposite direction to the feed roller. The separation roller, however, is driven through a slip clutch (torque limiter clutch) which allows it to turn in either direction depending on the friction between the rollers. The separation roller solenoid keeps the separation roller in contact with the feed roller.





The direction in which the separation roller [A] turns depends on the frictional forces acting on it. The slip clutch applies a constant clockwise force (F1). When there is a single sheet of paper being driven between the rollers, the force of friction between the feed roller [B] and the paper (F2) is greater than F1. So, the separation roller turns counterclockwise.

If two or more sheets are fed between the rollers, the forward force on the second sheet (F3), becomes less than F1 because the friction between the two sheets is small. So, the separation roller starts turning clockwise and drives the second sheet back to the tray.

6.3 SLIP CLUTCH MECHANISM



The slip clutch [A] consists of the input hub [B] and the output hub [C] which is the case of the clutch as well. The magnetic ring [D] and the steel spacers [E] are fitted onto the input hub. The ferrite ring [F] is fitted into the output hub. Ferrite powder [G] packed between the magnetic ring and the ferrite ring [F] generates a constant torque due to magnetic force. The input hub and the output hub slip when the rotational force exceeds the constant torque.

This type of slip clutch does not require lubrication.

6.4 FRR FEED DRIVE MECHANISM



The rotation of the paper feed motor [A] is transmitted to the gear [B] via the timing belt [C], and then transmitted to the separation roller via the feed clutch gear [D], gear [E], gear [F] and gear [G].

If the paper feed station is not selected, the separation roller solenoid [H] de-activates and the separation roller [I] rotates freely in the reverse direction of paper feeding.

Gear [B] also transmits the drive to the vertical transport roller [J] via gear [D], idle gear [K] and gear [L].



When the paper feed station is selected and the start key is pressed, the feed clutch [A], separation roller solenoid [B], and the pick-up solenoid [C] turn on at once.

When the feed clutch [A] activates to rotate the feed roller [D], the feed roller and the pick-up roller [E] turn together because they are linked by the idle gear [F].

When the separation roller solenoid [B] turns on, the separation roller [G] contacts the feed roller [D] then rotates together with the feed roller in spite of the separation roller's drive in the opposite direction due to the torque limiter function in the separation roller [G].

When the pick-up solenoid [C] activates, the pick-up roller [E] lowers to make contact with the top sheet of the paper stack and send it to the feed and separation rollers.
When the paper feed sensor [H] detects the leading edge of the paper [I], the pick-up solenoid de-energizes to lift the pick-up roller and the paper feed clutch de-energizes at a certain time to wait until it is ready to feed to the registration roller.

6.5 SEPARATION ROLLER RELEASE MECHANISM



In this model, the separation roller [A] is normally away from the feed roller [B]. When the paper feed station is selected, the separation roller solenoid [C] contacts the separation roller to the feed roller as explained in the previous two pages.

This contact/release mechanism has the following three advantages:

1. When the paper feed motor turns on, all separation rollers in each feed stations rotate. If the separation roller is away from the feed roller, it reduces the mechanical load to the paper feed motor and drive mechanism, and also reduces wear of the rubber surface of the separation roller due to the friction between the separation roller and the feed roller.

2. After paper feeding is completed, paper sometimes remains in the gap between the feed roller and the separation roller.
   If the feed tray is drawn out in this condition, it is possible for the remaining paper to be torn.
   When the separation roller is away from the feed roller, remaining paper is released from the gap between the feed and the separation rollers.

3. When paper misfeeds occur around this area, the customer can easily pull out the jammed paper between the feed and the separation rollers because the separation roller is away from the feed roller.

6.6 PAPER RETURN MECHANISM



When the paper feed clutch [A] activates and the feed roller drive shaft [B] rotates, the lever [C] rotates together with the shaft. However, the lever is immediately stopped by the stopper [D].

After all paper is fed and the paper feed clutch turns off, the paper feed motor still rotates to turn the separation roller [E] in the reverse direction. The separation roller, still contacting the feed roller, turns the feed roller in the reverse direction until the lever hits the rubber cushion [F].

By this feed roller reverse mechanism, the paper remaining in the gap between the feed and the separation rollers returns 3mm to the paper feed tray.

After that, the separation roller solenoid turns off to move the separation roller away from the feed roller. This releases the leading edge of the paper and drops the paper to the paper feed tray.

This prevents remaining paper from being torn when the feed tray is drawn out.

6.7 PAPER SKEW PREVENTION MECHANISM



In this model, paper corner holders [A] are not used to facilitate paper loading.

Instead of the corner holders, both paper press arms [B] press down both paper side edges, especially in the case of paper with a face curl. This helps to keep paper from being guided by the tray side fences to prevent paper skew or jam.

6.8 PAPER LIFT MECHANISM



When the tray is set in the machine, the machine detects this condition by using several detection methods as shown in the table:

Feed station	A095 copier	A096 copier
1st	Tray set switch	Tray set signal through the connector
2nd	Paper size switch	Paper size switch
3rd	Tray set switch	LCT set signal through the connector

When the machine detects that the paper tray is set in the machine, the lift motor [A] rotates and the coupling gear [B] on the tray lift motor engages the pin [C] of the lift arm shaft [D], then turns the tray lift arm [E] to lift the tray bottom plate [F].





When the lift motor turns on, the pick-up solenoid [A] activates to lower the pick-up roller [B]. When the top sheet of paper reaches the proper paper feed level, the paper pushes up the pick-up roller and the actuator [C] on the pick-up roller supporter [D] activates the lift sensor [E] to stop the lift motor.

After several paper feeds, the paper level gradually lowers then the lift sensor is de-activated and the lift motor turns on again until the lift sensor is activated again.

When the tray is drawn out of the feed unit, the lift motor coupling gear [F] disengages the pin [G] of the lift arm shaft [H], then the tray bottom plate [I] drops.

6.9 PAPER NEAR END / PAPER END DETECTION



A feeler [A] on the lift arm shaft rotates counterclockwise in accordance with the change of the top paper level. When almost 50 sheets are left on the tray, the feeler activate the paper near end sensor [B] and informs the copier CPU of the paper near end condition.

If paper is loaded in the paper tray, the paper end feeler [C] is raised by the paper stack and the paper end sensor [D] is deactivated. When the paper tray runs out of paper, the paper end feeler drops in the cut out [E] of the tray bottom plate and the paper end sensor is activated.

6.10 TANDEM FEED TRAY (A096 COPIER ONLY)

6.10.1 OVERVIEW





500 sheets of paper can be set in each of the left [A] and right trays [B]. Paper is fed from the right tray. When the paper in the right tray runs out, the paper in the left tray is automatically transported to the right tray. After the paper is transported to the right tray, paper feeding resumes.

Normally both the right and the left trays are joined together.
During copying, if there is no paper in the left tray, only the left tray can be pulled out to load paper, as shown. That time, paper feed continues.

6.10.2 Fences Drive Mechanism



The side fences [A] of the right tray are normally closed. They open only when paper in the left tray is transported to the right tray.

The side fences are driven by the side fence drive motor [B] (stepping motor). When the paper loaded in the left tray is transported to the right tray, the side fence drive motor turns counterclockwise to open the side fences until the side fence positioning sensor [C] is activated.

When the rear fence [D] in the left tray pushes paper into the right tray, the side fence drive motor turns clockwise to close the side fences.

6.10.3 Rear Fence Drive Mechanism



When the paper end sensor [A] in the left tray detects paper and the paper end sensor in the right tray detects the paper end condition, the rear fence drive motor [B] (dc motor) in the left tray rotates counterclockwise to drive the rear fence [C] to push the paper into the right tray.
When the actuator on the rear fence activates the return position sensor [D], the rear fence drive motor rotates clockwise until the actuator activates the rear fence home position sensor [E].

6.10.4 Tray Lock Mechanism



Normally the left tray lock lever [A] in the right tray [B] fits in the hole [C] in the left tray [D]. During copying, if there is no paper in the left tray, the tray lock solenoid [E] turns on to release the tray lock lever so that the left tray can be separated from the right tray. The lock lever solenoid also lowers the right tray lock lever [F] to hook itself in the hole [G] on the right tray. Therefore, only the left tray is pulled out to load paper.

6.11 PAPER SIZE DETECTION





SW Actuate....0 De-actuate....1 1 2 3 4 5	Paper size	L: Lengthwise S: Sideways
	A4/A3 Version	LT/DLT version
01111	A3–L	11 x 17–L
00111	B4–L	8 1/2 x 14–L
10011	A4–L	8 1/2 x 11–L
01001	A4–S	8 1/2 x 11–S
00100	8 1/2 x 13	5 1/2 x 8 1/2–S
00010	–	8 x 10–S
00001	A5–S	8 x 10–L
10000	–	8 x 13–L
11000	–	10 x 14–L
11100	–	11 x 15–L
11110	A5–L	5 1/2 x 8 1/2–L

For the first and the third feed trays, the paper size is stored by using the SP mode (4 SP Special Feature – PAGE 5).

For the second feed tray (universal tray), the paper size switch [A] detects the paper size. The paper size switch has five microswitches inside. The paper size switch is actuated by an actuator plate [B] located on the rear of the tray. Each paper size has its own unique combination as shown in the table and the CPU judges the paper size by this combination of activated switches.

6.12 VERTICAL TRANSPORT MECHANISM



The vertical transport rollers [A] in each feed unit is driven by the paper feed motor. The vertical transport rollers and the driven vertical transport rollers [B], on the upper and the lower vertical guide plates, transport the paper from each feed unit to the registration roller.

The upper [C] and lower [D] vertical transport guides can be opened to access jammed paper in the vertical transport area.
The lower vertical transport guide separates from the upper guide to gain wider jam removal space.

To reduce the first copy time, the paper feed motor rotates at a quicker speed (430mm/sec.) than normal (330mm/sec). This quick rotation is performed only in the case of the first copy from the first feed station.

6.13 TRAY POSITIONING MECHANISM



- Tray Lock Mechanism -

When the feed tray is set in the paper feed unit, the lock lever [A] drops behind the lock plate [B] on the Accuride support bracket to lock the tray in the proper position.

- Side-to-side Positioning Mechanism (1st and 3rd feed tray for A096 copier)-

When the feed tray is set in the paper feed unit, the side-to-side positioning plate [C] presses the feed tray against the rubber stopper [D]. By moving the positioning plate, the tray position can be changed to adjust the side-to-side registration.



- Side-to-side Positioning Mechanism -

(All feed trays for the A095 copier and 2nd feed tray for the A096 copier)

Side plates [A] are fixed on the positioning plate [B]. By moving the positioning plate (fixed by four screws), the paper position can be changed to adjust the side-to-side registration.

6.14 BUILT IN LCT

6.14.1 Paper Tray Lift Mechanism



Drive from the reversible LCT motor [A] is transmitted through a worm gear [B] to the drive pulley shaft [C]. The tray wires [D] are fixed in the slots [E] at the ends of the tray support rods [F] and [G].

When the LCT motor rotates forward and the drive pulley shaft [C] turns counterclockwise, the tray support rods and the tray bottom plate [H] move upward. The tray goes up until the top paper pushes up the pick-up roller and the lift sensor in the third feed unit is activated.

The paper near end sensor [I] detects the paper near end condition when it is activated by the actuator [J] on the rear end of the right support rod [G].

To lower the tray bottom plate [H], the LCT motor rotates in reverse and the drive pulley shaft [C] turns clockwise, the tray support rods and the tray bottom plate move downward. The tray goes down until the tray down sensor [K] is activated by the actuator.

6.14.2 Tray Lock Mechanism



When the tray starts moving up, the tray lock lever [A] drops in the hole on the base plate to engage the stopper [B], locking the tray in position. This prevents the tray from being pulled out while in the up position.

When the bottom plate is lowered to the bottom position, the bottom plate presses down the pin [C] on the lock lever. The opposite end of the lever then moves up, allowing the tray to be pulled out.

6.15 BY-PASS FEED TABLE

6.15.1 Feed Mechanism / Paper End Detection



The by-pass feed table uses the FRR feed system. The by-pass feed motor [A], pick-up solenoid [B], and by-pass feed clutch [C] control paper feeding from the by-pass feed table.

The by-pass paper end sensor [D] detects if there is paper on the by-pass feed table.

When there is no paper on the by-pass feed table, the paper end feeler [E] drops in the cut out [F] of the lower guide plate and the paper end sensor [D] deactivates. When paper is present on the by-pass feed table, the paper pushes up the end feeler [E] to activate the paper end sensor [D]. The CPU turns off the paper end indicator on the LCD panel and turns the start key from red to green.

6.15.2 Table Open/Close Detection



When the by-pass feed table is opened, the by-pass table switch [A] is activated by part of the feed table [B]. Then the CPU turns on the by-pass feed indicator on the operation panel.

On this model, opening the by-pass feed table does not shift the copier into interrupt mode. The selected modes and input data before opening the by-pass feed table remain. Also other paper trays can be selected while the by-pass feed table is open.

6.15.3 Paper Size Detection



The paper width detection is necessary to decide the lens horizontal position because the standard position of the optics (rear left corner) and the paper (center) is different.

The by-pass paper size sensor [A] (variable resistor) monitors the paper width. When the paper side fences [B] and [C] are positioned according to the paper width, the rear side fence is connected to the lever of the by-pass paper size sensor. The electrical resistance of the sensor changes in accordance with the side fence position, This informs the CPU of the paper width.

At the first copy from the by-pass feed table, the scanner makes a full distance scan. The registration sensor monitors the length of this paper (between the ON timing by the leading edge and the OFF timing by the trailing edge). From the following copies, the copier is controlled according to this paper length data.

6.16 PAPER REGISTRATION



The registration rollers [A] have two functions. One is aligning the lead edge of the paper with the leading edge of the latent image on the OPC drum. When the CPU receives the signal from the registration sensor, the registration clutch turns on. It turns off 90ms after the trailing edge of the paper is detected by the registration sensor.

The other function is to correct skewing of paper fed from the trays. When the leading edge of the paper reaches the registration rollers, the vertical transport rollers [B] continuously turn to transport the paper. On the other hand, the registration roller is not turning. The leading edge of the paper is pushed against the registration roller. This makes a little buckle on the paper between the vertical transport rollers and the registration rollers to correct paper skew.

Shortly after the leading edge of the paper reaches the registration roller, the registration clutch activates to feed the paper.

6.17 REGISTRATION DRIVE MECHANISM



Through the timing belt [A], main motor [B] rotation is transmitted to the registration clutch [C]. When the registration clutch activates, the main motor drive is transmitted to the lower registration roller [D], then to the upper registration roller [E] via two gears [F] at the front side.

A paper dust cleaner [G] is located at the center of the upper registration roller [E]. This is in line with the feed rollers where most paper dust is generated.

6.18 GUIDE PLATE RELEASE MECHANISM



When a paper misfeed occurs between the vertical transport rollers and the registration rollers, the lower paper guide plate [A] automatically opens.

When the registration sensor is not activated at a certain jam check timing, the guide plate solenoid [B] turns on. The lever [C] raises the lock lever [D] on the guide plate to release the pin [E] on the rear side frame. Then, the guide plate falls open.

The actuator [F] on the guide plate activates the guide plate position sensor [G] when the guide plate opens.

To prevent the guide plate from being left open, if the guide plate position sensor is activated, copying is prohibited and a caution guidance is displayed on the LCD panel.

7. IMAGE FUSING

7.1 OVERVIEW



After the image is transferred, the copy paper enters the fusing unit. Then the image is fused to the copy paper by a heat and pressure process through the use of a hot roller [A] and pressure roller [B].

The fusing lamp [C] located inside the hot roller is turned on and off to maintain the operating temperature of 185°C. The CPU monitors the hot roller surface temperature through a thermistor [D] which is in contact with the hot roller's surface. A thermofuse [E] protects the fusing unit form overheating.

This model uses an oilless hot roller system and does not have a hot roller cleaning mechanism.

The hot roller strippers [F] separate the copy paper from the hot roller and direct it to the fusing exit rollers [G]. The exit sensor [H] monitors the progress of the copy paper through the fusing unit and acts as a misfeed detector while the exit rollers drive the copy paper to the inverter section.

The hook positions of the tension springs [I] on the pressure lever [J] adjusts the roller pressure.

7.2 FUSING ENTRANCE GUIDE



The entrance guide [A] for this machine is adjustable for thick or thin paper.

With thin paper, set the entrance guide in the upper position. This slightly lengthens the paper path which prevents the paper from creasing in the fusing unit. With thick paper, set the entrance guide in the lower position.

This is because thick paper does not bend as easily, and is therefore less prone to creasing. Also, the lower setting allows more direct access to the gap between the hot and pressure rollers. This prevents thick paper from buckling against the hot roller, which can cause blurring at the leading edge of the copy.

In this model, the transfer belt improves paper transport and the paper path to the fusing entrance is stabilized. This reduces the chance of paper creasing due to paper skews in the fusing unit.

Therefore, the guide plate standard position is the lower position. (Standard position on previous models was the upper position).
Since there are very few reasons to change the guide plate position, there is no guide plate position adjustment lever for customer use.

7.3 FUSING DRIVE MECHANISM



The fusing drive gear [A] transmits the drive from the fusing/duplex drive motor to the gear [B] which drives the hot roller gear [C]. Rotation passes from the gear [B] through the idle gear [D] to the exit roller drive gear [E]. The pressure roller is driven by the friction between the two fusing rollers.

7.4 FUSING LAMP CONTROL



When the main switch is turned on the CPU starts sending a trigger pulse to the fusing control circuit to turn on the fusing lamp.

When the CPU detects a fusing temperature of 200°C through the thermistor, the copier starts fusing idling. This idling period can be adjusted by SP mode (1 SP Adjustment: PAGE 1). When the fusing idling finishes, the warm-up period is completed and the Ready indicator turns on. After this, fusing temperature is controlled at 185°C. If the fusing temperature is above 100°C when the main switch is turned on, the copier does not go into the fusing idling mode.

When the fusing temperature reaches 180°C (in the case that the main switch is turned on while the fusing temperature is less than 100°C), the machine starts the process control data initial setting.

The CPU also changes the fusing lamp on period at every check cycle. The change is calculated according to the result of the previous check. This keeps the fusing temperature as close as possible to the target temperature.

If the fusing lamp (950 W) is turned on or off while the exposure lamp is on, the power supplied to the exposure lamp may fluctuate, possibly degrading the copy image. To prevent this, the fusing lamp does not change while the exposure lamp is on: it stays either on or off.

The standard fusing temperature control mode is:
On-off control.....European version
Phase control.....Other versions

By cutting the JP501 on the optics control board, the control mode become to the another mode.

7.5 INVERTER AND PAPER EXIT



After passing the fusing unit, copies enter the inverter unit where paper is distributed to the paper exit rollers [A] or the duplex unit.
The junction gate solenoid changes the position of the junction gate [B]. In duplex mode, the junction gate solenoid turns on to raise the junction gate so that the junction gate guides the paper into the duplex unit.
The fusing exit sensor [C] and exit sensor [D] monitor paper misfeeds.

The duplex transport sensor [E] is used not only to monitor paper misfeed detection, but also to activate the duplex jogger motor.

When the paper passes the duplex transport roller [F], the paper pushes the paper guide [G] up, and the actuator on the rear end of the paper guide shaft de-activates the paper guide sensor [H]. The duplex entrance sensor monitors paper misfeeds.

7.6 INVERTER AND EXIT DRIVE MECHANISM



The gear [A] transmits the drive from the fusing/duplex drive motor [B] to the next gear [C]. This gear [C] transmits the drive to the paper exit and the inverter section through the timing belt [D].

8. DUPLEX

8.1 OVERVIEW



In this mode the junction gate [A] directs sheets exiting the fusing unit to the duplex tray entrance. After that, all sheets follow the path through the entrance rollers [B]. After all front side copying is completed, the sheets follow (the sheets on the duplex tray are fed in order from the bottom to the top) the path through the duplex feed mechanism and vertical transport rollers [C] to the registration rollers.

8.2 DRIVE MECHANISM



The duplex drive gear [A] transmits drive from the fusing/duplex drive motor [B] to the duplex unit. This drive is transmitted to the duplex paper feed section under the control of the duplex feed clutch [C] and transmitted to the duplex transport section under the control of the duplex transport clutch [D]. The duplex pick-up roller is driven by the gear [E], so this roller continuously rotates while the fusing/duplex drive motor is on.

8.3 DUPLEX ENTRANCE TO DUPLEX TRAY



After paper passes through the junction gate, it pushes the feeler [A] up. The feeler and the paper guide [B] form one part, so that when it is pushed up, the paper guide is moved out of the paper path.

The paper then enters the duplex unit. After the paper's trailing edge passes the feeler, nothing holds it up and the paper guide falls into place and is ready to guide the paper under brush roller.

(If the paper is caught on top of the brush roller [C], the guide pushes it under as it falls.)

8.4 DUPLEX STACKING



The jogger motor (stepping motor) [A] drives the side fence drive wire [B] to move the side fences [C] inward or outward.

When the main switch is turned on, the jogger motor rotates to place the jogger fences at the home position by monitoring the signal of the jogger home position sensor [D].

When the start key is pressed, the jogger motor rotates to position the side fences according to the selected paper size. 30 ms after the duplex transport sensor detects the leading edge of the paper (OFF → ON), the jogger motor rotates to position the jogger side fences 10 mm away from the selected paper size. When the copy paper is delivered in the duplex tray, actually 150 ms after the duplex transport sensor detects the trailing edge of the paper (ON → OFF), the jogger fences move inward to square the paper. 30 ms after the duplex transport sensor detects the leading edge of the next copy paper, the jogger fences move back to the previous positions (10 mm away from the paper size) again.

The jogger fences move inward to square the paper stack for every copy paper stack at the same timing as before. After the last copy of the first side copying enters the duplex tray, the jogger fences remain against the paper stack.

8.5 DUPLEX PICK-UP ROLLER MECHANISM



The positioning roller [A] is basically in the upper position. 150ms after the duplex transport sensor [B] detects the trailing edge of the paper (ON → OFF), the positioning solenoid [C] turns on to lower the positioning roller until it contacts the paper. The positioning roller continuously rotates clockwise while the fusing/duplex motor [D] rotates. The positioning solenoid turns on until the leading edge of the paper hits the separation belts [E].

30ms after the duplex transport sensor [B] detects the leading edge (OFF → ON) of the next paper, the positioning roller solenoid turns off to raise the positioning roller so that the positioning roller does not disturb the next paper as it enters.

8.6 DUPLEX PAPER FEED





The paper on the duplex tray is fed in order from the bottom to the top sheet.

After all copies are stacked on the duplex tray, the duplex pressure solenoid [A] turns on to lower the pressure arm [B] so that the pressure arm presses the paper against the pick up roller [C].

Then, the paper feed clutch [D] turns on to rotate the pick-up roller [C], separation belts [E] and the feed roller [F].

The separation belts [E] and the feed roller [F] rotate in opposite directions. Only the bottom paper is fed because the separation belt prevents any other paper from feeding.
The feed roller advances the bottom paper past the separation belts because the force of the feed roller is greater than the resistance of the separation belts. The separation belts prevent multiple feeds because the resistance of the separation belt is greater than the friction between the papers.





When the duplex entrance sensor [A] detects the trailing edge of the last paper, the pressure solenoid [B] turns off to raise the pressure arm [C]. At this moment, the duplex paper end sensor [D] confirms that no paper remains on the duplex tray.

The paper end actuator [E] is located on the pressure arm and moves with the pressure arm.

The paper end sensor is de-activated (the actuator interrupts the photosensor) only when the pressure arm is in the lower position (solenoid [B] is on) and no paper is present on the duplex tray.

200ms after the duplex entrance sensor [A] detects the leading edge of the paper, the duplex feed clutch [F] turns off and the paper is transported by the duplex transport rollers [G].

When the paper activates the duplex exit sensor [H], the duplex transport clutch [F] turns off and the paper waits there until the feed timing is adjusted to match the registration clutch on timing of the previous paper.

SECTION 3

INSTALLATION

1. INSTALLATION REQUIREMENTS

1.1 ENVIRONMENT

1. Temperature Range: 10°C to 30°C (50°F to 86°F)
2. Humidity Range: 15% to 90% RH
3. Ambient Illumination: Less than 1,500 lux (Do not expose to direct sunlight.)
4. Ventilation: Room air should turn over at least 3 times/hour.)
5. Ambient Dust: Less than 0.15 mg/m^3 (4 x 10^3 Oz/yd^3)
6. Room Size: More than 10 m^3 (13.4 yd^3)
7. If the place of installation is air-conditioned or heated, do not place the machine.
   a) where it will be subjected to sudden temperature changes.
   b) where it will be directly exposed to cool air from an air conditioner.
   c) where it will be directly exposed to heat from a heater.
8. Do not place the machine where it will be exposed to corrosive gasses.
9. Do not install the machine at any location over 2,000 m (6,500 feet) above sea level.
10. Place the copier on a strong and level base.
11. Do not place the machine where it may be subjected to strong vibrations.

1.2 MACHINE LEVEL

1. Front to back: Within 5 mm (0.2") of level
2. Right to left: Within 5 mm (0.2") of level

NOTE: The machine legs may be screwed up or down in order to level the machine. Set a carpenter's level on the exposure glass.

1.3 MINIMUM SPACE REQUIREMENTS

Place the copier near the power source, providing clearance as shown:



NOTE: *1. If the LCT is not installed, the distance between the wall and the edge of the by-pass feed table must be more than 30 cm.

*2. If the A374 sorter stapler is installed, the distance must be more than 20 cm.

*3. Copier only: 128.0 cm (with LCT 134.7 cm)
Copier + A374 S/S: 110.0 cm (with LCT 142.2 cm)
Copier + A377 S/S: 125.6 cm (with LCT 156.8 cm)
Copier + Finisher: 136.1 cm (with LCT 167.3 cm)

1.4 POWER REQUIREMENTS

1. Input voltage level: 120 V/60 Hz: More than 20 A
   220 ~ 240 V, 50/60 Hz: More than 10 A

2. Permissible voltage fluctuation: 10%

3. Permissible extension cord:
   At least 300 V/30 A capacity and less than 5 m (16.4 feet) long.

   NOTE: a) be sure to ground the machine. (Do not ground it to a gas pipe.)
   b) Make sure the plug is firmly inserted in the outlet.
   c) Avoid multi-wiring.

4. Do not set anything on the power cord.

2. COPIER INSTALLATION

2.1 ACCESSORY CHECK

Check the quantity and condition of the accessories in the box according to the following list:

Description	Q'ty
1. Operating Instructions (Except –27 machine)	1
2. User Survey Card (–17 machine only)	1
3. Envelope-NECR (–17 machine only)	1
4. NECR (–17, –27, –29 machines only)	1
5. Sensor Cover	1
6. Flat Head Screw 4 x 6	1
7. Leveling Foot	4

2.2 COPIER INSTALLATION PROCEDURE

NOTE: Since the installation procedure is not packed with the copier as an accessory, always bring this manual with you.





CAUTION: When installing the copier, make sure that the copier is unplugged.

NOTE: Insert the leveling shoes [A] under the leveling foots [B], and level the machine before starting the installation. (The leveling foots [B] can be screwed up or down.)

1. Remove the tape strips.



2. Open the front doors.
3. Remove the tape strips.
4. Remove the scanner clamp [A] (1 screw) and install the cap [B] stuck on the paper exit bracket with a tape.
5. Remove the transfer belt lock plate [C] (1 screw).
6. Turn about 180° then remove the cleaning unit lock pin [D].



7. Remove the shutter cover [A] by releasing the hook [B].
8. Remove the shutter inner cover [C] (1 screw).
9. Open the toner bottle holder [D].

   NOTE: To open the toner bottle completely, while lowering the shutter lever [E], push the bracket [F] to the right.

10. Close the toner hopper cap [G].
11. Remove the screw [H] fixing the drum stay [I].
12. Remove the drum stay knob [J].



13. Disconnect two connectors [A].

14. Pull out the development unit [B].

NOTE: 1. To prevent drum scratches, push the development unit to the right while pulling it out.
2. Place the development unit on the sheet [C] attached with the new developer to prevent foreign matter from being attracted to the sleeve rollers.
3. When pulling out the development unit, do not pull the knob [D].

15. Remove two screws [E] fixing the toner hopper [F].

16. Turn the toner hopper 90 degree, then, move it up to remove it from the development unit.



17. Evenly pour in one pack of developer [A] while turning the knob [B].
18. Install the toner hopper [C] to the development unit (2 screws).
19. Install the development unit to the machine.
20. Connect two connectors [D].
21. Install the drum stay [E] and fix the drum stay knob [F] and one screw [G].

    NOTE: When installing the drum stay, be careful not to pinch the harness and keep the harness away from the gear.
22. Open the toner hopper cap [H].



23. Install the shutter inner cover [A] (1 screw).
24. While pushing the lever [B], set the shutter cover [C].
25. Set a toner bottle by following the instructions on the decal.

    NOTE: Before plugging in the power cord, install the guidance ROMs. (–26, –27 machines) (See page 3-12)

26. Plug in the power cord, then turn on the main switch. The machine automatically enter the process control data initial setting mode.

NOTE: Do not make any copy until completing developer initial setting. Do not turn off the main switch during the process control data initial setting mode.

27. Enter SP mode as follows:

    1) Press the clear modes key.
    2) Enter "107".
    3) Press the clear/stop key for more than 3 seconds.



28. Press the "SP Adjustment" key [A].



29. Press the "Start" key [B] of the developer initial setting.



NOTE: Developer initial setting stops automatically.

30. Press the "Index" key [C].

31. Press the "Quit" key [D] to exit SP mode.

    NOTE: If the developer initial setting is not completed, you cannot exit the SP mode by pressing the "Quit" key. If this occur, turn off and on the main switch then repeat steps 29 to 33 again. If the result is the same, see the troubleshooting section "SC352" (Page 6-).

32. Check copy quality and machine operation.

2.3 GUIDANCE ROM, INSTALLATION (OPTION: EUROPE VERSION ONLY)



1. If necessary, replace the three guidance ROMs on the operation panel PCB with the optional guidance ROMs as follows:
   1) Remove three screws [A].
   2) Remove the two screws [B] securing the protective earth wires.



5) Insert the screw driver from the hole [F] and push the operation panel [G] up.
6) Disconnect the connector [H].
7) Replace the guidance ROMs (IC111 [I], IC112 [J], IC113 [K]) on the operation panel PCB [L].
8) Re-install the operation panel, the left inner cover and the left front door.

2. After installing the new guidance ROMs, plug in the power cord and turn on the main switch then perform the "touch panel display position adjustment" as follows.

1) Press the interrupt key then press the clear/stop key more than three seconds.

2) Follow the guidance on the LCD.

2.4 PLATEN COVER (OPTION) INSTALLATION



Install the optional platen cover as follows:

1. Install the sensor ass'y [A] which is an accessory of the platen cover [B] as follows:
   1) Connect the red connector [C] to the rear sensor [D].
   2) Connect the white connector [E] to the front sensor [F].
   3) Secure the sensor assembly with a screw [G].
2. Install the platen cover hooks [H].
3. Install the platen cover [B].

2.5 PAPER SIZE CHANGE



At the factory, all paper cassettes (1st, 2nd and 3rd) are set as A4 sideways. According to the customer's request, change the paper size as follows.

2.5.1 550 Sheets Paper Tray (1st and 3rd feed stations for A095 copier)

1. Draw out the paper feed tray [A].
2. Change the position of the front and the rear side fences [B] (2 screws each) and end fence [C] (one screw) according to the paper size.
3. Stick a size decal on the tray.

4. Enter SP mode as follows:

    1) Press the mode clear key.
    2) Enter "107".
    3) Press the clear/stop key more than 3 seconds.



5. Press the "SP Special Feature" key [A].



6. Press the "Next" key [B] 4 times to select the paper tray size setting mode (page 5) and press the appropriate paper size key of the 1st or the 3rd feed station.



7. Press the "Index" key [C].

8. Press the "Quit" key [D] to exit SP mode.

9. Check copy quality and machine operation.

2.5.2 1500 Sheets Paper Tray (3rd feed station for A096 copier)



1. Draw out the third feed tray [A].
2. Change the position of the front and the rear side fences [B] (1 screw each) and the end fence [C] (one screw) according to the paper size.
3. Perform steps 3 to 8 from the previous page.

2.6 KEY COUNTER HOLDER INSTALLATION (OPTION)



NOTE: Key counter holder set is available as a service part.

1. Remove the two plastic caps [A] and [B] on the right upper cover of the copier.
2. Replace the short-circuit connector [C] with the connector of the accessory harness [D].
3. Install the stepped screw [E].



4. Hold the fixing plate [A] on the inside of the key counter bracket [B] and insert the key counter holder [C].
5. Fix the key counter holder [C] to the bracket [B] (2 screws).
6. Install the key counter cover [D] (2 screws).
7. Connect the connector [E] of the key counter holder.
8. Hook the key counter holder assembly [F] to the stepped screw [G].
9. Secure the key counter holder assembly [F] with a screw [H].

2.7 IMAGE DENSITY ADJUSTMENT

The copy image density is already adjusted to the standard level at the factory. If a customer requests to have the image density adjusted, it can be done through the User Tool mode.

1. Enter the User Tool mode as follows:
   1) Press the clear mode key.
   2) Press the clear/stop key more than 3 seconds.



2. Press the "Set operation modes" key [A].



3. Press the "Next" key once [B].



4. Select appropriate Image Density level (5 steps) adjustment:
   1) Press appropriate ID level key [A].
   2) Press the enter key [B].

5. Press the "Menu" key [C].



6. Press the "Exit" key [D] to exit User Tools mode.



7. Check copy quality.

SECTION 4

SERVICE TABLES

1. SERVICE REMARKS

1.1 HANDLING THE DRUM

The organic photoconductor drum is comparatively more sensitive to light and ammonia gas than a selenium drum.

1. Never expose the drum to direct sunlight.
2. Never touch the drum surface with bare hands. When the drum surface is touched with fingers or becomes dirty, wipe with a dry cloth or clean with wet cotton. Wipe with a dry cloth after cleaning with wet cotton.
3. Never use alcohol to clean the drum; alcohol dissolves the drum surface.
4. Store the drum in a cool, dry place away from heat.
5. Take care not to scratch the drum as the drum layer is thin and is easily damaged.
6. Never expose the drum to corrosive gases such as ammonia gas.
7. Always keep the drum in its protective sheet when out of the copier. Also always close the protective shutter on the drum unit when keeping the drum unit out of the copier. Doing so avoids exposing the drum to bright light or direct sunlight. This will protect the drum from light fatigue.
8. Process control data initial setting (1 SP Adjustment: PAGE 1) must be performed when a new drum is installed.

1.2 DRUM UNIT

1. Make sure that the drum unit is set in position and the drum stay is secured with a screw when the main switch is turned on. If the drum unit is loose, poor contact of the drum connectors may cause electrical noise, resulting in unexpected malfunctions (RAM data change is the worst case).
2. To prevent drum scratches, remove the development unit before removing the drum unit.

1.3 CHARGE CORONA

1. Clean the corona wires with a dry cloth. Do not use sandpaper or solvent.
2. Clean the charge corona casing with water first to remove NOx. Then clean it with alcohol if any toner still remains on the casing.
3. Clean the end blocks with a blower brush first to remove toner and paper dust. Then clean it with alcohol if any toner still remains on it.
4. Do not touch the corona wires with oily bare hands. Oil stains may cause white bands on copies.
5. Make sure that the corona wires are correctly positioned between the cleaner pads and that there is no foreign material (iron filings, etc.) on the casing.
6. When installing new corona wires, do not bend or scratch the wire surface to avoid any uneven charge. Also be sure that the corona wires are correctly positioned in the end blocks. (See charge corona wire replacement.)
7. Clean the charge grid plate with a blower bush (not with a cloth).
8. Do not touch the charge grid plate with oily bare hands. Also, do not bend the charge grid plate or make any dent on it. Doing so may cause an uneven charge.

1.4 OPTICS

1. When installing the exposure glass, make sure that the mark (red for the A095 and white for the A096) on the edge of the glass faces up. This side has received a special treatment to be smoother and generate less static electricity.
2. When moving the 1st or 2nd scanners, always hold them at the center. Move them slowly, carefully, and gently.
3. Do not bend or crease the exposure lamp flat cable.
4. Do not touch the following parts with bare hands:
   a) Reflectors
   b) Exposure lamp
   c) Mirrors and lens
   d) V_D, ADS and V_L patterns
5. To clean the mirrors and lens, use only a clean soft cloth damped with alcohol or water.
6. Do not turn the vertical lamp position adjusting cam. Adjusting the vertical lamp position is very difficult because the filament cannot be seen clearly as the lamp is frosted.
7. The mirror surface with the reflective coating must face the light path. The spring plates must contact the reverse side of the mirror (the side without the reflective coating).
8. Because the toner shielding filter is coated with an anti-static solution (which is removed when wiped with water or alcohol) clean the toner shielding filter very gently to prevent generating static electricity, and wipe with dry cloth.

1.5 ERASE LAMP

1. A narrower lead edge erase margin increases the possibility of fusing jams. The margin should be at least 1.0 mm.
2. After cleaning the erase lamp unit, rub it lightly with your finger to discharge any static electricity on the unit surface.
3. Use only a dry cloth to clean the potential sensor.

1.6 DEVELOPMENT UNIT

1. Be careful not to nick or scratch the development roller sleeves.
2. Place the development unit on a sheet of paper after removing it from the copier. This prevents any small metal objects (staples, clips, E-rings, etc.) from being attracted to the development roller and getting inside the unit.
3. Be careful not to bend terminals on the rear side.
4. Clean the drive gears after removing the used developer.
5. Never load different types of developer or toner into the development unit. Doing so will cause poor copy image and toner scattering inside the copier.
6. Developer initial setting is necessary when new developer is loaded.
   Do not perform the developer initial setting with used developer.
   Do not make any copy before initial setting.
7. When removing the development unit, push it to the right to prevent the OPC drum from being scratched by part of the development unit.
8. The doctor gap and the development rollers position must not be adjusted in the field as they are precisely adjusted at the factory using special tools. Do not loosen any screws with white paint.
9. Before pulling out the development unit, disconnect two connectors.
10. When pulling out the development unit, do not pull the knob.
11. When setting the development unit in the machine, do not forget to set the two connectors.

1.7 TRANSFER BELT UNIT

1. Do not touch the transfer belt with oily bare hands.
2. When servicing the transfer belt cleaning unit, be careful not to damage the edge of the cleaning blade.
3. Apply setting powder or toner to the new cleaning blade.

1.8 CLEANING SECTION

1. When servicing the cleaning section, be careful not to damage the edge of the cleaning blade.
2. Do not touch the cleaning brush with bare hands.
3. Before disassembling the cleaning section, place a sheet of paper under it to catch any toner falling from the section.
4. Empty the used toner collection bottle at every PM.
5. Apply setting powder to the new cleaning blade.

1.9 PRE-TRANSFER LAMP

1. After cleaning the pre-transfer lamp filter, rub it lightly with your finger to discharge any static electricity on the filter.

1.10 PAPER FEED

1. Do not touch the pick-up, feed, separation rollers and the friction pads with oily bare hands.
2. The side fences and the rear fence of the paper trays should be positioned correctly to align with the actual paper size. Otherwise, paper misfeeds may occur.
3. Be careful when reinstalling the paper feed (pick-up, feed, separation) rollers in the paper tray unit. They are not interchangeable with the feed rollers of the by-pass feed tray and 3.5 K LCT because the feeding direction is different.
4. When actuating the front door safety switch to check the machine operation while the front doors are open also actuate the lower front door safety switch. Otherwise, the paper feed motor does not activate, causing SC501.

1.11 FUSING UNIT

1. Be careful not to damage the edges of the hot roller strippers or their tension springs.
2. Do not touch the fusing lamp with bare hands.
3. Make sure that the fusing lamp is positioned correctly (the yellow connector must be at the rear) and that it does not touch the inner surface of the hot roller.

2. SERVICE PROGRAM MODE

2.1 SERVICE PROGRAM MODE OPERATION

The service program (SP) mode is used to check electrical data, change modes, and adjust values.

2.1.1 Service Program Access Procedure

1. Press the clear modes key.
2. Enter "107".
3. Press the clear/stop key for more than 3 seconds until the service program menu appears on the touch panel display.



4. Touch a number [A] on the display to access the desired function.
   This copier has 9 service program modes (mode [5] is not used).
   Only 5 service program modes are visible on the touch panel display at one time.
   Use the down key [B] or the up key [C] to see other service program mode menus.



2.1.2 To Exit SP Mode

1. Touch the [Quit] key [D].

2.1.3 To Return to the Index Menu

1. Return to the index menu by touching Index [A] on the display.



2.1.4 Change the Menu Screen

1. To move to the next page, touch Next [B].
2. To move to the previous page, touch Prev. [C].

   NOTE: For the adjustments for which the data is entered by using, − + [D] the default data is "00".

2.1.5 Access to "Copy in SP" Mode

1. Press Copy in SP [F] to access "Copy in SP" mode. LCD displays as shown at right.
2. Select the appropriate copy mode and make trial copies.
3. Return to the SP mode by pressing SP mode [G].



Service Tables

2.2 SERVICE PROGRAM MODE TABLE

1 SP ADJUSTMENT

PAGE 1



Item	Function	Note
❶	Both the TD sensor toner supply target data (VREF) and the TD sensor gain data are set automatically by using new developer.	With new developer, do not make any copy before performing the developer initial setting. This mode is required when new developer is set or the TD sensor is replaced.
❷	Starts the process control data initial setting.	Perform this program when the following parts are replaced (or cleaned). Drum potential sensor / Exposure lamp / OPC drum / Main charge wire and casing / Mirrors / Lamps around the OPC drum / Charge P.P./ RAM etc.
❸	Increases the period to sufficiently heat the pressure roller at power on. **Default:** 5 min	Perform this only if poor fusing occurs just after the power is turned on.
❹	Adjusts fusing temperature. (1°C/ step) Procedure: 1) Touch [Adjust] . 2) Enter the appropriate number by using the number keys. 3) Press the enter key.	Increase only when thick paper is used and poor fusing occurs. Default: 185 °C

PAGE 2



Item	Function	Note
❶	Enables or disables automatic charge wire cleaning mechanism. **Default:** ON	Select OFF only when a cleaning mechanism malfunction occur.
❷	Changes the paper feed clutch on timing to adjust the paper buckle at the registration roller. (1 mm/step)	Refer to 6.6 Paper Feed Timing Adjustment" in section 5. ① First paper feed clutch ON timing at the first copy ② First paper feed clutch ON timing after the second copy. ③ 2nd paper feed clutch ON timing. ④ 3rd paper feed clutch ON timing. ⑤ By-pass feed clutch ON timing. ⑥ Duplex feed clutch ON timing. ⑦ LCT feed clutch ON timing.

1 SP ADJUSTMENT

PAGE 3



PAGE 4



Item	Function	Note
❶	Changes the ON timing of the registration clutch. (0.5 mm/step)	**Adjustment standard:** 0 ± 2 mm
❷	Changes the OFF timing of the erase lamp to adjust the leading edge erase margin. (0.5 mm/step)	**Adjustment standard:** 3.5 ± 2.5 mm
❸	Adjusts magnification in the paper feed direction by adjusting the scanner motor speed. (0.1%/step)	Perform this adjustment when the optic control PCB is replaced. **Adjustment standard:** 100 ± 1%
❹	Adjusts magnification perpendicular to the direction of the paper feed. The lens position in the full size mode is changed. (0.1%/step)	Perform this adjustment when the optic control PCB is replaced. **Adjustment standard:** 100 ± 1%
❺	Enables or disables the 5 mm width side edge erase.	**Default:** No
❻	Adjusts the lens horizontal stop position for each paper feed section. (0.1 mm/step)	Refer to 8.9 Side-To-Side Registration Adjustment" in Section 5.
❼	Adjusts the lens horizontal stop position to compensate for variations of the side to side original position.	

1 SP ADJUSTMENT

PAGE 5



PAGE 6



Item	Function	Note
❶	Adjusts the lens position to correct magnification in enlarge/reduction modes.	Input only the data number marked on the lens.
❷	Adjusts the 3rd scanner home position to correct the focus.	
❸	Factory use only	Do not change the data.
❹	Adjusts the ADS sensor output while scanning the ADS pattern to 2.7 ± 0.1 V	This mode is also performed during the process control data initial setting.
❺	Adjusts the VSG to 4.0 ± 0.2 V.	This mode is also performed during the process control data initial setting.
❻	Adjusts the original stop position against the original side scale in one-sided original mode (0.5 mm/step).	Refer to page 43 of the DJF manual.
❼	Adjusts the original stop position against the original side scale in two-sided original mode (0.5 mm/step).	Refer to page 44 of the DJF manual.

1 SP ADJUSTMENT

PAGE 7



PAGE 8


Copy in SP
Prev.
Next
Index
1 SP Adjustment
PAGE 8
❺ Grid Volt.(M-CH) Adj. 0000V Adjust
❻ Development Bias Adj. 000V Adjust
❼ Factory Use — D +00 − +
❽ Factory Use — P +00 − +
❾ Factory Use — L +00 − +

Item	Function	Note
❶	Selects toner supply mode. (See the process control section for details of each supply mode.) **Default:** Auto Mode	Select "Auto Mode" in the field.
❷	Factory Use only	Select "N" in the field.
❸	Changes the toner supply ratio in fixed toner supply mode. **Default:** 4%	Be careful, there is no overtoning protective system.
❹	Enables and disables the auto process control (V_R, V_L, V_D corrections). (See the process control section for details.) **Default:** Set	Normally select "Set". Select "Reset" only to confirm if the cause of the problem is related to process control or not.
❺	Selects the grid bias voltage when auto process control is disabled or RAM is cleared. (1 V/step) **Default:** 870 V	Enter the data by using the number keys, then touch "Enter".
❻	Selects the development bias voltage when auto process control is disabled or RAM is cleared. (1 V/step) **Default:** 220 V	Enter the data by using the number keys, then touch "Enter".
❼	Factory Use only	Do not change the data in the field.
❽	Factory Use only	Do not change the data in the field.
❾	Factory use only.	Do not change the data in the field.

1 SP ADJUSTMENT

PAGE 9



Item	Function	Note
❶	Selects the exposure lamp voltage when auto process control is disabled or RAM is cleared. (0.5 V/step) **Default:** 65.0 V	Enter the data by using the number keys, then touch [Adjust].
❷	Adjusts the transfer current. (1μA/step) **Default:** 40 μA	**Standard Data:** 40 mA Enter the data by using the number keys, then touch [Adjust].
❸	Initializes the by-pass paper size sensor.	**Procedure:** 1. Set the by-pass table side fence to the A4/81/2 x 11 position, then touch the [Enter] key ①. 2. Set the by-pass table side fence to the A6/41/4 x 51/2 position, then touch the [Enter] key ②. Perform this mode when the by-pass paper size sensor is replaced.

1 SP ADJUSTMENT

PAGE 10 A4/A3 VERSION **PAGE 11** LT/DLT VERSION



Item	Function	Note
❶	Adjusts the duplex jogger fence position for each paper size. (0.3 mm/step)	Press [+] to increase the distance in-between the side fences. Press [−] to decrease the distance in-between the side fences. **Procedure:** 1. Feed a sheet of paper to the duplex tray. 2. Take out the duplex unit. 3. Adjust the jogger fence position so that the distance between the fences becomes 1 mm wider than the paper width.

1 SP ADJUSTMENT

PAGE 12



NOTE: PAGE 15 is for factory use only. PAGE 16 is an extra page, it is not used.

PAGE 13

A4/A3 VERSION



PAGE 14

T/DLT VERSION



Item	Function	Note
❶	Adjusts the staple position. ① Adjusts the vertical staple position. ② Adjusts the horizontal staple position. (0.5 mm/step) 	This mode affects only the A377 Sorter Stapler (horizontal and vertical) and the A379 Finisher (horizontal only).
❷	Changes the duplex positioning roller down timing for both A4/A3 and LT/DLT version machines.	
❸	Changes the duplex positioning roller up timing to adjust the paper buckle at the separation roller. (5 ms/step)	Adjusts the timing so that the paper leading edge just touches the separation belt without any buckle.

2 SP TEST MODE

PAGE 1



PAGE 2



Item	Function	Note
❶	Operates the copier without feeding paper.	Place sheets of white paper (A3 or 11" x 17") on the exposure glass.
❷	Operates the copier without feeding paper or turning on the exposure lamp.	Do not operate the machine in this mode for a long time because a lot of toner is spent.
❸	Disables jam detection. (Not effective for peripherals)	This mode is only effective in the "Copy in SP" mode.
❹	Indicates the paper width detected by the by-pass paper size sensor.	
❺	Rotates the main and development motors and turns on the toner supply clutch to supply toner in the development unit. T.D. sensor toner supply target data (V_{REF}) and detected data (V_T) is indicated.	Toner is supplied under the following conditions. 1. Toner supply ratio: 25% 2. Repeats 0.5 sec ON and 1.5 sec, OFF. 3. Continues 30 sec. Check the image after this SP mode is completed.

2 SP TEST MODE

PAGE 3



PAGE 4



Item	Function	Note
❶	Use to check if the original size sensors are correctly activated and de-activated.	Status 0 ----- de-activated Status 1 ----- activated
❷	Use to check if the sensors or switches are correctly activated and de-activated. **Access this mode as follows:** 1. Touch the input mode key ①. 2. Enter the sensor/switch/signal number by using the number keys on the operation panel. (Refer to the input check mode on page 4-35) 3. Touch the enter key ③.	Status 0 ----- de-activated Status 1 ----- activated This mode cannot be used with the MATT20
❸	Use to confirm the proper function of the copier electrical components **Access this mode as follows:** 1. Touch the Output mode key ②. 2. Enter the electrical component number by using the number keys on the operation panel (Refer to the output check mode on page 4-41). 3. Press the enter key ③.	Touch [ON] to activate and touch [OFF] to de-activate the electrical component This mode cannot be used with the MATT20
❹	Operates the DF without the copier operation.	**Procedure:** 1. Set originals on the table. 2. Touch [Start] .
❺	Operates the sorter stapler (A374 and A377) or A379 finisher without copier operation.	The sorter operates as if 3 copies are made from five originals in sort and staple mode. No stapling is actually made.

2 SP TEST MODE

PAGE 5



Item	Function	Note
❶	Operates the toner collection drive mechanism.	After touching the Start key, the toner collection motor turns on for 1 minute.

3 DATA OUT MODE

PAGE 1



PAGE 2



Item	Function	Note
❶	Indicates the drum potential sensor output when –100 V is applied to the OPC drum.	**Standard data:** 0.1 ~ 0.7 V
❷	Indicates the drum potential sensor output when –800 V is applied to the OPC drum.	**Standard data:** 2.7 V ~ 4.2 V
❸	Indicates the drum potential when detecting the V_D pattern.	**Standard data:** V_R +770 ± 20 V
❹	Indicates the drum potential when detecting the V_L pattern.	**Standard data:** V_R +140 ± 20V
❺	Indicates the drum potential when detecting the bare drum surface.	**Standard data:** 0 ~ 200 V
❻	Indicates the charge grid bias voltage decided during process control data initial setting.	Works only when auto process control is enabled. (1 SP Adjustment – PAGE 7) **Standard data:** 870 ~ 1,200 V
❼	Indicates the development bias voltage decided during process control data initial setting.	Works only when auto process control is enabled. (1 SP Adjustment – PAGE 7) **Standard data:** VR -220 V
❽	Indicates the ID sensor bias voltage decided during process control data initial setting.	Works only when auto process control is enabled. (1 SP Adjustment – PAGE 7) **Standard data:** 300 V ~ 400 V

NOTE: ❸ ~ ❺ are absolute value.

3 DATA OUT MODE

PAGE 3



Item	Function	Note
❶	Indicates the exposure lamp voltage (ID Level 4) decided during process control data initial setting.	Works only when the auto process control is enabled (1 SP Adjustment - PAGE 7.) **Standard data:** 50 ~ 80 V
❷	Indicates the toner supply level by image area ratio on an original surface. This data changes at every copy through fuzzy control.	
❸	Indicates the TD sensor output: VT: Current detected data Initial: TD sensor output at last process control data initial setting. Previous: Previous detected data during ID sensor compensation. VTP: Last detected data during ID sensor compensation. VREF: Toner supply level target data.	**Standard data:** 0.5 ~ 4.0 V
❹	Indicates the ID sensor output VSGP: ID sensor output while detecting the bare drum surface (with dev. bias and development roller rotation) VSP: ID sensor output while detecting the ID sensor pattern image VSG: ID sensor output while detecting the bare drum surface (without development bias and without development roller rotation)	VSGP is not used for auto image density control. **Abnormal condition:** V_{SGP} < 2.5 V V_{SP} > 2.5 V V_{SG} < 2.5 V

3 DATA OUT MODE

PAGE 4



Item	Function	Note
❶	Indicates the drum potential while detecting ID sensor pattern (grid voltage = – 700 V)	**Standard data:** 600 ~ 700 V
❷	Indicates the ADS sensor output at every scan.	**Standard data:** 2.7 ± 0.1 V Present: Output at last detection. Initial: Output at ID sensor initial setting.
❸	Indicates the fusing temperature based on the fusing thermistor output.	**Standard data:** Around 185°C
❹	Indicates the drum temperature based on the drum thermistor output.	
❺	Indicates the optics temperature based on the optics thermistor output.	

4 SP SPECIAL FEATURES

PAGE 1



Item	Function	Setting		Default
❶	Selects copy count up or down.	Set	Count up	Reset
		Reset	Count down	
❷	Counts twice when an A3 or 11" x 17" copy is made.	Set	Count twice	Reset
		Reset	Count once	

PAGE 2





Item	Function	Setting		Default
❶	Enables user code mode. * See the NOTE below.	Set Reset	Enable Disable	Reset
❷	Enables the PM alarm.	Set Reset	Enable Disable	Reset
❸	Selects the PM alarm interval after counter clear (9 PM Counter Clear - PAGE 1)			120 K

NOTE: To enable user code mode, perform the following procedure.

CAUTION: When Set is selected, at least one user code should be entered.

1. Register the user code by using user tool No.6.
2. Enter SP mode then enable the user code mode by selecting Set .
3. Turn off the main switch.
4. Remove the plastic cap [A] on the right upper cover.
5. Disconnect the key counter short-circuit connector [B].
6. Return the plastic cap [A].
7. Turn on the main switch and check the operation.

4 SP SPECIAL FEATURES

PAGE 3



Item	Function	Setting		Default
❶	Enables automatic sort mode selection when 2 or more is entered in the copy counter and an original is set on the DJF feed tray.	Set Reset	Enable Disable	Set
❷	Enables automatic feed-out of the last copy on the duplex tray without copying when an odd number of originals is set on the DJF feed tray.	Set Reset	Enable Disable	Set
❸	Cancels the maximum copy quantity limit (50) in staple mode.	Set Reset	Limit No limit	Set
❹	Cancels the maximum copy quantity limit in sort mode (50) and in stack mode (40).	Set Reset	Limit No limit	Reset

4 SP SPECIAL FEATURES

PAGE 4



Item	Function	Setting		Default
❶	Enables automatic access to the border/center erase mode in platen cover mode.	Set Reset	Enable Disable	Reset
❷	Enables automatic selection of a right margin (5 mm, 0.2") for the duplex back side when making 2 sided copies from 1 sided originals.	Set Reset	Enable Disable	Reset
❸	Limits user access to User Tools No. 10 and 11 to only those who know the access code. Procedure: 1. Touch the 0000 Key. 2. Input the access code with the number keys. 3. Touch the enter key ①. *See the caution below.	Set Reset	Limit No limit	Reset

CAUTION: After enabling this mode, be sure to instruct the key operator not to forget the access code.

Service Tables

4 SP SPECIAL FEATURES

PAGE 5, 6



PAGE 7



Item	Function	Note
❶	Selects the paper size of each paper feed station. Refer to section 3 for details of the paper size change procedure.	1. Default is A4 or 8 1/2 x 11 sideways.
❷	Holds the service center telephone number. This telephone number is indicated on the LCD with the SC number when a problem occurs.	**Entering procedure:** 1. Touch the [00000000000000000] 2. Enter the phone number by pressing the number keys. (Touch [-] to enter the hyphen) 3. Touch (#) .
❸	Holds the copier's serial number.	

4 SP SPECIAL FEATURES

PAGE 8



PAGE 9



Item	Function	Setting		Default
❶	Selects the staple mode for the 1st job when the staple mode is selected for the 2nd job in the pre-set mode.	Set Reset	Enable Disable	Reset
❷	The original size detection system for this model cannot distinguish between A4 and 8 1/2 x 11. This mode enables recognition of A4 and 8 1/2 x 11originals as A4 size for the A4/A3 version as 8 1/2 x 11 for the LT/DLT version.	Set Reset	Enable Disable	Reset
❸	Indicates the part number, with ROM suffixes, on each PCB. *See NOTE below.			

NOTE: Only the produced date is indicated for the operation panel (guidance) ROMs.

6 JAM/SC COUNTER

PAGE 1



Item	Function	Note
❶	Indicates the total number of occurrences of each SC code.	Press ↑ to scroll up. Press ↓ to scroll down. See Section 6 for details of each SC code. The counters for SCs that have not occurred are not displayed.

6 JAM/SC COUNTER

PAGE 2



PAGE 3



Item	Function	Note
❶	Indicates the total number of jams in the copier and all peripherals.	
❷	Indicates the total number of jams in the copier only.	
❸	Indicates the total number of jams at each location.	**Locations:** 
❹	Indicates the total number of jams for each feed station.	
❺	Indicates the total number of jams at each location in the DF.	
❻	Indicates the total number of jams in the DF.	

7 COPY COUNTER

PAGE 1



PAGE 2



Item	Function	Note
❶	Indicates the total main motor rotation time.	
❷	Indicates the total number of originals fed by the DF.	
❸	Indicates the total number of copies.	
❹	Indicates the total number of copies for each paper size.	
❺	Indicates the total number of copies for each magnification.	
❻	Indicates the total number of copies for each edit image mode.	

7 COPY COUNTER

PAGE 3, 4





PAGE 5



PAGE 6



Item	Function	Note
❶	Indicates the total number of the copies for each copy mode.	
❷	Indicates the total number related to consumables.	
❸	Indicates the total number of staples for each staple position.	
❹	Indicates the total number of copies broken down by paper feed station.	

8 COUNTER CLEAR

PAGE 1



PAGE 2



Item	Function	Note
❶	Clears all SC counters.	**Procedure to clear:** 1. Touch [Clear] . The display changes as shown at right. 2. Touch [Yes]. (Touch [No] to cancel.) The display returns to the one shown at left and the beeper sounds four times.
❷	Clears all paper jam counters.	
❸	Clears all original jam counters.	
❹	Clears all copy counters.	
❺	Clears all counters (❶ ~ ❹).	

9 PM COUNTER CLEAR

PAGE 1



PAGE 2



Item	Function	Note
❶	1. Indicates the total number of copies since the last PM (PM counter). 2. Clears the PM counter.	**Procedure to clear:** 1. Touch [Clear] . The display changes as shown at right. 2. Touch [Yes]. (Touch [No] to cancel.) The display returns to the one shown at left.
❷	1. Indicates the total number of copies since the last PM for each unit (unit counter). 2. Clears each unit counter.	

Service Tables

9 PM COUNTER CLEAR

PAGE 3, 4



Item	Function	Note
❶	1. Indicates the total number of copies since the last PM for each unit. (unit counter) 2. Clears each unit counter.	**Procedure to clear:** 1. Touch [Clear] . The display changes as shown at right. 2. Touch [Yes]. (Touch [No] to cancel.) The display returns to the one shown at left.

10 MEMORY CLEAR

PAGE 1



Item	Function	Note
❶	Returns all data to the default data.	**Procedure to clear:** 1. Touch [Clear] . The display changes as shown at right. 2. Touch [Yes]. (Touch [No] to cancel.) The display returns to the one shown at left and the beeper sounds twice. 3. Turn the main switch off and on.

2.3 SENSOR/SWITCH/SIGNAL DATA CHECK (INPUT MODE)

– How to check the sensor/switch/signal –

1. Enter SP mode as follows:
   1) Press the mode clear key.
   2) Enter "107"
   3) Press the clear/stop key for more than 3 seconds.



2. Touch [2] [A] on the display to access SP test mode.



3. Touch [Next] [B] on the display twice.



4. 1) Touch [Input No. 00] [C].
   2) Enter the input sensor/switch/signal number by using the number keys (Refer to the table in the following pages).
   3) Press the Enter key [D].



Input No	Sensor/Switch/|Signal	Status	
		0	1
1	Registration Sensor	Paper not detected	Paper detected
2	Fusing Exit Sensor	Paper not detected	Paper detected
3	Exit Sensor	Paper not detected	Paper detected
4	Vertical Transport Sensor	Paper not detected	Paper detected
5	1st Tray Set Switch (A095 only)	Not set	Set
6	By-Pass Paper End Sensor	Paper detected	Paper not detected
7	2nd Paper End	Paper detected	Paper not detected
8	3rd Paper End	Paper detected	Paper not detected
9	Built-in LCT Tray Down Key	Pressed	Not pressed
10	2nd Paper Near End Sensor	Not near end	Near end
11	3rd Paper Near End Sensor	Not near end	Near end
12	Built-in LCT Paper Set	Paper not detected	Paper detected
13	2nd Paper Size Switch (All SW)	Set	Not Set
14	2nd Tray Set Detection	Not set	Set
15	3rd Tray Set Switch (A095 only)	Not set	Set
16	Built-in LCT Set Detection	Not set	Set
17	1st Paper Feed Sensor	Paper not detected	Paper detected
18	2nd Paper Feed Sensor	Paper not detected	Paper detected
19	3rd Paper Feed Sensor	Paper not detected	Paper detected
20	Not Used	—	—
21	2nd Lift Sensor	Not lifted	Lifted
22	3rd Lift Sensor	Not lifted	Lifted
23	Built-in LCT Tray Down Sensor	Tray at down	Tray not down
24	Fusing Set Detection.	Not set	Set
25	Drum Unit Set Detection	Not set	Set
26	Right Tandem Paper End Sensor	Paper detected	Paper not detected
27	Left Tandem Paper End Sensor	Paper detected	Paper not detected
28	Right Tandem Tray Set Detection	Not set	Set
29	Left Tandem Tray Set Detection	Not set	Set
30	Rear Fence Return Sensor	Not at return position	At return position
31	Rear Fence HP. Sensor	Not at HP	At HP
32	Base Plate Down Sensor (Tandem)	Not down	Down
33	1st Paper Near End Sensor	Not at near end	Near end
34	1st Lift Sensor	Not lifted	Lifted
35	Side Fence HP. Sensor	At HP	Not at HP
36	3.5 K LCT Paper End Sensor	Paper detected	Paper not detected
37	3.5 K LCT Set Detection	Not set	Set

Input No	Sensor/Switch/|Signal	Status	
		0	1
38	3.5 K LCT Lift Sensor	Not lifted	Lifted
39	3.5 K LCT Tray Down Key	Not pressed	Pressed
40	3.5 K LCT Feed Sensor	Paper not detected	Paper detected
41	3.5 K LCT Tray Down Sensor	Tray not down	Tray down
42	3.5 K LCT Door Switches	Closed	Open
43	3.5 K LCT Paper Position Sensor	Paper not detected	Paper detected
44	Duplex Jogger HP Sensor	Not at HP	At HP
45	Duplex Entrance Sensor	Paper not detected	Paper detected
46	Duplex Transport Sensor	Paper not detected	Paper detected
47	Duplex Exit Sensor	Paper not detected	Paper detected
48	Duplex Unit Set Detection	Not set	Set
49	Duplex Paper End Sensor	Paper not detected	Paper detected
50	Toner End Sensor	Toner present	No toner
51	Toner Overflow Switch	No overflow	Overflow
52	By-Pass Table Switch	Closed	Open
53	Front Door Safety Switch	Closed	Open
54	Toner Collection Bottle Set Switch	Set	Not set
55	By-Pass Feed Motor Lock Detection	Not detected	Detected
56	Development Motor Lock Detection	Not detected	Detected
57	Main Motor Lock Detection	Not detected	Detected
58	Not used	—	—
59	Paper Feed motor Lock Detection	Not detected	Detected
60	Fusing/Duplex Drive Motor Lock Detection	Not detected	Detected
61	By-pass Paper Feed Motor Lock Detection	Not detected	Detected
62	Duplex Paper Guide Sensor	Paper not detected	Paper detected
63	Not used	—	—
64	Not used	—	—
65	3.5 K LCT Paper Near End Sensor	Paper detected	Paper not detected (Near end)
66	Guide Plate Position Sensor	Closed	Open
67	3.5 K LCT Motor Lock	Not detected	Detected
Input No 68 ~ 90 are not used.			
91	Auto Response Sensor	Not detected	Detected
92	Key Counter Connector	Open	Short
Input No 93 ~ 100 are not used.			

Input No	Sensor/Switch/|Signal	Status	
		0	1
101	Entrance Sensor (A377 S/S)	Paper detected	Paper not detected
	Entrance Sensor (Finisher)	Paper detected	Paper not detected
102	Proof Exit Sensor (A377 S/S)	Paper detected	Paper not detected
	Exit Sensor (Finisher)	Paper detected	Paper not detected
103	Jam Sensor (Photo transistor) (A377 S/S)	Paper detected	Paper not detected
	Shift Tray Half Turn Sensor (Finisher)	At HP	Not at HP
104	Bin Sensor (Photo transistor) (A377 S/S)	Paper detected	Paper not detected
	Stack Height Sensor 2 (Finisher)	At HP	Not at HP
105	Bin HP. Sensor (A377 S/S)	Not at HP	At HP
	Stack Height Sensor 1 (Finisher)	Not at HP	At HP
106	Wheel Sensor (A377 S/S)	Not interrupted	Interrupted
	Shift Tray Lower Limit Sensor (Finisher)	At lowest position	Not at lowest position
107	Bin Rear Plate Release Sensor (A377 S/S)	Not at release position	At release position
	Jogger Unit Entrance Sensor (Finisher)	Paper detected	Paper not detected
108	Bin Rear Plate HP. Sensor (A377 S/S)	Not at HP	At HP
	Jogger Unit Paper Sensor (Finisher)	Paper not detected	Paper detected
109	Jogger HP. Sensor (A377 S/S)	Not at HP	At HP
	Jogger HP. Sensor (Finisher)	Not at HP	At HP
110	Grip HP. Sensor (A377 S/S)	Not at HP	At HP
	Staple Unit HP. Sensor (Finisher)	Not at HP	At HP
111	Staple Unit HP. Sensor (A377 S/S)	Not at HP	At HP
	Stack Feed-out Belt HP. Sensor (Finisher)	At HP	Not at HP
112	Staple HP. Sensor	At HP	Not at HP
	Staple Hammer HP Sensor (Finisher)	At HP	Not at HP
113	Staple End Sensor (A377 S/S)	Present	Empty
	Staple End Sensor (Finisher)	At HP	Not at HP
114	Paper Sensor (A377 S/S)	Paper detected	Paper not detected
	Not Used	—	—
115	Door Safety Switch (A377 S/S)	Closed	Open
	Front Door Safety Switch	Closed	Open
116	Sorter Main Motor Encoder (A377 S/S)	—	—

Input No	Sensor/Switch/|Signal	Status	
		0	1
Input No 117 ~ 130 are not used.			
131	Scanner HP. Sensor	Not at HP	At HP
132	Lens vertical HP. Sensor	At HP	Not at HP
133	Lens Horizontal HP. Sensor	At HP	Not at HP
134	3rd Scanner HP. Sensor	Not at HP	At HP
135	Platen Cover Position Sensor 1	Not interrupted	Interrupted
136	Platen Cover Position Sensor 2	Not interrupted	Interrupted
137	Optics Thermistor	Low Temp.	High Temp.
Input No 138 ~ 150 are not used.			
151	Not Used (DJF)	–	–
	One Turn Sensor (RDH)	At HP	Not at HP
152	Original Set SN(DJF)	Original not detected	Original detected
	Pulse Generator Sensor (RDH)	Interrupted	Not interrupted
153	Original Feed SN (DJF)	Original not detected	Original detected
	Original Set Sensor (RDH)	Original not detected	Original detected
154	Not Used (DJF)	–	–
	Recycle Sensor (RDH)	Original not detected	Original detected
155	Lift Switch (DJF)	Down	Sifted
	Original Width Sensor (RDH)	Original not detected	Original detected
156	Feed-out Motor Encoder Pulse (DJF)	–	–
	Registration Sensor (RDH)	Original not detected	Original detected
157	Belt Drive Motor Encoder Pulse (DJF)	–	–
	Inverter Sensor (RDH)	Original not detected	Original detected
158	Feed-in Motor Encoder Pulse (DJF)	–	–
	Feed-out Sensor (RDH)	Original not detected	Original detected
159	Registration SN 2 (DJF)	Original not detected	Original detected
	Not used	–	–
160	Original Width SN 1 (DJF)	Original not detected	Original detected
	Transport Belt Motor Encoder Pulse (RDH)	–	–
161	Original Width SN 2 (DJF)	Original not detected	Original detected
	Feed-in Motor Encoder Pulse (RDH)	–	–
162	Original Width SN 3 (DJF)	Original not detected	Original detected
	Inverter Motor Encoder Pulse (RDH)	–	–

Input No	Sensor/Switch/|Signal	Status	
		0	1
163	Registration SN 1 (DJF)	Original not detected	Original detected
	Feed-out Motor Encoder Pulse (RDH)	–	–
164	Feed-out SN (DJF)	Original not detected	Original detected
	Lift Switch (RDH)	Down	Lifted
165	Not used (DJF)	–	–
	RDH Position Sensor (RDH)	Lifted	Down
166	DF Position SN (DJF)	Open	Closed
	Not used (RDH)	–	–
167	Feed Cover Switch (DJF)	Closed	Open
	Not used (RDH)	–	–
168	Not Used (DJF)	–	–
	Not used (RDH)	–	–
169	Original Length SN (DJF)	Interrupted	Not interrupted
	Not used (RDH)	–	–

2.4 ELECTRICAL COMPONENT CHECK (OUTPUT MODE)

CAUTION: The motors keep turning in this mode regardless of the upper or lower limit sensor signal. Do not keep the electrical component on for a long time to prevent mechanical or electrical damage.

– How to check the sensor/switch/signal –

1. Enter SP mode as follows:
   1) Press the mode clear key.
   2) Enter "107".
   3) Press the clear/stop key for more than 3 seconds.



2. Touch [2] [A] on the display to access SP Test mode.



3. Touch Next [A] on the display twice.



4. 1) Touch Output No. 00 [B].

2) Enter the electrical component number by using the number keys on the operation panel. (Refer to the table in the following pages.)

3) Press the Enter key [C].

4) Press ON [D] to activate and press OFF [E] to de-activate the electrical component.



NOTE: When confirming the activating sound, keep the front door open.

If the front door is closed, when OFF is touched, a mechanical noise caused by home positioning disturbs actual de-activating sound.

Service Tables

Output Check Mode Table – 1

Output No.	Electrical Component
1	Not used
2	Junction Solenoid
3	LCT Feed Clutch
4	By-pass Feed Clutch
5	Duplex Transport Clutch
6	Toner Supply Clutch
7	By-pass Pick-up Solenoid
8	Guide Plate Solenoid
9	LCT Pick-up Solenoid
10	Toner Bottle Motor
11	Duplex Transport Clutch
12	Pressure Arm Solenoid
13	Duplex Positioning Solenoid
14	LCT Down Key LED
15	Not used
16	Main Motor Forward
17	Main Motor Reverse
18	Fusing/Duplex Drive Motor
19	Development Motor
20	Paper Feed Motor - Low Speed
21	Paper Feed Motor - High Speed
22	LCT Motor - Up
23	LCT Motor - Down
24	By-pass Feed Motor - Low
25	By-pass Feed Motor - High (First Copy)
26	Anti-condensation Heater Relay
27	1st Pick-up Solenoid
28	2nd Pick-up Solenoid
29	3rd Pick-up Solenoid
30	Not used
31	1st Pressure Solenoid
32	2nd Pressure Solenoid
33	3rd Pressure Solenoid
34	Not used
35	Toner Collection Motor - High
36	Toner Collection Motor - Low
37	Tandem Lock Solenoid

Output No.	Electrical Component
38	1st Lift Motor (Up)
39	1st Lift Motor (Down)
40	2nd Lift Motor (Up)
41	2nd Lift Motor (Down)
42	3rd Lift Motor (Up)
43	3rd Lift Motor (Down)
44	Not used
45	Not used
46	Rear Fence Drive Motor (Counterclockwise)
47	Rear Fence Drive Motor (Clockwise)
48	1st Paper Feed Clutch
49	2nd Paper Feed Clutch
50	3rd Paper Feed Clutch
51	Not used
52	Registration Clutch
53	Main Power Relay
54	Erase Lamp
55	Charge Wire Cleaner Motor
56	Transfer Belt Positioning Solenoid
57	Potential Calibration Mode (–100 V)
58	Potential Calibration Mode (–800 V)
59	QL/PTL
60	Charge Corona/Grid (Copying)
61	Charge Corona/Grid (ID Sensor Pattern)
62	Development Bias (Copying)
63	Development Bias (Non-image Area)
64	Development Bias (ID Sensor Pattern)
65	Transfer Current
66	Exhaust Fan - Low
67	Exhaust Fan - High
Output No68 ~ 100 are not used	
101	Main Motor: Proof mode (A377 S/S) / Not used (Finisher)
102	Main Motor: Sort mode (A377 S/S)
	Transport Drive Motor (Finisher)
103	Exit Motor (A377 S/S) / Not used (Finisher)
104	Turn Gate Solenoid (A377 S/S)
	Exit Drive Motor (Finisher)

Output No.	Electrical Component
105	Bin Drive Motor (A377 S/S)
	Junction Gate Solenoid (Finisher)
106	Jogger Motor (A377 S/S)
	Positioning Roller Solenoid (Finisher)
107	Bin Rear Plate Drive Motor (A377 S/S)
	Jogger Motor (Finisher)
108	Grip Motor (A377 S/S)
	Sift Motor (Finisher)
109	Grip Positioning Solenoid (A377 S/S)
	Stack Feed-out Motor (Finisher)
110	Grip Solenoid
	Shift Tray Lift Motor (Finisher)
111	Staple Unit Drive Motor (A377 S/S)
	Not used (Finisher)
112	Staple Motor (A377 S/S)
	Stapler Drive Motor (Finisher)
113	Not used (A377 S/S)
	Staple Motor (Finisher)
Output No 114 ~130 are not used	
131	Optics Cooling Fan
Output No132 ~ 151 are not used	
152	Not used (DJF) / Original Gate Solenoid (RDH)
153	Not used (DJF) / Inverter Solenoid (RDH)
154	LED "READY" (DJF) / Push Plate Solenoid (RDH)
155	LED "AUTO" (DJF) / Feed-in Clutch (RDH)
156	Not used (DJF) /Feed-in Motor (Clockwise) (RDH)
157	Feed-in motor (DJF) / Feed-in Motor (Counterclockwise) (RDH)
158	Feed-out Motor (DJF) / Feed-in Motor (Clockwise) (RDH)
159	Not used (DJF) / Feed-in Motor (Counterclockwise) (RDH)
160	Belt Drive Motor (DJF) / Transport Belt Motor (Forward) (RDH)
161	Not used (DJF) / Transport Belt Motor (reverse) (RDH)
162	Separation Solenoid - SADF (DJF) / Inverter Motor (RDH)
163	Not used (DJF) / Feed-out Motor (Low) (RDH)
164	Not used (DJF) / Feed-out Motor (High) (RDH)
165	Stopper Solenoid (DJF) / Friction Belt Motor (RDH)
166	Inverter Solenoid (DJF) / Not Used (RDH)
167	Feed-In Clutch (DJF) / LED "READY" ON (RDH)
168	Not Used (DJF) / LED "READY" OFF (RDH)

2.5 USER TOOLS

This mode is for the key operators in charge of this copier. The operator can change or set the copier's default settings using the following user tools.

2.5.1 User Tools Menu







2.5.2 How To Access The User Tools

1. Press the Clear Modes key.
2. Press the Clear/Stop key more than 3 seconds until the User Tool Menu appears on the touch panel display.



3. Select the menu number to use by touching the touch panel display.



This copier has 12 user tools. You can see 5 user tools on the touch panel display at the same time. Use these keys to see the rest of the user tool menu.



Use to exit the user tool.

Use to return to the user tool menu display.

1 Auto reset/Auto off

Auto reset	The copier returns to its initial condition automatically after your job is finished. The automatic reset time can be set from 1 second to 999 seconds, or the function can be turned off. **Default:** 60 sec.
Screen Saver	When the machine does not detect anyone operating it for the selected time, the touch panel display turns off automatically. This time can be set from 1 second to 999 seconds, or the function can be turned off. **Default:** 60 sec.
Auto off	When the copier is used after the weekly timer has turned it off, the copier will turn itself back off after the selected time. The auto off time can be set from 1 minute to 999 minutes, or the function can be turned off. **Default:** OFF
SADF Auto reset (for machines with dual job feeder only) (system A or B)	In the SADF mode (Semi-Automatic Document Feed, see page 23), if the next original is not set within the selected time, the machine will cancel the SADF mode automatically. The SADF Auto reset time can be set from 1 second to 60 seconds, or the function can be turned off. **Default:** 5 sec.

2 Select special tray

Tray for Cover Sheet	Select the tray for the Cover function. Paper for cover sheets will be fed from the selected tray. **Default:** No select
Tray Display for Cover Sheet	You can see which tray is set for cover sheets. If you want to see the tray display only in the Cover mode, select "Mode selected". If you want to always see the tray display, select "Full time". **Default:** Full time
Tray for Slip Sheet	Select the tray for the Slip Sheet functions (Paper Designate and OHP Slip Sheet). Paper for slip sheets will be fed from the selected tray. **Default:** No select
Tray Display for Slip Sheet	You can see which tray is set for the slip sheets. If you want to see the tray display only in the Slip Sheet mode, select "Mode selected". If you want to always see the tray display, select "Full time". **Default:** Full time

- The trays set for cover sheets or slip sheets cannot be used for the Auto Paper Select, Auto Tray Switching, and Duplex copying modes.

3 Set date/time

Use to set the copier's internal clock before setting the weekly timer. Set the clock following the touch panel display instructions.

- If necessary, remember to adjust the clock for daylight saving time (summer time), or return it to standard time.

4 Weekly Timer

Use to set the weekly timer. If you set the timer, the copier turns on and off automatically at the selected time each day.

- **Default:** No weekly timer setting
- If you want to turn on the machine for an entire day, input "000" for the ON time and do not input the OFF time.
- If you want to turn off the machine for an entire day (ex.: Saturday, Sunday), do not input the ON time and input "000" for the OFF time.

5 Set operation modes

Maximum copy input number	The maximum copy quantity can be set from 1 to 999. **Default**: 999
Panel beeper	The beeper (key tone) can be set to on or off. ❒ default: ON
Job End Call	The beeper (job end call) sounds when your copying job is finished, supplies (toner, paper) run out, or if a problem occurs in the machine. The Job End Call can be set to on or off Default: ON
Next ↓	↑ Prev.
Image Density Level	Auto and Manual Image Density levels can be adjusted to be lighter or darker. **Default:** **(center)**
Default Setting	You can select Program No. 5 (see page 42) as a default mode. Use it to store job settings you frequently use. **Default:** Normal
Touch Panel in Waiting Mode	You can select the animation display during the warm-up period and copying run. During the warm-up period, the remaining warm-up time is displayed. During copying, you can see how long it takes to finish copying by entering the number of originals with the Number keys and Enter key. To exit the animation display, touch the Exit key of the touch panel display. **Default:** Reset (no animation display)

6 Change fixed R/E

This copier has 10 fixed ratios (4 enlargements and 6 reductions). You can change these fixed reproduction ratios to different ratios.

7 Set standard tray display

Paper Tray Priority	When Auto Paper Select is canceled, the 1st tray is selected as a default setting. You can cancel this setting and select the other tray as a default setting. **Default:** OFF
Auto Paper Select Priority	As a default setting, the Auto Paper Select is selected. You can cancel this setting. **Default:** Yes
Paper Tray Display in APS mode	In the default setting, the tray display is shown only when the Auto Paper Select mode is canceled. You can cancel this setting and have the tray display shown always. **Default:** No
Auto Tray Switching	If you load paper of the same size and in the same direction in two or more paper trays, the machine automatically shifts to the other tray when the tray in use runs out of paper. **Default:** Yes Bypass feed tray, and trays for cover sheet and slip sheet cannot be used for Auto Tray Switching.

12 Select ARDF/RDH modes

This user tool can be used only when your machine is equipped with the dual job feeder (system A and B) or the recirculating document handler (system C).

Original Count Display	In the default setting, you can see the entered copy quantity on the upper part of the copy counter and the number of copies made on the lower part. You can cancel this setting and see the number of originals to be fed on the lower part of the copy counter. On the upper part, you can see the number of copies made. To cancel the default setting, select "Yes". **Default:** No
Auto Paper Select	In the default setting, the Auto Paper Select is not selected when you set originals in the dual job feeder or recirculating document handler. You can cancel this setting. **Default:** No
Thin Paper mode (for machines with dual job feeder only) (system A or B)	Use when changing the type of originals to be fed. Select this function when you use thin originals (lighter than 53 g/m^2, 14 lb). **Default:** No

☞ Regarding User Tools No. 8, 9, 10, and 11, see the next page.

User Tools for User Code Mode

If the copier is set to use the User Code function, operators must input their user codes before the machine can operate. The copier keeps count of the number of copies made under each user code.

User tools 8, 9, 10 and 11 are for the User Code mode. When you want to use these user tools, you should enter the key operator access code first.

8 Set User Code(s)

Register	Use to register your user code (maximum: 6 digits) ❒ Up to 500 user codes can be registered. ❒ Registered user codes will be sorted in numerical order.
Change	Use to change your present code to a new one. ❒ The number of copies made under the old code is added to that made under the new user code.
Delete	Use to delete your user code. ❒ The number of copies made under the code is deleted.

9 Check/Reset copy count

You can check the number of copies made using each user code. Also, you can clear each code's counter.

10 Reset data for User Codes

Use to reset counter data for all user codes.

11 Reset User Codes/Counters

Use to reset all user codes and counters.

3. TEST POINTS / CHECK POINTS

3.1 MAIN CONTROL BOARD

TP Number	Label	Monitoring Signal
TP101	(PSN)	ID Sensor Output
TP102	(TSN)	TD Sensor Output
TP103	(VLT)	Drum Potential Sensor Output
TP104	(D.TH)	Drum Thermistor Output
TP105	(SIZE)	By-pass Size Signal
TP106	(LAMP)	Exposure Lamp Voltage Monitor Signal
TP107	(FUSER)	Fusing Thermistor Output
TP108	(+5V)	VCC
TP109	(GND)	GND
TP110	(+24V)	VAA
CP101	—	CPU2 → CPU1
CP102	—	CPU1 → CPU2
CP103	—	RXD SS
CP104	—	TXD SS
CP105	—	RXD
CP106	—	TXD
CP107	—	RXD
CP108	—	TXD
CP109	—	RXD
CP110	—	TXD
CP111	—	RXD
CP112	—	TXD
CP113	—	RXD ADF
CP114	—	TXD ADF
CP115	—	Not Used
CP116	—	Not Used
CP117	—	PRT CTS
CP118	—	PRT SOUT

NOTE: TP101 ~ 110 have test pins.

3.2 OPTICS CONTROL BOARD

TP Number	Label	Monitoring Signal
TP501	(ADS)	ADS Sensor Output
TP502	(UNIT-TEMP)	Optics Thermistor Output
TP503	(MOTOR-TEMP)	Scanner Motor Thermistor Output
TP504	(GND)	CGND
TP505	(+5V)	VCC
TP506	(SC-START)	Scanner Start Signal
TP507	(ENCODER-OUT)	Scanner Encoder Signal
TP508	(LP-PWM)	Exp. Lamp PWM
TP509	(HT-PWM)	Fus. Lam PWM
TP510	(SC-PWM)	Scanner PWM
TP511	(SC-DIR)	Scanner DIR
TP512	(FREE-RUN)	Scanner Free Run
TP513	(+24V)	VAA
TP514	(UNIT-ADJ-MODE)	Adjustment Mode
TP515	(ZERO-CROSS)	Zero Cross
TP516	(+38V)	VMM
TP517	(RXD)	RXD
TP518	(THRMST)	Fusing Thermistor Output
TP519	(LAMP)	Exposure Lamp Voltage
TP520	(LE)	Lead Edge
TP521	(TXD)	TXD
TP522	(SUB-IN)	SUB IN

NOTE: TP504, 512, 514 have test pins.

3.3 OPERATION PANEL BOARD

TP Number	Label	Monitoring Signal
TP101	(CPUCK)	CPU Check
TP102	(CLK)	Clock
TP103	(FLM)	Fluorescent Lamp Monitor
TP104	(GND)	GND

4. PREVENTIVE MAINTENANCE SCHEDULE

4.1 PM TABLE

NOTE: The numbers mentioned for PM intervals indicate the number of copies.
Symbol key: C: Clean R: Replace L: Lubricate I: Inspect

	EM	120 K	240 K	360 K	NOTE
OPTICS					
Mirrors, Lens, Reflectors		C	C	C	Cotton pad with water, or blower brush.
Exposure Glass	C	C	C	C	Alcohol or glass cleaner.
Platen Cover Sheet	C	R	R	R	Alcohol or water (replace if necessary).
Scanner Guide Rail		C	C	C	Dry cloth.
ADS, Original Size sensor	C	C	C	C	Blower brush.
Toner Shield Filter	C	C	C	C	Dry cloth, Discharge any static before installation.
Scanner/Lens Guide Rods		L	L	L	Refer to NOTE 1
PAPER FEED (for each paper feed station)					
Paper Feed Rollers (Paper Trays)	C	R	R	R	Water. Replace pick-up, feed, and separation rollers as a set.
Paper Feed Rollers (By-pass/LCT)	C	R	R	R	Water, replace pick-up, feed, and separation rollers as a set.
Paper Feed Guide Plate		C	C	C	Alcohol.
Registration Sensor		C	C	C	Blower brush.
Vertical Transport Rollers		C	C	C	Water
Paper Dust Cleaner		C	C	C	Dry cloth or blower brush
Registration Rollers		C	C	C	Water or alcohol.
Vertical Transport Guide Pin			L		Refer to NOTE 2
AROUND THE DRUM					
Corona Wires	C	R	R	R	Dry cloth or water.
Wire Cleaner			R		
Cleaner Drive Gear			L		Refer to NOTE 3
Charge Grid		R	R	R	
VD, VL, ADS Pattern	C	C	C	C	Dry cloth.
Drum Grounding Terminal		I	I	R	
End Blocks and Casing	C	C	C	C	Water.

	EM	120 K	240 K	360 K	NOTE
Pre-Transfer Lamp Filter	C	C	C	C	Dry cloth and blower brush. Discharge any static before installation.
Quenching Lamp	C	C	C	C	Dry cloth and blower brush.
ID Sensor	C	C	C	C	Blower brush.
Erase Lamp Unit	C	C	C	C	Dry cloth.
Pick-off Pawls	C	C	C	C	Replace if necessary.
Drum Potential Sensor	C	C	C	C	Dry cloth or blower brush.
Cleaning Blade		R	R	R	
Cleaning Seal		C	C	C	Replace if necessary.
Cleaning Brush			R		
Toner Collection Bottle	C	C	C	C	Empty used toner.
Cleaning Drive Section			L		Refer to NOTE 4
DEVELOPMENT UNIT					
Developer		R	R	R	
Upper Seal		C	C	C	
Side Seals		C	C	C	
Air Filter		R	R	R	Vacuum cleaner
Toner Bottle Holder	C	C	C	C	Dry cloth.
Toner Receiver	C	C	C	C	Dry cloth.
Toner Bottle Holder		L	L	L	Refer to NOTE 5
TRANSFER BELT UNIT					
Transfer Belt	C	C	R	C	Dry cloth, clean both sides.
Cleaning Blade		R	R	R	
Belt Drive/Guide/ Bias Rollers		C	C	C	Dry cloth
FUSING/PAPER EXIT UNIT					
Hot Roller		C	R	C	Replace if necessary.
Pressure Roller and Pressure Roller Bearings		C	R	C	Replace if necessary.
Stripper Pawls	C	C	R	C	Replace.
Fusing Entrance and Exit Guides		C	C	C	Suitable solvent.
Fusing Thermistor		C/L	C/L	C/L	Suitable solvent. Refer to NOTE 6
Transport/Exit Rollers			C		Water.

	EM	120 K	240 K	360 K	NOTE
Hot Roller Isolating Bushing			L		Refer to NOTE 6
DUPLEX (for duplex copies)					
Feed Roller		R	R	R	
Separation Belts		R	R	R	
Pick-up/Transport Rollers		C	C	C	
Positioning Pins/Holes		L	L	L	Refer to NOTE 7
OTHERS					
Ozone Filter				R	
Drive Belts		I	I	I	Replace if necessary.
Exit Sensor		C	C	C	Blower brush.
Bushings			L		Spindle oil.
Development Drive Gear				C	
DUAL JOB FEEDER (for originals)					
Transport Belt	C	R	R	R	Belt cleaner. Replace if necessary.
Pick-up Roller	C	C	C	C	Alcohol. Replace if necessary.
Feed Roller	C	R	R	R	Alcohol. Replace if necessary.
Separation Belts	C	R	R	R	Alcohol. Replace if necessary.
SORTER STAPLER (A377)					
Rollers	C	C	C	C	Water.
Bins		C	C	C	Water.
Bushings		L	L	L	Use Launa oil or equivalent.
Gears		L	L	L	Use Grease–501.
SORTER STAPLER (A374)					
Bins		C	C	C	Water.
Rollers		C	C	C	Water.
Bushings		L	L	L	Use Launa oil or equivalent.
Gears		L	L	L	Use Grease–501.

	EM	120 K	240 K	360 K	NOTE
RECIRCULATING DOCUMENT HANDLER					
Transport Belts	C	C	R	C	Belt cleaner. Replace if necessary.
Feed Roller	C	R	R	R	Alcohol. Replace if necessary.
Separation Belt	C	R	R	R	Alcohol. Replace if necessary.
FINISHER					
Rollers		C	C	C	Water.
Bushings		L	L	L	Use Launa oil or equivalent.
Gears		L	L	L	Use Grease–501.

The location of the parts which should be lubricated at PM, are shown in the following figures:

NOTE 1: Scanner/Lens Guide Rods

(1) Lubricate the horizontal and vertical lens guide rods [A] with Launa Oil every 120 K copies.



(2) Lubricate the third scanner guide rod [B] with Launa oil every 120 K copies.



NOTE 2: Vertical Transport Guide Lock Pin

(1) Lubricate the vertical transport guide lock pin [A] with Mobil Temp. 78. every 240 K copies.



NOTE 3: Charge Wire Cleaner Drive Gears

1. Open the drive motor cover [B] (2 screws).

   NOTE: When re-installing the cover, do not tighten the screws too much.

2. Lubricate the charge wire cleaner drive gears every 240 I



NOTE 4: Cleaning Drive Section

(1) Lubricate the cleaning blade shift cam [A] with Grease G501 every 240 K copies.



(2) Lubricate the cleaning section drive gear [B] with Grease G501 every 240 K copies.



NOTE 5: Toner Bottle Holder

(1) Lubricate the toner bottle drive gears [C] with Grease G501 every 120 K copies.

(2) Lubricate the toner bottle holder [D] with Mobil Temp. 78 every 120 K copies.



NOTE 6: Fusing Section

(1) Clean the surface of th
thermistor [A] where tc
hot roller. Then apply s
of silicone oil there eve
copies.



(2) Lubricate the inner anc
surface of the isolating bushing [B]
with BARRIERTA L55/2 grease
every 240 K copies.



NOTE 7: Duplex Unit

(1) Lubricate the two positioning pins
[C] and two positioning Holes [D]
with Mobil Temp. 78 every 120 K
copies.



4.2 EXPLANATION OF REGULAR PM

Item		Explanation
Optics Unit	Mirrors, Lens, Reflector, Exposure Glass, Platen Cover, Toner Shield Filter	Stains on any part of the optics unit result in black lines or areas of decreased sharpness on the copy image. Periodic cleaning is required. The exposure glass and the platen cover sheet must also be cleaned. If stains on the platen cover sheet cannot be removed, it must be replaced.
	Exposure Lamp	Deterioration of the exposure lamp affects the copy image. Check the lamp at regular intervals and replace if discolored.
	V_D, V_L, ADS Patterns	If paper dust or toner accumulates on the V_D, V_L, ADS Patterns, the image density cannot be controlled correctly. This results in light or dark copies. Clean these patterns at regular intervals.
Transfer Belt Unit	Transfer Belt	A dirty or old transfer belt causes poor image transfer due to its weak chargeability. Clean (both front and rear sides) or replace the transfer belt at regular intervals.
	Belt Drive/ Guide/Bias Rollers	Dirty rollers shift the transfer belt to the front or rear.
	Cleaning Blade	A dirty or worn out cleaning blade will cause toner to adhere on the rear side of the copy. The blade must be replaced at regular intervals.
Paper Feed, Registration	Paper Feed Roller, Pick-up Roller, Separation Roller	This machine uses paper trays, a by-pass feed table, and an LCT for paper feeding. If paper dust adheres to the paper feed rollers or if these rollers are worn out, paper may not feed correctly, or skewing may result. Replacing is required at regular intervals.
	Registration Roller	A dirty registration roller can cause paper to register incorrectly, skew, or jam. Cleaning is required at regular intervals.
	Paper Dust Cleaner	Too much paper dust caught in the cleaner causes paper dust overflow. This results in early deterioration of the cleaning blade, fusing rollers, etc. Clean at regular intervals.
	Registration Sensor	A dirty registration sensor causes paper jams. Clean at regular intervals.

Item		Explanation
Around the Drum	Charge Wires/ Wire Cleaner/ Charge Grid	Dirty charge wires may cause uneven image density. They should be replaced at regular intervals.
	End Blocks	Toner tends to accumulate on the corona end blocks, this can result in a high voltage leak. Clean end blocks at regular intervals.
	Drum Grounding Terminal	Too much drum grounding terminal deterioration causes poor drum grounding. This results in dirty backgrounds and drum potential sensor calibration errors.
	QL	If toner accumulates on the QL, a dirty background or a repeating negative image may result. Clean the QL at regular intervals.
	PTL	If paper dust or toner accumulates on the PTL filter, its efficiency may be reduced. This can cause toner to be reattracted to the drum during transfer, reducing image density. Clean the PTL filter at regular intervals.
	ID Sensor	If too much paper dust or toner accumulates on the ID sensor, the toner density cannot be controlled correctly. This results in light copy or over toning. Clean this sensor at regular intervals.
	Erase Lamp	If toner accumulates on the erase lamp, a dirty background may occur in the erased area that becomes progressively worse in long copy runs. Also this affects sensor pattern detection, causing incorrect toner density and exposure lamp control. Clean this lamp at regular intervals.
	Cleaning Blade	A dirty or worn out cleaning blade will cause black lines on copies or scratches on the drum. The blade must be replaced at regular intervals.
	Cleaning Brush	A worn out cleaning brush will not clean the drum surface effectively, resulting in a dirty background and damage to the cleaning blade. Replace at regular intervals.
	Toner Collection Bottle	If the toner collection bottle becomes full, a service call condition occurs and copying is prohibited. Empty the toner collection bottle at regular intervals.
Developme-nt Unit	Developer	The tribo-chargeability of overused developer decreases. This results in toner scattering. Developer must be replaced at regular intervals.

Item		Explanation
Fusing Unit	Thermistor	If toner accumulates on the thermistor, fusing temperature control may not be accurate. Clean the thermistor at regular intervals.
	Stripper Pawls	Toner or dust adhering to the stripper pawls can cause a paper jam. Clean or replace the pawls at regular intervals.
	Fusing Entrance and Exit Guides	Toner piling up on the guide plate will cause a dirty background on the copy or paper jam. Clean the guide plate at regular intervals.
Duplex Unit	Separation/Feed/ Transport Rollers and Separation Belts	If paper dust adheres to the separation/feed/transport rollers and the separation belts, paper may not feed correctly, or skewing may result. Replacement is required at regular intervals.
Others	Ozone Filter	When an ozone filter deteriorates, ozone produced in the copier will not be absorbed, causing headaches, irritations, or other discomforts. Replace at regular intervals.
DJF	Transport Belt	A dirty transport belt can leave stains on copies. Replace the belt at regular intervals.
	Pick-up Roller, Feed Roller, Separation Belt	When dirty, these rollers and this belt can leave stains on the copy paper. Also, original misfeeds or multi-feeds may occur. Replace these parts at regular intervals.
RDH	Transport Belt	A dirty transport belt can leave stains on copies. Clean or replace the belt at regular intervals.
	Feed Roller Separation Belts	When dirty, these rollers and these belts can leave stains on the copier. Also, original misfeeds or multi-feeds may occur. Replace these parts at regular intervals.

4.3 REGULAR PM PROCEDURE


Every 120k
Every 240k or 360k
1. Make a copy
Make a copy of O-S-A3 test chart at manual image density level 4.
2. Optics (every 120 K)
2-1. Clean the mirrors, lens and reflectors by using a soft cloth, cotton pad with water, or a blower brush.
2-2. Clean the exposure glass with alcohol or water.
2-3. Clean the scanner guide rail with a dry cloth.
2-4. Clean the magnification guide rail with a dry cloth.
2-5. Clean the ADS sensor and the original width and length sensors with a blower brush.
2-6. Inspect the exposure lamp, if necessary, replace it.
2-7. Lubricate the lens and 3rd scanner drive guide rods. [Launa oil]
3. Around the Drum (every 120 K)
3-1. Remove and open the drum unit and clean the ID and Drum Potential sensors with a blower brush.
3-2. Clean the pick-off pawls and the toner shield filter. Discharge any static electricity on the filter.
Lubricate the cleaning drive gears (every 240 K) [Grease-G501]
3-3. Clean the QL and PTL filter, and erase lamp with a dry cloth, discharge any static before installation.
Replace the wire cleaner and lubricate the drive gears [Grease-G501] (every 240 K)
3-4. Clean the end blocks and casing with water or alcohol.
3-5. Replace the grid plate and corona wire.
3-6. Clean the registration rollers and paper dust cleaner.
Replace the cleaning brush (every 240 K)
3-7. Empty the toner collection bottle.
3-8. Clean the inside of the cleaning section, cleaning brush, and seals.
3-9. Replace the cleaning blade.



4-1. Remove the developer.

4-2. Clean the development unit and gears.

4-3. Pour a pack of new developer.

4-4. Replace the air filter.

4-5. Clean the toner bottle holder and toner receiver.

4-6. Lubricate the bottle drive mechanism. [Grease G-501]

5-1. Clean the paper guide plates and vertical transport/relay rollers.

5-2. Replace the paper feed, pick-up, and separation rollers.

Note:
The feed (pick-up, feed, separation) rollers for the 1st ~ 3rd feed trays are different from the feed rollers for the by-pass feed table and 3.5 K LCT.
There is no interchangeability.

5-3. Clean the registration sensor.

5-4. Lubricate the transport guide lock pin.

6-1. Clean the transfer belt.

6-2. Replace the transfer unit cleaning blade.

6-3. Clean the belt drive/guide rollers and bias Surlier.

7-1. Replace the separation roller and separation belts.

7-2. Clean the feed and transport rollers.

7-3. Lubricate the duplex positioning pins.



8-1. Clean the entrance and exit guide plates.

8-2. Clean the thermistor and apply silicone oil.

8-3. Clean the stripper pawls.

9-1. Clean the exit rollers.

9-2. Inspect the antistatic brush.

9-3. Clean the exit sensor.

10-1. Lubricate the gears.

10-2. Inspect the timing belts.

11-1. Clean the covers.

12-1. Perform the developer initial setting. (1 SP Adjustment – PAGE 1).

12-2. Perform the process control data initial setting. (1 SP Adjustment – PAGE 1).

CAUTION: Perform the developer initial setting only when the new developer is installed.
Never make any copies before the developer initial setting.

SECTION 5

REPLACEMENTS AND ADJUSTMENTS

1. EXTERIOR AND INNER COVER REMOVAL

1.1 FRONT SIDE



1.1.1 Left Front Cover

1. Open the left front door [A] then unhook the chain (1 screw).
2. Pull out the pin [B].
3. Unhook the upper pin [C].

1.1.2 Right Front Door

1. Open the left front door [D].
2. Open the right front door [E].
3. Lower the pin [F] to unhook the upper hinge bracket [G].
4. Unhook the lower pin [H].

1.2 REAR SIDE



1.2.1 Upper Rear Cover

1. Turn off the main switch.
2. If the DJF or RDH is installed, disconnect the fiber optics connectors [A] and [B].

   NOTE: After the upper rear cover is re-installed, set the fiber optics connectors [A] and [B] so that the fiber optic cable [A] is located over the electrical cable [B]. Also, the fiber optic cable [A] should not bend while opening and closing the DJF or RDH.
3. Remove the upper rear cover [C]. (4 screws)

1.2.2 Lower Rear Cover

1. Remove the lower rear cover [D]. (6 screws)

   NOTE: When installing the lower rear cover, set the hooks in the holes on the right and left side covers.



1.2.3 Left Inner Cover

1. Remove the left front door [A].
2. Remove the left inner cover (4 screws) [B].

1.2.4 Right Inner Cover

1. Open the right door [C].
2. Remove knob (B1) [D] (1 screw).
3. Remove the right inner cover [E] (2 screws).

1.2.5 Shutter Inner Cover



1. Open the right door.
2. Remove the shutter cover [A] by releasing the hook [B].
3. Remove the shutter inner cover [C] (1 screw).

NOTE: 1. Be sure to move the lever [D] until it contact the part [E].
2. While installing the shutter cover [A], the lever [D] must be pushed as shown.

1.3 RIGHT SIDE

1.3.1 Feed Unit Cover



1. Open the by-pass table [A] approximately 45 degrees and push the stoppers [B] of the feed unit cover [C] by using a small flat head screw driver [D], then remove the feed unit cover.



1.3.2 Upper Right Cover

1. Remove the right inner cover [A], shutter cover [B] and the shutter inner cover [C]. (Refer to Shutter Inner Cover Removal.)
2. Remove the upper rear cover [D]. (Refer to Upper Rear Cover Removal.)
3. Open the manual feed table and remove the upper right cover [E] (6 screws).

1.3.3 Lower Right Cover

1. Remove the lower rear cover. (Refer to Lower Rear Cover Removal.)
2. Open the right door.

   NOTE: When installing the lower right cover, set the hooks in the holes on the right and left side covers.
3. Remove the lower right cover [F] (4 screws).

1.4 LEFT SIDE



1.4.1 Upper Left Cover

1. Remove the left inner cover. (Refer to Left Inner Cover Removal.)
2. Remove the upper rear cover [A]. (Refer to Upper Rear Cover Removal.)
3. Remove the upper left cover [B] (4 screws).

   NOTE: When installing the upper left cover, set the hooks in the holes on the right and left side covers.

1.4.2 Lower Left Cover

1. Pull out the second and the third feed trays [C].
2. Remove the lower rear cover [D].
3. Remove the lower left cover [E] (4 screws).

   NOTE: When installing the lower left cover, set the hooks in the holes on the right and left side covers.

1.5 OPERATION PANEL





1. Turn off the main switch.
2. Remove the left door. (Refer to Left Door Removal.)
3. Remove the left inner cover. (Refer to Left Inner Cover Removal.)
4. Open the right door.
5. Open the toner bottle.
6. Remove three screws [A].
7. Remove two screws [B] securing the protective earth wires.
8. Insert the screw driver through the hole [C] and push the operation panel [D] up.
9. Disconnect the connector [E].

NOTE: Be sure not to damage the harness by pulling the connector too strongly.

1.6 UPPER SIDE



1.6.1 Upper Cover

1. Turn off the main switch.
2. Remove six screws [A].
3. Remove two screws [B] securing the grounding wires.
4. Disconnect two connectors [C].
5. Remove the upper cover [D].

1.6.2 Rear Upper Cover

1. Turn off the main switch.
2. Remove the platen cover or document feeder (DJF or RDH) from the copier.
3. Remove the upper cover.
4. Remove the 2 screws securing the rear upper cover [E].
5. Disengage the hooks [F] by sliding the rear upper cover to the front and remove it.

2. OPTICS

2.1 EXPOSURE GLASS REMOVAL



1. Turn off the main switch.
2. Remove the left scale [A] (2 shoulder screws).
3. Remove the rear scale [B] (3 screws).
4. Grasp the left edge of the exposure glass [C] and lift slightly. Slide the other edge out from under the right glass holder [D]. Remove the exposure glass.

   NOTE: When reinstalling the exposure glass, make sure that the mark (white: A095 copier/red: A096 copier) on the edge of the glass is located at the rear right corner. This side is smoother and it generates less static electricity when the RDH is used.

2.2 EXPOSURE LAMP REPLACEMENT



NOTE: Do not touch the reflector or the new exposure lamp with your bare hands. Use a strip of paper as shown. (Oil marks from fingers on the lamp or reflectors will be affected by heat from the lamp.)

1. Remove the exposure glass. (Refer to Exposure Glass Removal.)
2. Move the first scanner [A] to the cutout position at the rear frame [B]. (See illustration.)
3. Remove the reflector cover [C] (2 screws).
4. While holding the lamp with the paper strip, release the lamp terminal [D] as shown; then, take out the lamp.
5. Install a new lamp. Use a strip of paper as shown to hold the lamp. Confirm that the lamp is properly set by both terminals and that the clip [E] is set properly.



NOTE: Make sure that the blister [A] on the lamp points towards the reflector opening (left side of the copier) as shown.

6. Reassemble the copier.
7. Turn on the main switch and enter SP mode, then perform the process control data initial setting ([1] SP Adjustment – PAGE 1).

2.3 OPTICS THERMOSWITCH REPLACEMENT



NOTE: The thermoswitch can be reset manually by pushing the red button [A] when the exposure lamp area cools.

1. Remove the exposure glass. (Refer to Exposure Glass Removal.)
2. Move the first scanner to the cutout position at the rear frame.
3. Remove the reflector cover [B] (2 screws).
4. Remove the exposure lamp leads [C] from the terminals on both sides of the thermoswitch [D].
5. Remove the thermoswitch bracket [E] (1 screw).
6. Remove the thermoswitch from the bracket (2 screws), and replace it.

2.4 SCANNER HP SENSOR REPLACEMENT



1. Remove the upper rear cover [A]. (Refer to Upper Rear Cover Removal.)
2. Remove the exhaust fan [B] (3 screws).
3. Manually turn the scanner drive pulley [C] counterclockwise to move the scanners about 10mm to the left (rear view).
4. Remove the scanner HP sensor bracket [D] (1 screw).
5. Disconnect the connector.
6. Replace the scanner HP sensor [E] (1 screw).

2.5 ADS SENSOR REMOVAL



1. Remove the exhaust fan [A]. (Refer to Scanner HP Sensor Replacement.)
2. Remove the DJF/RDH connector bracket [B] (2screws).
3. Remove the ADS Sensor [C] with the cover [D] (1screw).
4. Replace the ADS Sensor [C] (2 screws).
5. Assemble the copier.
6. Turn on the main switch and enter SP mode, then perform the Auto ADS initial setting (1 SP Adjustment-PAGE 5).

2.6 SCANNER DRIVE MOTOR



1. Remove the exhaust fan. (Refer to Scanner HP Sensor Replacement.)
2. Remove the tension spring [A].
3. Remove the tension tightener [B].

   NOTE: Re-install the tightener as follows;

   1) Hook part [C] of the bracket on the screw [D] installed on the scanner drive motor bracket.
   2) Hook the tension spring [A].
   3) Install two screws.

4. Remove the two connectors [E] from the Optic Control Board.
5. Remove the scanner motor [F] (4 screws).

   NOTE: While replacing the drive pulley, the gap [G] should be 0.5mm so that the upper edge [H] of the pulley is lower than the upper surface [I] of the bracket, as shown. After installing the scanner motor, perform the scanner control adjustment. (Refer to Scanner Control Adjustment.)

2.7 SCANNER DRIVE WIRES REPLACEMENT

- Removal -



1. Turn off the main switch.
2. Remove the exposure glass.
3. Remove the upper cover and the rear upper cover.
4. Remove the optics thermistor [A] (1 screw, 1 harness clamp).
5. Remove the scanner HP sensor with bracket . (Refer to Scanner HP Sensor Replacement.)
6. Remove the scanner drive motor. (Refer to Scanner Drive Motor Replacement)
7. Unhook the harness from the two harness clamps [B].
8. Remove the upper optics frame [C] (9 screws).



9. Remove the lens unit cover [A] (2 screws).

10. Unhook the tension spring [B].

11. Remove the lens shield plate [C].

NOTE: When installing the lens shield plate, set the rear part [D] of the lens shield plate between the guides [E] as shown. Then set the grooves on the guide pins [F] in the rail [G].
After reinstalling the tension spring, confirm that movement of the lens shield plate is smooth.



12. Remove the front bracket [A] (2 screws).
13. Remove the screw [B] securing the scanner flat cable.
14. Unhook the four harness clamps [C].
15. Disconnect the connector [D] outside the optic side frame.
16. Remove the connector [E] from the optic side frame.
17. Remove the scanner clamps [F] securing both sides of the first scanner unit to the scanner wires (4 screws).



18. Remove the harness cover [A] (2 screws).
19. Remove the light shield mylar bracket [B] (1 screw).
20. Disconnect the paper length size sensor connector [C] and move the lens unit to the left, then remove the rear bracket [D] (2 screws).
21. Unhook the tension spring [E] and remove the scanner wire [F].
22. Remove the second scanner [G].

NOTE: When re-installing the mylar bracket [B], be sure not to create any gap between the bracket and the lens cover.



23. Remove the left inner cover [A] (4 screws).
24. Remove the E-ring [B] of the scanner drive shaft and remove the front ball bearing [C].
25. Remove the rear drive pulley [D] (1 Allen screw) and remove the rear ball bearing [E].
26. Loosen the two Allen screws of the front drive pulley [F] and slide the pulley about 10 cm to the rear then take out the drive shaft.

- INSTALLATION -



1. Round the rear scanner drive wire on the rear pulley as follows:

   1) Align the cut out [A] on the edge of the rear drive pulley and the blue mark [B] on the wire as shown.
   2) Round the wire counterclockwise 5 times as shown (in the illustration, the D-cut [C] on the shaft is at the front side) then set the bead [D] on the wire in the hole [E] on the pulley.
      (In this condition, the bead just reaches the hole on the pulley.)
   3) After setting the bead in the hole, round the wire two more times (in total 7 times).
   4) Fix the wire with tape [F] as shown.



2. Round the front scanner drive wire on the front pulley as shown:

   1) Align the cut out [A] on the edge of the front drive pulley and the red mark [B] on the wire.
   2) Round the wire clockwise 5 times as shown (in the illustration, the Allen screw holes are at the rear side) then set the bead [C] on the wire in the hole [D] on the pulley.
      (In this condition, the bead just reaches to the hole on the pulley.)
   3) After setting the small ball in the hole, round the wire twice more (in total 7 times).
   4) Fix the wire with tape [E] as shown.



3. Set the front drive pulley [A] on the drive shaft. (Leave the Allen screws loosened.)
4. Place the scanner drive shaft [B] in the holes on the optics front and rear side frames.
5. Set ball bearings [C] on both sides of the scanner drive shaft.
6. Set the E-ring [D] on the front end of the scanner drive shaft.
7. Set, and fully push in, the scanner drive pulley [E] on the front end of the scanner drive shaft, then tighten the Allen screw [F].
8. Install the scanner drive motor. (Refer to Scanner Drive Motor Replacement.)
9. Place the second scanner [G] on the guide rail and fix it there by using two jig pins [H].

   NOTE: This jig pin is used as the left door hinge pin [I]. However, only one pin is used on the copier, so it is necessary to prepare another one.



10. Route the shorter end [A] of the rear scanner drive wire in the following order.

    ❶ Rear track counterclockwise

    ❷ Clockwise

    ❸ Lower track clockwise.

    ❹ Fix the end of the wire on the frame with tape [B].



11. Route the longer end [A] of the rear scanner drive wire in the following order.

❶ Through front track, upper side.

❷ Counterclockwise.

❸ Upper track counterclockwise.

❹ Hook the end [B] of the wire on the cutout on the right optics side frame.



12. Route the shorter end [A] of the front scanner drive wire in the following order.

    ❶ Front track counterclockwise
    ❷ Clockwise
    ❸ Lower track clockwise.
    ❹ Fix the end of the wire on the frame with tape [B].



13. Route the longer end [A] of the front scanner drive wire in the following order.

    ❶ Through rear track, upper side.

    ❷ Counterclockwise.

    ❸ Upper track clockwise.

    ❹ Hook the end of the wire [A] on the cut out on the right optics side frame.

14. Slightly push the front drive pulley [B] against the front optics side frame and tighten the two Allen screws.

15. Remove the jig pins securing the second scanner.

16. Remove the tapes [C] fixing the ends of the scanner drive wires and hook the ends of the scanner drive wires with the tension springs.

17. Remove the tapes [D] fixing the wire to the front and rear drive pulleys.



18. Install the rear bracket [A] (2 screws, 1 connector), shielding mylar bracket [B] (1 screw) and harness cover [C] (2 screws).

19. Adjust the second scanner alignment as follows:

- Second Scanner Alignment -

1) Move the second scanner [D] to the left end position. Fix the rear side of the second scanner by inserting the jig pin [E] in the holes on the rear side of the second scanner and the rear guide rail.
2) Turn the adjusting nut [F] to adjust the second scanner alignment so that the jig pins [G] can be smoothly set in the holes on the front side of the second scanner and the front guide rail.



20. Place the first scanner unit on the guide rail then adjust the first scanner alignment as follows:

- First Scanner Alignment -

1) Move the first scanner [A] to the left end position. Fix the rear end of the first scanner by inserting the jig pin [B] in the holes on the first scanner and the guide rail.
2) Position the first scanner so that the jig pin [C] can be smoothly set in the holes on the first scanner and the guide rail, then tighten the wire clamp brackets [D] (4 screws).

21. Install the scanner HP sensor [E] (1 screw).

22. Secure the scanner flat cable (1 screw).

23. Install the upper optics frame [F] (9 screws).





24. Turn on the main switch and perform the scanner free run for about 5 minutes to break in the wires and to confirm correct scanner movement as follows:

- Scanner Free Run -

1. Remove the air inlet duct [A] (1 screw).
2. Remove CN502, CN503, CN504 from the optic control Board [B].
3. Short-circuit TP514 and TP504(GND) on the optics control Board.
4. Turn on the main switch.
5. Short-circuit TP512 and TP504(GND), then the machine automatically starts the scanner free run.
6. Turn off the main switch.

25. After performing the scanner free run, check the second scanner alignment, then the first scanner alignment.

26. Perform the scanner control adjustment. (Refer to Scanner Control Adjustment.)

27. Check the copy image.

2.8 SCANNER CONTROL ADJUSTMENT



Perform this adjustment under any one of the following conditions:

After the scanner motor replacement
After the scanner wire replacement
After the scanner timing belt replacement
After replacing the optics control Board

1. Perform the free run (2 Test Mode – PAGE 1) 30 times.
2. After the free run is completed, turn the rotary dip switch [A] until LED 501 [B] turns on.

   NOTE: If this adjustment is improper, the timing between the scanner and the paper feed will be also improper, causing paper jams at the registration roller, or causing scanner noise due to wire vibration.

2.9 THIRD SCANNER REMOVAL



1. Remove the exposure glass. (Refer to Exposure Glass Removal.)
2. Remove the upper cover [A]. (Refer to Upper Cover Removal.)
3. Remove the lens unit cover [B] (2 screws).
4. Remove the two screws [C] fixing the front third scanner bracket.
5. Remove the sixth mirror [D].
6. Remove the third scanner [E] as shown.

2.10 THIRD SCANNER DRIVE MOTOR / HP SENSOR REPLACEMENT



1. Remove the third scanner unit. (Refer to the Third Scanner Removal.)
2. Open the right front cover then remove the shutter cover [A].
3. Remove the shutter inner cover [B] (1 screw).
4. Open the toner bottle [C] and close the toner hopper cover [D].
5. Remove the third scanner drive unit [E] (3 screws [F]).
6. Replace the third scanner drive motor [G] (1 connector, 2 screws).
7. Remove the third scanner HP sensor [H] with the bracket [I] (1 screw).
8. Replace the third scanner HP sensor (1 screw).

2.11 LENS HORIZONTAL DRIVE BELT REMOVAL



1. Remove the lens unit cover [A] and light shielding plate [B]. (Refer to Scanner Drive Wires Replacement.)
2. Remove the light shielding mylar bracket [C] (1 screw).

   NOTE: When re-installing the mylar bracket [C], be sure not to create any gap between the bracket and the lens cover.
3. Remove the flat cable bracket [D] (1 screw, 2 connectors).
4. Position the roller [E] underneath the bracket [F].



5. Remove the lens unit [A] (2 screws).
6. Loosen the tension pulley bracket [B] (1 screw).
7. Push the pulley bracket to the front then unhook the timing belt [C].
8. Remove the two timing belt holders [D] (1 screw each).

NOTE: When setting the timing belt, align the end [E] of the timing belt to the edge [F] of the belt holder.

2.12 LENS VERTICAL DRIVE BELT REMOVAL



1. Remove the third scanner drive unit. (Refer to Third Scanner Drive Motor Replacement.)
2. Remove the front bracket [A]. (Refer to Scanner Drive Wires Replacement.)
3. Remove the lens unit [B]. (Refer to Lens Horizontal Drive Belt Replacement.)
4. Loosen the two screws [C] fixing the tension pulley bracket [D].
5. Push the tension pulley bracket to the left (front view) then unhook the timing belt.

2.13 ORIGINAL SIZE SENSORS (2 LENGTH SENSORS, 1 WIDTH SENSOR)



1. Remove the exposure glass. (Refer to Exposure Glass Removal.)
2. Remove the lens unit cover [A] (2 screws).
3. Remove the original size sensor covers [B] (1 screw each).
4. Replace each original size sensor [C] (1 screw, 1 connector each).

3. DEVELOPMENT AND TONER SUPPLY

3.1 DEVELOPMENT UNIT REMOVAL



1. Turn off the main switch.
2. Open the front doors.
3. Remove the shutter cover [A] by releasing the hook [B].

   NOTE: Be sure to move the lever [C] until it contacts part [D] (fully to the front).
4. Remove the shutter inner cover [E] (1 screw).
5. Open the toner bottle holder [F].

   NOTE: To open the toner bottle holder completely, while lowering the shutter lever [G], push the bracket [H] to the right.



6. Close the toner hopper cap [A].
7. Remove the screw [B] fixing the drum stay [C].
8. Remove the drum stay knob [D] then take out the drum stay.
9. Disconnect the two connectors [E].
10. Pull out the development unit [F].

NOTE:
1. To prevent drum scratches, push the development unit to the right while pulling it out.
2. When installing the development unit, do not forget to set the two connectors [E].
3. When installing the drum stay, be careful not to pinch the harness. Also, keep the harness away from gears.
4. When pulling out the development unit, do not hold the knob [G].

3.2 DEVELOPER REPLACEMENT



1. Take out the development unit. (Refer to Development Unit Removal.)
2. Place the development unit on the sheet [A] included with new developer.
3. Remove the two screws [B] fixing the toner hopper [C].
4. Turn the toner hopper 90 degree, then move it up to remove it from the development unit.
5. Turn over the development unit then turn the paddle roller knob [D] to empty developer onto the sheet. (The one way clutch in the knob [D] allows turning the paddle roller counterclockwise only.)

   NOTE: Dispose of used developer according to local regulations.

Make sure that no developer remains on the development rollers or in the development unit.



6. Clean the side seals [A] and entrance seal [B].

   NOTE: Cover the sleeve rollers with a sheet of paper [C] to prevent the used developer being attracted to the sleeve rollers.

7. Evenly pour in one pack of developer [D] while turning the knob [E].
8. Re-install the toner hopper, then re-assemble the machine.

   NOTE: Be sure to set to connectors after installing the development unit in the machine.

9. Turn on the main switch, then perform developer initial setting (1 SP Adjustment – PAGE.1).

CAUTION: Never make any copy with the new developer before completing the developer initial setting, otherwise toner density control will be abnormal.

NOTE: If the developer initial setting is not completed, you cannot exit the SP mode by pressing the "Quit" key. If this occur turn the main switch off and on, then perform the initial setting again. If the result is the same, see the troubleshooting section "SC352" (Page 6-9).

3.3 DEVELOPMENT ROLLERS REPLACEMENT



1. Remove the developer. (Refer to Developer Replacement.)
2. Remove the developer entrance seal [A] (2 screws, 2 hooks).
3. Remove the front and rear side seals [B].

NOTE: When re-assembling the development unit, use new side seals and align the edge of the side seals to the corner [C] and the edge [D] as shown.



4. Remove the coupling gear [A] (1 screw).

   NOTE: Be careful not to lose the pin [B].

5. Remove the gear [C] (1 E-ring), gear [D] (1 E-ring) and gear [E].

CAUTION: Do not touch the screws at [F] and [G].
If the screws at [F] are loosened, the doctor gap will be improper.
If the screws at [G] are loosened, the photoconductor gap and magnetic field angle will be improper.
If either of them become abnormal, toner density control will be abnormal.

6. Remove the front roller holder [H] (1 screw and 2 E-rings) and rear roller holder [I] (1 screw).

7. Replace the sleeve rollers.
8. Re-assemble the development unit and set the developer, then re-assemble the copier.

CAUTION: If the original developer (already used) is returned to the development unit, do not perform the developer initial setting.

If the new developer is set, never make any copy before completing the developer initial setting (1 SP Adjustment – PAGE.1).

3.4 TONER DENSITY SENSOR REPLACEMENT



1. Remove the developer. (Refer to Developer Replacement.)
2. Replace the TD sensor [A] (2 screws).

   NOTE: Before installing the TD (Toner Density) sensor, clean the development unit well so that no carrier particle remains in the gap between the TD sensor and the development unit casing.

3. Install the new developer and perform the developer initial setting.

CAUTION: Never make any copy before completing the developer initial setting.

3.5 TONER BOTTLE DRIVE MOTOR REPLACEMENT



1. Open the toner bottle holder [A] with the bracket [B]. (Refer to Development Unit Removal.)
2. Remove the toner bottle [C].
3. Remove four screws then remove the toner bottle holder by unhooking the hole [D] from the pin on the hinge.
4. Remove the toner receiver [E].
5. Remove the toner bottle drive motor assembly [F] (1 connector, 2 screws).
6. Remove an E-ring [G] and slide the gear [H] to access a screw.
7. Replace the toner bottle drive motor [I] (3 screws – M3 x 4).

4. DRUM UNIT

4.1 DRUM UNIT REMOVAL AND OPC DRUM REPLACEMENT



1. Take out the development unit. (Refer to Development Unit Removal.)
2. Lower the transfer belt unit.
3. Take out the drum unit by holding the knob [A].

   NOTE: Close the protective shutter [B] to protect the OPC drum from light when the drum unit is left outside the machine for servicing.

4. Open the upper drum unit (2 screws [C]).
5. Replace the OPC drum. Then remove the drum protective sheet from the new drum.

   NOTE: When returning the drum unit to the copier, do not forget to open the protective shutter [B].
   If it is hard to completely set the drum unit in the machine because the gear is disengaged, then push in the drum unit while holding down the cleaning blade release knob [D].

4.2 QUENCHING LAMP REPLACEMENT





1. Remove the OPC drum. (Refer to Drum Unit Removal and OPC Drum Replacement.)

   NOTE: Wrap a protective sheet or a few sheets of paper around the drum to protect it from light.

2. Slightly pull up the wires [A] on the quenching lamp, then insert the head of the small flat head screw driver [B] between the quenching lamp and the drum unit casing to release the hook [C] at the center of the quenching lamp.

   NOTE: Do not pull the wire too strongly.

3. Disconnect the connector [D].

4. Replace the quenching lamp.

4.3 GRID PLATE / CHARGE WIRE / WIRE CLEANER REPLACEMENT



1. Take out the main charge corona [A] (1 screw, 1 connector).
2. Remove the grid plate [B] (1 plastic screw, 4 hooks).

   NOTE: When installing the grid plate, do not tighten the plastic screw [C] too strongly.
3. Remove the front grid terminal [D], then the front end block cover [E].
4. Remove the terminal spring [F].
5. Slide the rear grid terminal [G] to the rear and remove it, then remove the rear end block cover [H].
6. Remove the charge corona wire [I].



7. Remove the wire cleaner [A] (1 snap ring).

8. Install the wire cleaner and the charge corona wire.

   NOTE: Locate the joint part [B] of the wire in the rear end block as shown.
   Correctly set the wire between the wire cleaner pads.
   Do not loosen the screw [C], otherwise the charge corona height will change.

4.4 ERASE LAMP AND DRUM POTENTIAL SENSOR REPLACEMENT



1. Open the drum shutter [A].
2. While pushing the hook [B] to the front by using a small flat head screw driver [C], move up the front side of the erase lamp [D] as shown.
3. Slide the erase lamp to the front to release the rear side of the erase lamp from the drum unit casing.
4. Disconnect the connector [E].

   NOTE: Before removing the drum potential sensor, set a few sheets of paper between the sensor and the OPC drum to protect the drum surface.
5. Replace the drum potential sensor [F].

CAUTION: After replacing the drum potential sensor, perform the process control data initial setting.
(1 SP Adjustment – PAGE.1)

4.5 CLEANING BLADE REPLACEMENT



1. Remove the OPC drum. (Refer to Drum Unit Removal and OPC Drum Replacement.)
2. Remove the cleaning blade [A] (2 screws).
3. Clean the entrance seal [B], side seals [C] and cleaning brush [D].

   NOTE: When a vacuum cleaner is used, to protect the electrical parts from static electricity, disconnect the connector on the charge power pack and remove the ID sensor as follows:

   1) Disconnect the 12P connector on the charge power pack [E].
   2) Remove the screw [F] and separate the upper and the lower drum units.
   3) Remove the pick-off pawl bracket [G] (2 screws).
   4) Disconnect the connector [H].
   5) While turning the bracket counterclockwise (front view), slide the pick-off pawl bracket to the rear.

4. Install the new cleaning blade.

   NOTE: Do not clean the edge of the cleaning blade with cloth, otherwise it damages the edge and causes black lines on copy images.
   Do not touch the edge of the new cleaning blade, if some setting powder or toner on the blade edge is removed, apply toner there.
   When installing the cleaning blade, do not pinch the side seals.

4.6 CLEANING BRUSH REPLACEMENT



1. Remove the cleaning blade. (Refer to Cleaning Blade Replacement.)
2. Remove the coupling gear [A] (1 screw).
3. Remove the grounding wire [B] (1 screw).
4. Remove the bushing [C].
5. Pull the cleaning brush shaft to the rear to release the cleaning brush [D], then remove the cleaning brush.

   NOTE: Do not touch the cleaning brush with oily hands.
   After replacement, clean the ID sensor surface.

4.7 PICK-OFF PAWL REPLACEMENT



1. While pulling the shaft [A] to the rear, turn the pick-off pawl about 45 degree clockwise (front view) and move up the pick-off pawl.
2. Replace the pick-off pawl.

   NOTE: Do not forget to hook the tension spring [B].
   After replacement, check the smooth movement of the pick-off pawl.

4.8 TONER COLLECTION COIL REPLACEMENT



NOTE: Before starting the procedure remove the drum unit and the transfer belt unit to prevent toner from dropping in the machine.

1. Open the front doors then remove the toner collection bottle [A] (1 push-lock [B]).
2. Remove the upper and lower rear covers. (Refer to Upper and Lower Rear Covers Removal.)
3. Remove the tank cover bracket [C] (2 screws).
4. Remove the toner collection motor [D] (2 connectors, 2 screws).

   NOTE: When re-installing the toner collection motor, be sure to set the 2 positioning pins in the holes on the machine rear frame.



5. Open the main control board [A] (2 screws).
6. Remove the pulley bracket [B] and the timing belt [C] (1 screw).

   NOTE: When re-installing the timing belt [C], be sure that the belt is correctly hooked on the four pulleys as shown.
7. Remove the belt tightener unit [D] (2 screws).
8. Remove the four screws [E] fixing the toner collection coil casing [F] to the machine rear frame.



9. Remove the upper right cover [A]. (Refer to Upper Right Cover Removal.)

10. Remove the pin [B] of the push-lock fixing the toner collection coil casing.

NOTE: When removing the push-lock pin [B], catch the pin with needle-nose pliers [C] (accessing from the hole under the main control board, as shown).
When re-setting the push-lock pin [B], hold the pin with needle-nose pliers. Then, while holding the pin above the push-lock holder [D], push the pin head down with you finger. Insert your finger from the space below the LCT connector bracket, as shown.



11. Remove the exhaust fan [A] (1 connector, 3 screws).
12. Remove the main motor [B] (1 connector, 4 screws).
13. Remove the toner collection coil casing [C] and put it on the sheet of paper.
14. Disassemble the toner collection coil casing [D] (8 screws).
15. Remove the drive pulley [E] (1 E-ring).
16. Replace the toner collection coil [F].

4.9 OZONE FILTER REPLACEMENT



1. Open the front doors and open the toner bottle holder.
2. Remove the transfer belt unit prop [A] (3 screws).
3. Replace the ozone filter [B].

NOTE: To install the transfer belt unit prop smoothly, set in order the lower pins [C], drive roller shaft [D], and the upper pins [E].

5. TRANSFER BELT UNIT

5.1 TRANSFER BELT UNIT REMOVAL/INSTALLATION



- Removal -

1. Turn off the main switch.
2. Remove the transfer belt unit prop [A] (3 screws).
3. Disconnect the connector [B].
4. While turning the lever [C] counterclockwise, take out the transfer belt unit.

   NOTE: 1) Do not touch the transfer belt with oily hands.
   2) Take care not to scratch the OPC drum with part of the transfer belt unit. Be careful when installing the transfer belt unit.

- Installation -

1. While turning the lever [C] counterclockwise, install the transfer belt unit.

   NOTE: 1) Insert the gear [D] in the hole [E] on the rear frame.
   2) Place the slot [F] of the transfer belt unit on the rail [G].



2. Install the transfer belt unit prop (3 screws).

   NOTE: To install the transfer belt unit prop smoothly, set in order the lower pins [A], drive roller shaft [B], and the upper pins [C].

3. After installation, confirm the following points:
   1) Smooth up-down movement of the transfer belt unit,
   2) Part [D] of the transfer belt unit is inside the drum stay,
   3) Part [D] of the transfer belt unit is set in the dent [E] on the drum unit casing.

5.2 TRANSFER BELT REPLACEMENT



1. Take out the transfer belt unit. (Refer to Transfer Belt Unit Removal.)
2. While raising the knob [A], disconnect the two connectors [B].
3. Turn the transfer belt upper unit [C] 90 degrees counterclockwise, then raise and remove it.
4. Remove the screws [D].



5. Turn the belt drive roller holder [A] clockwise (front view).

6. Replace the transfer belt [B].

NOTE: 1) Before installing the transfer belt, clean both sides of the transfer belt with a dry cloth (do not use alcohol).

2) Before installing the transfer belt, clean the following items with alcohol.

- Belt drive roller [C]
- Belt roller [D]
- Bias roller [E]
- Discharge terminal [F]

3) Position the transfer belt at the center of the belt roller [D]. (Both marks [G] should be visible.)

4) Set the transfer belts inside the bias terminals [H].

5.3 CLEANING BLADE REPLACEMENT



1. Remove the transfer belt. (Refer to Transfer Belt Replacement.)
2. Remove the cleaning blade [A] (2 screws).
3. Clean the seals [B].

   NOTE: When using a vacuum cleaner, to protect the transfer power pack from static electricity, remove the power pack as follows:

   1) Disconnect two connectors [C].
   2) While pushing the power pack toward the solenoid [D], release the power pack from the hook [E].

4. Install the new cleaning blade.

   NOTE: Do not touch the edge of the cleaning blade. If some of the setting powder on the blade edge is removed, apply setting powder or toner there.

6. PAPER FEED

6.1 PAPER TRAY UNIT REMOVAL



To facilitate transportation, the upper part of the copier (copier main frame) [A] and the lower part of the copier (paper tray unit) [B] can be separated as follows:

1. Turn off the main switch.
2. Remove the front covers. (Refer to Front Cover Removal.)
3. Remove the four screws [C].
4. Open the small rear cover [D] (1 screw).
5. Remove the five connectors [E].
6. Remove the copier main frame [A] from the paper tray unit [B].

NOTE: When re-installing the copier main frame on the paper tray unit, do not pinch the harness between the copier main frame and the paper feed unit.

6.2 PAPER TRAY REMOVAL

- Tandem Tray Removal (1st tray of the A096 copier) -



1. Open the left door and draw out the tandem tray.
2. While pushing the release lever [A] to the right with the head of the screw driver [B], slightly push the right tandem tray [C] to separate it from the left tandem tray [D].
3. Remove the stopper [E] (1 screw).
4. Remove the left tandem tray [D] from the left guide Accuride [F] (2 screws).
5. While holding the right tandem tray [C] from the bottom, remove the right tandem tray from the right guide Accuride [G] (2 screws).

   NOTE: If two screws are removed without holding the right tandem tray, it will drop.

- Universal Tray / 550 sheet tray/ Built-in LCT Removal
(all trays of the A095 copier / 2nd, 3rd trays of the A096 copier) -





1. Draw out the tray.
2. Remove the tray from both guide Accurides as shown (4 screws).

6.3 PAPER FEED ROLLERS REPLACEMENT



1. Turn off the main switch.
2. Remove the paper tray where the feed rollers belong to. (Refer to Paper Tray Removal.)
3. Remove the pick-up roller [A] (1 snap ring).
4. Remove the feed roller [B] (1 snap ring).
5. Remove the snap ring [C] fixing the separation roller [D] then separate the separation roller [D] from the torque limiter [E].

NOTE: 1) The paper feed (pick-up, feed, separation) rollers used in the 1st ~ 3rd feed units in the paper tray unit are different from the feed rollers used in the by-pass feed table and 3.5K LCT.
2) Do not touch the surface of the rollers with oily hand.

6.4 TANDEM REAR FENCE DRIVE BELT REMOVAL (A096 copier only)



1. Draw out the tandem tray.
2. Separate the right tandem tray from the left tandem tray [A]. (Refer to Tandem Tray Removal.)
3. Remove the rear fence [B] on the left tandem tray (2 screws).
4. Remove the rear base plate [C] with the rear fence drive motor [D] (3 screws).

   NOTE: When re-installing the rear base plate, make sure that the grounding plate [E] is attacked to the rear base plate.
5. Remove the end fence [F] (2 screws).
6. Remove the center bottom plate [G] (2 screws).



7. Disconnect the three connectors [A].
8. Loosen the tightener screw [B] and unhook the tension spring [C].
9. Remove the timing belt [D].

NOTE: When installing the timing belt, hook the spring [C] then, tighten the screw [B].

6.5 TANDEM SIDE FENCE MOTOR REMOVAL (A096 copier only)



1. Open the side fences [A] and raise the bottom plate [B] of the right tandem tray.
2. Remove the lift arm [C] (2 screws).
3. Remove the cover [D] (1 screw).
4. Remove the bracket [E] (2 screws [F]).
5. Remove the side fence drive motor [G] (2 screws [H] and 2 nuts).

   NOTE: When installing the side fence drive motor, move both side fences to the innermost position, then set the motor gear between the two rack gears [I].

6.6 PAPER FEED TIMING ADJUSTMENT





1) Paper feed timing adjustment for the 1st feed station

1. Place a white paper on the exposure glass so that there is a gap of 10 mm between the white paper [A] and the left scale [B].
2. Enter SP mode (refer to Service Program Access Procedure) and access the 1 SP Adjustment – PAGE 2.
3. Touch the **"Copy in SP"** key [C] then select the 1st feed station.
4. Enter a copy quantity of "2" using the number keys.
5. Touch the **"SP Mode"** key.
6. Press the **Start** key and evaluate the width of the white area [D] on the copy. The adjustment standard is 10 ± 5 mm.

   NOTE: In this mode, the registration roller does not stop for registration. Do not make copies in "Copy in SP" mode for this adjustment. In "Copy in SP" mode, the registration clutch stops normally.



7. For the first copy, touch the – key [A] or the + key [B] to adjust the white area width.
8. For the second copy, touch the – key [C] or the + key [D] to adjust the white area width.
9. Repeat steps 6 to 8.

2) Paper feed timing adjustment for the 2nd, 3rd feed stations, the LCT and duplex unit.

Refer to Paper Feed Timing Adjustment for the 1st feed station.

NOTE: Concerning the adjustment for the 1st feed station, it is necessary to adjust the feed timing for the 1st and 2nd papers individually. However, for the other feed stations, it is necessary to adjust the feed timing only for the 1st paper fed.

Therefore, you can skip steps 4 and 7 of the paper feed timing adjustment for the 1st feed station.





3) Paper feed timing adjustment for the by-pass feed station

1. Set two sheets of paper on the by-pass feed table [A].
2. Enter SP mode (refer to Service Program Access Procedure) and access 1 SP Adjustment – PAGE 2.
3. Touch the **"Copy in SP"** key [B].
4. Select the by-pass feed station.
5. Press the **start** key then when the paper stops for registration, mark the trailing edge [C] of the paper on the next paper as shown.
6. Measure the distance [D] between the leading edge of the mark [E] and the trailing edge of the paper [F] as shown. The adjustment standard is 106 ~ 115 mm.
7. Touch the **"SP Mode"** key.
8. Touch the – key [G] or the + key [H] to adjust the distance [D].
9. Touch the **"Copy in SP"** [B].
10. Repeat steps 5 to 9.

6.7 PAPER FEED CLUTCH REMOVAL



1. Turn off the main switch then open the right front door and remove the push-lock [A].
2. Remove the toner collection bottle [B].

   NOTE: If the LCT is installed, remove it from the copier.
3. Remove the lower right cover [C]. (Refer to Lower Right Cover Removal.)
4. Remove the upper then the lower vertical transport guides [D] and [E].







n remove the right inner cover [B] (2 screws).

6. While holding the shaft [C] with an Allen key, remove the fixing screw [D], then remove the knob [E].
7. Remove the magnet [F].
8. Pull out all paper trays then remove the paper tray unit inner cover [G] (2 screws).
9. Remove the two connectors [H].
10. Remove the support bracket [I] (1 screw).

    NOTE: The support bracket is used only for the first feed station.





11. Fully draw out the paper tray.
12. Remove the two screws [A] fixing the tray feed unit [B].
13. Remove the tray feed unit.
14. Disconnect the connectors [C].
15. Loosen the two Allen screws [D].
16. Remove the tray feed clutch [E] (1 connector).

NOTE: When re-installing the tray feed clutch, set the stopper [F] of the clutch on the edge of the bracket [G] then fully push in the clutch on the feed roller shaft [H] and secure the Allen screws [D].

6.8 BY-PASS FEED TABLE REMOVAL



1. Remove the right inner cover. (Refer to Right Inner Cover Removal.)
2. Remove the total counter with bracket (1 screw, 1 connector).
3. Loosen the Allen screw [A] on the hinge.
4. Remove the hinge pin [B] (1 screw).
5. Remove the by-pass feed table (1 connector).

6.9 BY-PASS FEED ROLLERS REPLACEMENT



1. Open the by-pass feed table then remove the cover [A] (3 screws).
2. Replace the pick-up roller [B] (1 snap ring) and the feed roller [C] (1 snap ring).

NOTE: The paper feed (pick-up, feed, separation) rollers used in the by-pass feed table and LCT are different from the paper feed rollers used in the 1st ~ 3rd feed units in the paper tray unit. They are not interchangeable.





3. Remove the feed unit cover [A] as shown.
4. Replace the separation roller [B] (1 snap ring).

6.10 BY-PASS PAPER SIZE SENSOR REPLACEMENT



1. Turn off the main switch.
2. Open the by-pass table and remove the feed unit cover. (Refer to Feed Unit Cover Removal.)
3. While pushing the hook [A] with the head of the flat head screw driver as shown, remove the table assembly [B] (2 screws, 1 connector [C]).
4. Remove the by-pass paper size sensor [D] (2 screws).



5. Re-install the by-pass paper size sensor then reassemble the by-pass feed table.

   NOTE: When installing the table assembly, route the wires [A] correctly as shown.
   The paper guides [B] must be in the lower position as shown.

6. Perform the by-pass feed sensor paper size correction ([1] SP Adjustment mode – PAGE 9) as follows:
   1) Enter SP mode (refer to Service Program Access Procedure) then access [1] SP Adjustment mode – PAGE 9.
   2) Place the side fence [C] at the A4 or 8 1/2 x 11 sideways position according to the paper size decal on the table.
   3) Place the side fence [C] at the A6 or 4 1/2 x 5 1/2 lengthwise position according to the paper size decal on the table.

6.11 BY-PASS FEED CLUTCH REMOVAL



1. Remove the upper rear cover [A]. (Refer to Upper Rear Cover Removal.)
2. Lower the main control board [B] (2 screws).
3. Unhook the main control board bracket hinge [C].



4. Remove the by-pass feed motor [A] (2 screws).
5. Remove the clutch stopper [B] (1 screw).

   NOTE: When re-installing the by-pass feed clutch [C], set the pin [D] of the clutch in the cutout [E] of the stopper.
6. Remove the by-pass feed clutch (1 connector).

6.12 REGISTRATION CLUTCH REMOVAL



1. Lower then unhook the main control board bracket hinge. (Refer to By-Pass Feed Clutch Removal.)
2. Remove the clutch stopper [A] (1 screw).

   NOTE: When re-installing the registration clutch [B], set the pin [C] of the clutch in the cutout of the stopper [D].
3. Loosen the Allen screw [E].
4. Remove the registration clutch (1 connector).

   NOTE: When re-installing the registration clutch, fully push in the clutch on the registration roller shaft [F] and secure the Allen screw.

6.13 PAPER DUST CLEANER REMOVAL



1. Remove the development unit. (Refer to Development Unit Removal.)
2. While pushing down the hook lever [A], remove the paper dust cleaner [B].
3. Remove paper dust inside the paper dust cleaner and clean the inside of the cleaner with a dry cloth or a blower-brush.

6.14 REGISTRATION SENSOR REMOVAL



1. Remove the right inner cover [A]. (Refer to Right Inner Cover Removal.)
2. Disconnect the connector [B].
3. Pull out the registration sensor assembly [C].
4. Clean the photo sensor [D] with a blower-brush.

6.15 COPIER FEED UNIT REMOVAL





1. Remove the development unit. (Refer to Development Unit Removal.)
2. Remove the right inner cover. (Refer to Right Inner Cover Removal.)
3. Remove the by-pass feed motor. (Refer to By-pass Feed Clutch Removal.)
4. Remove the three connectors [A] for the guide plate positioning solenoid, registration clutch, and the pick-up solenoid.

   NOTE: Before disconnecting the connectors, make sure to identify them. Some of the connectors use identical pin leads but they are not interchangeable. Take special care not to misconnect the positioning solenoid and registration clutch connectors.
5. Remove the upper right cover [B] and the paper feed unit cover [C].
6. Disconnect the three connectors [D].
7. Draw out the duplex unit about 10 cm.



8. Remove the registration roller knob [A] (1 screw).
9. Remove the copier feed unit [B] (4 screws).

NOTE: When installing the copier feed unit to the copier:

1) Do not pinch the harness.
2) Keep the duplex unit drawn out.
3) Fit the two cut outs [C] to the pins [D].

6.16 TANDEM FEED TRAY PAPER SIZE CHANGE

NOTE: 1. At the factory, all paper trays (1st, 2nd and 3rd) are set as A4 sideways. At the customer's request, change the paper size as follows.

2. For the 550 sheet fixed paper tray and the 1500 sheet built-in LCT, refer to the installation procedure section.



- Used as tandem tray for A4 sideways or smaller size paper -

1. Draw out the tandem tray [A].
2. Remove the rear and front side fences [B] (one screw and one pushlock each) on the right tandem tray.
3. Re-position the end fences [C] on both rear and front side fences (1 screw each) according to the paper size.



4. Re-install both side fences [A] to the appropriate position according to the paper size, as shown.

   NOTE: The position of the side fence holders [B] and the pins [C] on the lack gear differs according the paper size (from the outside pin: A4, 11", B5).

5. Change the position of the front and rear side fences [D] (2 screws each) and end fence [E] (2 screws) on the left tandem tray according to the paper size.

6. Enter SP mode (refer to Service Program Access Procedure) and access 4 SP Special Features – PAGE 5.

7. Select the appropriate paper size according to position of the side and end fences.





- Used as fixed tray for paper longer than A4/Letter sideways -

1. Draw out the tandem tray.
2. Remove the rear and the front side fences [A] (1 screw and 1 push-lock pin each) on the right tandem tray.
3. Remove the end fences [B] on both the rear and the front side fences (2 screws each).

   NOTE: It is not necessary to re-install the end fences.
4. Install both side fences to the appropriate position according to the paper size (one screw and one lock pin for each side fence).

   NOTE: Support plates [C] are used only for A4, B5, and letter lengthwise sizes.
   Keep the end fences and support plates for future use.



5. Change the position of the front and rear side fences [A] (2 screws each) and end fence [B] (2 screws) of the left tandem tray according to the paper size.
6. Enter SP mode (refer to Service Program Access Procedure) and access 4 SP Special Features – PAGE 5.
7. Select the appropriate paper size according to the side and end fences position.

6.17 UNIVERSAL TRAY PAPER SIZE CHANGE

At the factory, the universal paper tray is set as A4/8 1/2" x 11" sideways. Normally, paper size is changed by the customer by following the operating instructions.
Only when the customer needs the A5/5 1/2" x 8 1/2" lengthwise paper size does a service representative need to change the paper size. In this case, proceed as follows:



1. Install the front and rear side fences [A] (2 screws).

NOTE: These side fences are the same as the side fences used in the 550 sheet fixed paper tray.
These side fences are options, order them as service parts.

7. FUSING UNIT

7.1 FUSING UNIT REMOVAL



1. Turn off the main switch.
2. Open the left front door.
3. Remove the stopper [A] (1 screw).
4. While releasing the lever [B], pull out the fusing unit as shown.
   NOTE: Hold the bottom of the fusing unit as shown.

7.2 FUSING THERMISTOR REPLACEMENT



1. Remove the fusing unit. (Refer to Fusing Unit Removal.)
2. Remove the knob [A] (1 screw).
3. Remove the two screws fixing the fusing front cover [B].
4. Pull the lever [C] then lower the cover [B] to unhook the fusing unit.
5. Remove the fusing unit upper cover [D] (1 screw).
6. Replace the thermistor [E] (1 screw, 1 connector).

NOTE: When re-assembling the fusing unit, secure the harness in the clamps correctly.
Apply a little silicone oil at the thermistor's point of contact with the hot roller.

7.3 FUSING THERMOFUSE REPLACEMENT



1. Remove the fusing unit upper cover. (Refer to Fusing Thermistor Replacement.)
2. Remove the terminal bracket [A] (2 screws, 1 hook).
3. Disconnect the two connectors [B].
4. Replace the fusing thermofuse [C] (1 screw).

   NOTE: When re-assembling the fusing unit, secure the harness in the clamps correctly.

7.4 FUSING LAMP REPLACEMENT





1. Remove the fusing unit. (Refer to Fusing
2. Remove the terminal bracket [A] (2 screws).
3. Disconnect the front connector [B] and the rear connector [C].
4. Remove the front fusing lamp holder [D] and the rear fusing lamp holder [E] (1 screw each).
5. Replace the fusing lamp [F].

   NOTE: Locate the yellow connector [C] of the fusing lamp to the rear side.
   Set the connectors from the fusing lamp (yellow) [G] and from the thermofuse (white) [H] in the correct position on the terminal.

7.5 HOT ROLLER REPLACEMENT



1. Remove the fusing lamp [A]. (Refer to Fusing Lamp Replacement.)
2. Lower the fusing exit assembly [B].
3. Remove the upper stay [C] (4 screws).
4. Remove the upper entrance guide [D] (1 screw).



5. Lower both side pressure spring holders [A] by using the screw driver [B] as a lever.

6. Remove the front and rear C-rings [C], gear [D], antistatic spacers [E] isolating bushings [F] and bearings [G].

   NOTE: When installing a new fusing roller:

   1) Lubricate the inner and the outer surface of the isolating bushings [F] with BARRIERTA L55/2 grease.
   2) Lubricate the fusing drive gears and their shafts with grease G501.
   3) Peel off 3 cm (1 inch) form both ends of the protective sheet, and install the hot roller.
      Before applying fusing pressure, remove the rest of the protective sheet.

7.6 PRESSURE AND BEARING ROLLER REPLACEMENT



1. Remove the hot roller. (Refer to Hot Roller Replacement.)
2. Remove the lower fusing entrance guide [A] (2 screws).
3. Lift the pressure roller [B] and remove it.
4. Replace pressure roller and bearings [C].

   NOTE: When installing a new pressure roller:

   1) Lubricate the roller shaft and the inner surface of the bearings with BARRIERTA L55/2 grease.
   2) Lubricate the fusing drive gears and their shafts with G501 grease.
5. Re-assemble the machine.

7.7 FUSING STRIPPER PAWL REPLACEMENT



1. Turn off the main switch and pull out the fusing unit.
2. Lower the fusing exit assembly [A].
3. Remove the two screws (the front screw [B] is a stepped screw) fixing the upper exit guide [C].
4. Unhook the spring [D] then replace the strippers [E].

   NOTE: After setting the fusing stripper pawl, confirm that the strippers are correctly held by the stripper holders [F] as shown. If not, remove the stripper and bend the holders [F] inward. Apply the grease-Barrierta L55/2 on the inner surface of the holder [F].

7.8 FUSING PRESSURE ADJUSTMENT



NIP BAND WIDTH ADJUSTMENT STANDARD: 8.1 ± 0.8 mm

1. Make a black copy (sky shot, A3 / Double Letter paper).
2. As soon as the paper starts to exit, open the left door to stop the paper in the fusing unit.
3. Wait about 20 seconds, then turn the fusing knob quickly to deliver the paper.
4. Measure the nip band width [A] at the center.
5. If the nip band width is not within 8.1 ± 0.8 mm, change the spring hook position [B].

7.9 PAPER EXIT UNIT REPLACEMENT

- Removal -



1. Remove the upper left cover. (Refer to Upper Left Cover Removal.)
2. Draw out the duplex unit [A].
3. Remove the lever bracket [B] (2 screws).
4. Disconnect the two connectors [C].
5. Take out the paper exit unit [D] (4 screws).

   NOTE: Place the paper exit unit so that the paper exit roller comes to the bottom to prevent the brush roller from being pressed and damaged.

- Installation -



1. Set the paper exit unit in the following order:
   1) Set the drive shaft [A] on the left rail [B].
   2) Set the plate [C] on the right rail [D].
   3) Set the positioning pin [E] in the hole [F].

2. Install the paper exit unit (2 connectors, 4 screws).

3. Re-assemble the copier.

8. DUPLEX UNIT

8.1 FEED ROLLER REPLACEMENT



1. Open the front doors and draw out the duplex unit.
2. Remove the duplex front cover [A] (3 screws).
3. Slide the lever [B] to the rear then open the duplex reverse assembly [C].
4. Remove the lower separation guide plate [D] (2 screws).
5. Remove the snap ring [E].



6. Remove the harness bracket [A] (1 screw).
7. Remove the gear [B] (1 E-ring).
8. Remove the bushing [C] (1 E-ring).
9. Slide the feed roller shaft [D] to the rear then slide the feed roller [E] to the front and replace it as shown.

8.2 SEPARATION BELTS REPLACEMENT



1. Open the front doors and draw out the duplex unit.
2. Remove the gear [A] (1 E-ring).
3. Remove the bracket [B] (1 screw) then remove the gear [C].
4. Remove the gear [D] and the bushing [E] (1 E-ring).
5. Remove the separation belt unit [F].
6. Remove the guide mylar [G] (2 snap rings).



7. Remove the bushing [A] (1 snap ring).
8. Remove the drive roller [B].
9. Replace the three separation belts [C] as a set.

NOTE: When setting the tension spring [D], set it on the hook [E] normally. The hook [F] applies higher separation pressure.
Confirm that the separation belt is correctly set between the guides [G].
Confirm that the snap rings [H] do not touch the separation belts.

8.3 DUPLEX UNIT REMOVAL



1. Open the front doors and remove the left door.
2. Remove the right inner cover [A]. (Refer to the right inner cover removal.)
3. Draw out the duplex unit [B] until the stop position.
4. Take out the right and left stopper pulleys [C] (1 snap ring each).
5. Take out the duplex unit.

8.4 SEPARATION CLUTCH/TRANSPORT CLUTCH REMOVAL



Before replacing both clutches, take out the duplex unit. (Refer to Duplex Unit Removal.)

NOTE: When installing both clutches, be sure to set the stopper [A] to the projection [B].

- Separation Clutch -

1. Remove the harness bracket [C] (1screw).
2. Remove the E-ring [D].
3. Replace the separation clutch [E].

- Transport Clutch -

1. Remove the E-ring [F].
2. Replace the separation clutch [G].

8.5 JOGGER MOTOR REPLACEMENT



1. Take out the duplex unit. (Refer to the duplex unit removal.)
2. Remove the duplex front cover (3 screws).
3. Slide the lever [A] to the rear then open the separation belt unit [B].
4. Remove the lower separation guide plate [C] (2 screws).
5. Remove the pressure arm [D] (1 snap-ring).
6. Remove the harness cover [E] (1 screw).
7. Remove the two connectors [F].
8. Remove the upper stay [G] (4 screws, 1 connector).



9. Remove the positioning roller drive gear [A] (1 E-ring).
10. Remove the bushing [B] (1 E-ring).
11. Remove the positioning roller assembly [C].
12. Remove the front jogger fence [D] and the rear jogger fence [E] (1 screw each).
13. Remove the duplex tray [F] (3 screws and a connector).

    NOTE: To release the hooks [G], slide the duplex tray to the upper left as shown.



14. Remove the drive wire stoppers [A].
15. Unhook the tension spring [B] and remove the drive wire [C].
16. Remove the E-ring [D] and slide the shaft [E] to the left.
17. Remove the jogger motor bracket [F] (1 screw).
18. Remove the pressure arm solenoid [G] (1 screw).
19. Replace the jogger motor [H] (2 screws).

    NOTE: When installing the drive pulley [I] to the jogger motor shaft, align the shaft head [J] with the pulley head [H].

20. Re-assemble the duplex unit.



- Jogger Drive Wire Installation -

1) Set the bead [A] which is closer to the red colored hook [B] in the hole [C] and install the stopper [D] (1 screw).
2) Round the drive wire twice around the drive motor pulley [E] as shown.
3) Move the rear jogger fence bracket [F] to the rear end position (until the bracket [F] touches the screw [G]) and keep this condition.
4) Under the above condition, place the front jogger fence bracket [H] to the front end position (until the bracket [H] touches the front screw).
5) Install the stopper [I] to fix the front jogger fence bracket with the wire.



NOTE: 1) When installing the jogger fences, confirm if the two positioning pins [A] are correctly set in the two holes on the side fences after the screw is set.

2) When installing the positioning roller assembly, insert the plate [B] in the hole [C] on the rear frame, then set the plate on the lever [D].

3) When installing the rear paper press mylar, set the hook [E] to the rear jogger fence [F] as shown so that the mylar moves together with the jogger fence [F].

4) After installing the jogger fences, manually move the jogger fences [F] to confirm that they move smoothly.

5) After re-assembling the duplex unit, manually pull the plungers of the positioning roller solenoid and the pressure arm solenoid to confirm that the positioning roller assembly and the pressure arm move up and down correctly.

6) After re-assembling the duplex unit, adjust the jogger fence width so that the distance between both side fences become 1mm wider than the paper size, when paper is set on the duplex tray.
(1 SP adjustment mode – PAGE 10.)

8.6 COPY QUALITY ADJUSTMENT

8.6.1 SP Adjustment Mode

The copy quality adjustments in the table below can be performed by using the appropriate [1] SP Adjustment mode.

Item	SP Adjustment – PAGE	Standard	Change Amount/1 step	Default
Leading edge registration	3	0 ± 2 mm	0.5 mm	00
Leading edge erase margin	3	3.5 ± 2.5 mm	0.5 mm	00
Vertical magnification	3	100 ± 1%	0.1%	00
Horizontal magnification	3	100 ± 1%	0.1%	00
Side to side registration	4	0 ± 2 mm	0.1%	00
Focus in full size	5	—	0.1%	00
Focus in enlarge/ reduce (Lens error correction)	5	—	0.1%	00

NOTE: When performing multiple adjustments, perform the items in order from top to bottom.
Perform each adjustment as explained in the next pages.



1. Enter SP mode (refer to Service Program Access Procedure) and access 1 SP Adjustment mode.
2. Access the appropriate page by touching the "Prev." [A] or "Next" [B] key.
3. Touch the "Copy in SP" key [C] then select the proper copy mode.
4. Make a copy of the OS-A3 chart.
5. Confirm if copy quality is within the adjustment standard.
6. If the copy quality is not correct, touch the "SP Mode" key [D] at the left upper corner of the LCD panel.
7. Touch the – key [E] or the + key [F] to change the data, then repeat steps 3 to 6 until the copy quality becomes within the adjustment standard.
8. Exit the SP mode.

8.6.2 Side-to-side Registration Adjustment



– Rough Adjustment –

1. Loosen the screws [A] for the tandem tray or built-in LCT, [B] for 550 sheets fixed tray or universal tray, or [C] for by-pass feed tray.
2. Move the tray position by moving parts [D], [E] and [F] of the trays.

– Fine Adjustment –

1. Enter SP mode (refer to the service program access procedure) and access the side to side registration adjustment mode (1 SP Adjustment – PAGE 4).
2. Adjust side-to-side registration for each feed station by changing the SP mode data.

   NOTE: Copies can be made in SP mode. Touch "Copy in SP" key to select the paper feed station.
   Adjustment standard: Less than ± 2 mm difference between original and copy.

8.6.3 Uneven Exposure Adjustment

When: If the exposure is uneven.

Purpose: To maintain even exposure.

Adjustment standard: The side-to-side variation of the gray scales on the test chart should be less than one level.

How: Change the position of the exposure lamp or exposure adjustment wings to make light intensity from the exposure lamp even across its length.



Wing positioning:

Image turns darker.

Image turns lighter.

1. Remove the exposure glass. (See Exposure Glass Removal.)
2. Position the adjustment wings [A] so that the side-to-side copy image density variation is within the adjustment standard.
3. Turn on the main switch and enter SP mode, then perform the process control data initial setting (1 SP Adjustment – PAGE 1).

NOTE: If uneven density is not solved by this adjustment, proceed to the steps 4 and 5 in the next page.



4. Turn the screw [A] to correct the position of the filament. The **left edge** of the exposure lamp [B] should be directly beneath the center of the sight hole [C] in the reflector cover.

CAUTION: Do not touch the screw [D].

5. Turn on the main switch and enter SP mode, then perform the process control data initial setting (1 SP Adjustment – PAGE 1).

8.6.4 Image Density Adjustment

When: The copy image density is already adjusted to the standard level at the factory, and process control maintains copy image density until the next PM. If the customer asks you to adjust the image density, it can be done by using the User Tool mode.

Purpose: To adjust the copy image density.

How: The User Tool "image density level" mode changes the development bias voltage.

1. Enter User Tool mode and access [5] Set operation modes.
2. Press the [Next] key once.
3. Select the appropriate image density level (5 steps).

   adjustment:

   1) Press the appropriate ID level key [A].
   2) Press the enter key [B].



4. Press the "Menu" key [C].
5. Press the "Exit" key [D] to exit User Tool mode.



6. Check copy quality.

8.6.5 Scanner Height Adjustment

When:	If optically skewed images appear after adjusting the 1st and 2nd scanner positions.
Purpose:	To maintain a proper copy image.
How:	Turn the 3rd scanner height adjusting cam. This changes the 3rd scanner's height.



1. Remove the upper right cover [A]. (Refer to the upper right cover removal.)
2. Remove the lens unit cover [B].
3. Move the third scanner to the far right position.



4. Peel off the cover seal [A].
5. Loosen the Allen screw on the adjusting cam [B].
6. Adjust the third scanner height by turning the adjusting cam. (This is a fine adjustment.)



7. If a fine adjustment is insufficient, make a rough adjustment then make the fine adjustment again.

- Rough adjustment -

1) Remove the air inlet duct [A](1 screw).
2) Peel off the cover seal [B].
3) Loosen the screws [C].
4) Rotate the rough adjustment cam [D], as shown, to adjust the third scanner height.

   Black arrow ---- Raise the rear side

   White arrow ---- Lower the rear side

NOTE: Normally the cut out of the adjustment cam is at nine o'clock.

5) Tighten the screw [C] after the adjustment.

SECTION 6

TROUBLESHOOTING

1. SERVICE CALL CONDITIONS

1.1 SUMMARY

There are 4 levels of service call conditions.

Level	Definition	Display
A	The SC can only be reset by service representative (see note in the next page) to prevent the machine from being damaged. The copier cannot be operated at all.	SC display will not be canceled.  Service Call Functional problem within the copier. Report the service code when placing your service call. Exposure SC100 Call Tel 1234567890123456789
B	The copier can be operated as usual except for the unit related to the service call.	If the related function is selected, this display appears.  Ready Preset Quantity 1 Functional problem within the copier. Report the service code when placing your service call. Exposure SC100 Call Tel 1234567890123456789 Clear Cover/Slip Sheet Edit Image Duplex/Series Copies Reduce/Enlarge
C	Only the SC counter is incremented. The copier can be operated as usual.	SC will not be displayed.
D	The SC can be reset by turning main switch off and on if the SC is caused by misdetection.	 Service Call Functional problem within the copier. Report the service code when placing your service call. Exposure SC100 Call Tel 1234567890123456789

NOTE: 1) If the problem is related to electrical circuit boards, first disconnect then reconnect the connectors before replacing the PCBs.

2) If the problem is related to motor lock, first check the mechanical load before replacing motors or sensors.

3) To reset the SC of "Level: A", enter SP mode then turn off and on the main switch.

4) When an SC condition occurs while in SP mode, the display does not indicate the SC number. You can recognize the SC condition because in this condition, you cannot exit the SP mode by touching the [Quit] key.
If this occurs, confirm the SC number as follows:

1. Perform the same procedure to duplicate the SC condition.
2. Enter "Copy in SP" mode. You can see the SC number on the display. You can also confirm the SC number by checking the increment of the SP mode SC counter ([6] Jam/SC Counter – PAGE 1).

1.2 EXPOSURE

SC101 - Exposure lamp malfunction - abnormal On/Off

Definition: [level: A]
During the lamp off condition, the optics control board detects a lamp voltage.

Possible causes

- Exposure lamp open
- Triac shorted
- Exposure lamp thermoswitch open
- Optics control board defective

SC103 - Power source frequency detection error

Definition: [level: D]
Detects frequencies out of the 45Hz to 65Hz range.

Possible causes:

- Abnormal power source
- Electrical noise
- AC drive board defective
- Optics control board defective

SC104 - Exposure lamp malfunction - abnormal off

Definition: [level: D]
The scanner start signal is received even if the main relay off condition is detected.

Possible causes:

- Main relay defective
- Communication error between the main control board and the optics control board because of a poor harness connection.
- Optics control board defective

1.3 SCANNER

SC120 - Scanner home position sensor abnormal - stays off

Definition: [level: D]
The scanner home position sensor does not detect the on condition even if the scanner returns home.

Possible causes:

- Scanner home position sensor defective
- Optics control board defective

SC121 - Scanner home position sensor abnormal - stays on

Definition: [**level: D]**
The scanner home position sensor does not detect the off condition even if the scanner leaves the scanner home position sensor by 120 mm.

Possible causes:
- Scanner home position sensor defective
- Scanner motor defective
- Scanner HP sensor short

SC125 - Low scanner speed

Definition: [level: D]
The scanner speed, detected by the optics control board through the encoder, is lower than the specified speed.

Possible causes:
- Scanner drive motor defective
- Optics Control Board defective

SC126 - High scanner speed

Definition: [level: D]
The scanner speed, detected by the optics control board through the encoder, is higher than the specified speed.

Possible causes:
- Scanner drive motor defective
- Optics control board defective

SC127 - Scanner drive motor encoder failure

Definition: [level: D]
Scanner rotating direction detected by the optics control board through the encoder is opposite to the specified direction.

Possible causes:
- Scanner drive motor defective
- Optics control board defective

1.4 LENS MAGNIFICATION

SC140 - Lens vertical home position sensor abnormal - stays off

Definition: [level: D]
When the lens returns to the home position, the lens vertical home position sensor does not detect the on condition for 2 seconds or more, and more than twice.

Possible causes:
- Lens vertical home position sensor shorted
- Lens vertical drive motor defective
- Optics control board defective

SC141 - Lens vertical home position sensor abnormal - stays on

Definition: [level: D]
When the lens returns to the home position, the lens vertical home position sensor does not detect the off condition for 3.5 seconds or more, and more than twice.

Possible causes:
- Lens vertical home position sensor open
- Lens vertical drive motor defective
- Optics control board defective

SC142 - Lens horizontal home position sensor abnormal - stays off

Definition: [level: D]
When the lens returns to the home position, the lens horizontal home potion sensor does not detect the on condition for 1.7 seconds or more, and more than twice.

Possible causes:
- Lens horizontal home position sensor short
- Lens horizontal drive motor defective
- Optics control board defective

SC143 - Lens horizontal home position sensor abnormal - stays on

Definition: [level : D]
When the lens leaves from the home position, the lens horizontal home potion sensor does not detect the off condition for 2.3 seconds or more, and more than twice.

Possible causes:
- Lens horizontal home position sensor open
- Lens horizontal drive motor defective
- Optics control board defective

SC144 - 3rd scanner home position sensor abnormal - stays off

Definition: [level: D]
When the 3rd scanner returns to the home position, the 3rd scanner home position sensor does not detect the on condition for 1.2 seconds or more, and more than twice.

Possible causes:
- 3rd scanner home position sensor shorted
- 3rd scanner drive motor defective
- Optics control board defective

SC145 - 3rd scanner home position sensor abnormal - stays off

Definition: [level: D]
When the 3rd scanner leaves from the home position the 3rd scanner home position sensor does not detect the off condition for 2.0 seconds or more, and more than twice.

Possible causes:
- 3rd scanner home position sensor open
- 3rd scanner drive motor defective
- Optics control board defective

SC146 - Abnormal magnification operation

Definition: [level: D]
The lens vertical drive motor or the lens horizontal drive motor move for no apparent reason in the ready condition.

Possible causes:
- Lens vertical drive motor defective
- Lens horizontal drive motor defective
- 3rd scanner drive motor defective
- Optics control board defective

1.5 OPTICS THERMISTOR

SC190 - Optics thermistor open

Definition: [level: D]
The optics thermistor is open.

Possible causes:
- Optics thermistor open

NOTE: When the optics thermistor is shorted, no SC code is indicated. The exhaust fan rotates quickly and continuously.

SC191 - Scanner motor thermistor open

Definition: [level: D]
The scanner motor thermistor is open.

Possible causes:
- Scanner drive motor defective

1.6 MAIN CHARGE

SC302 - Charge corona leakage

Definition: [level: D]
The charge power pack detects a charge corona leakage (output: 0V) for 4.8 msec, or detects the output to be more than 7 kV, 10 times in one job.

Possible causes:
- Main charge corona unit defective
- Main charge power pack defective
- High voltage control board defective

SC303 - Charge corona wire cleaner failure

Definition: [level: C]
The current of the charge corona wire cleaner drive motor is over the specified current within 4 seconds after the cleaner motor starts.
The charge corona wire cleaner does not move back to the end block within 30 seconds.

Possible causes:
- Charge corona wire cleaner drive motor defective
- Insufficient lubrication for the charge corona wire cleaner drive mechanism (G501 grease)
- High voltage control board defective

1.7 DEVELOPMENT

SC341 - Development motor locked

Definition: [level: D]
Development motor lock signal stays low more than 1 second in development motor on condition.

Possible causes:
- Extra load in the development unit
- Development motor defective
- Main control board defective

SC342 - Toner collection motor locked

Definition: [level: D]
The toner collection sensor output does not change (OFF → ON or ON → OFF) for more than 2.55 seconds in the toner collection motor on condition.

Possible causes:
- Toner collection sensor defective
- Toner collection motor defective
- Toner clog in the toner collection pipe

SC343 - Toner collection bottle at improper position

Definition: [level: D]
Toner bottle set switch is off and the front door is closed.

Possible causes:
- Toner collection bottle set switch defective
- Toner collection bottle is set incorrectly

1.8 PROCESS SENSOR

SC351 - Abnormal Vsg Detection (Vsg > 4.2V)

Definition: [level: C]
The detected Vsg value is over 4.2 V.

Possible causes:
- ID sensor defective
- Main control board defective

SC352 - Incomplete TD sensor initial setting

Definition: [level: C]
The output voltage of the TD sensor is higher than 2.6 V or lower than 2.4 V during the developer initial setting mode.
VOUT to get 2.5 V for the TD sensor output is higher than 10 V or lower than 2 V.

Possible causes:
- Connector [A] not set correctly
- Toner density sensor defective
- Abnormal toner concentration



SC353 - Abnormal Vsp Detection (Vsp ≥ 2.5 V: lighter pattern)

Definition: [level: C]
Vsp is 2.5 V or higher.

Possible causes:
- ID sensor defective
- OPC drum
- High voltage control board defective
- Poor contact of the development bias terminal

SC354 - Abnormal Vsg detection (Vsg ≤2.5 V)

Definition: [level: C]
Vsg is 2.5 V or less.

Possible causes:
- ID sensor defective
- OPC drum
- Dirty charge corona casing
- Quenching lamp defective
- Erase lamp defective
- Cleaning blade defective
- Dirty ID sensor

SC355 - Abnormal VTD detection (VTD ≥ 4 V)

Definition: [level: C]
VTD is 4 V or higher.

Possible causes:
- Toner density sensor defective
- Toner concentration too low

SC356 - Abnormal VTD detection (VTD < 0.5 V)

Definition: [level: C]
VTD is less than 0.5 V.

Possible causes:
- Toner density sensor defective
- Toner concentration is too high

SC357 - Abnormal Vsp detection (Vsp/Vsg ≥ 25%)

Definition: [level: C]
Vsp/Vsg is 25% or higher.

Possible causes:
- ID sensor defective
- OPC drum
- Dirty ID sensor

SC358 - Abnormal Vsp detection (Vsp/Vsg < 2.5%)

Definition: [level: C]
Vsp/Vsg is less than 2.5%.

Possible causes:
- ID sensor defective
- OPC drum
- Toner scattering

SC361 - Incomplete drum potential sensor calibration

Definition: [level: C]
When the process control initial setting is performed and a development bias of -100 V or -800 V is applied to the drum shaft, the drum potential voltage is out of these ranges:
$0.1 \leq V\text{-}100 \leq 0.7$ [V] or $2.7 \leq V\text{-}800 \leq 4.2$ [V].

Possible causes:
- Drum potential sensor defective
- High voltage control board defective
- Drum shaft terminal not grounded
- OPC drum
- Main charge corona unit defective

SC364 - Abnormal V_D detection

Definition: [level: C]
V_D is out of specification ($V_R + 770 \pm 20$ V).

Possible causes:
- Drum potential sensor defective
- OPC drum
- Main charge corona unit defective

SC365 - Abnormal V_L detection

Definition: [level: C]
V_L is out of specification ($V_R + 140 \pm 20$ V).

Possible causes:
- Drum potential sensor defective
- OPC drum
- Main charge corona unit defective
- Optics too dirty

1.9 TRANSFER CURRENT

SC402 - Transfer current leakage

Definition: [level: D]
When the transfer power pack output voltage exceeds 4.5 KV for 200 msec or more, the output current is multiplied by 0.8. If this condition occurs 11 time in a row, an SC is displayed.

Possible causes:
- Transfer belt defective
- Transfer power pack defective
- Poor contact at transfer bias roller, discharge plate terminals
- High voltage control board defective

1.10 DRUM

SC440 - Abnormal main motor speed

Definition: [level: D]
Lock signal stays low in the main motor on condition for 1.0 second or more.

Possible causes:
- Main motor defective

SC442 - Drum thermistor open

Definition: [level: D]
The drum thermistor is open.

Possible causes:
- Drum thermistor defective

1.11 PAPER FEED

SC500 - Abnormal manual feed drive motor speed

Definition: [level : D]
Lock signal stays low in the manual feed motor on condition for 1.0 second or more.

Possible causes:
- Manual feed motor defective

SC501 - Abnormal paper feed drive motor speed

Definition: [level: D]
Lock signal stays low in the paper feed motor on condition for 1.0 second or more.

Possible causes:
- Paper feed motor defective
- Paper feed control board defective

SC502 - Abnormal 1st lift motor movement

Definition: [level: B]
The 1st lift sensor detects high condition for 10 seconds or more after the 1st lift motor starts. The first time, after the paper tray is opened and closed, the 1st lift motor starts again. If the above condition occurs twice, this SC is displayed.

Possible causes:
- 1st lift sensor shorted
- 1st lift motor defective
- Paper feed control board defective

SC503 - Abnormal 2nd lift motor movement

Definition: [level: B]
The 2nd lift sensor detects the high condition for 10 seconds or more after the 2nd lift motor starts. The first time, after the paper tray is opened and closed, the 2nd lift motor starts again. If the above condition occurs twice, this SC is displayed.

Possible causes:
- 2nd lift sensor shorted
- 2nd lift motor defective
- Paper feed control board defective

SC504 - Abnormal 3rd lift motor (1.5 K LCT motor for A096 copier) movement

Definition: [level: B]
The 3rd lift sensor detects the high condition for 10 seconds or more after the 3rd lift motor starts. The first time, after the paper tray is opened and closed, the 3rd lift motor starts again. If the above condition occurs twice, this SC is displayed.

Possible causes:
- 3rd lift sensor shorted
- 3rd lift motor (1.5 K LCT motor for A096 copier) defective
- Paper feed control board defective

SC506 - Abnormal 3.5 K LCT motor movement

Definition: [level: B]
The LCT lift sensor detects the low condition for 10 seconds or more after the LCT motor starts. The first time, after the LCT cover is opened and closed, the LCT motor starts again. If the above condition occurs twice, this SC is displayed.

Possible causes:
- LCT motor defective
- LCT lift sensor shorted

SC507 - Abnormal 3.5 K LCT feed motor movement

Definition: [level: B]
The LCT feed motor is locked for 1 second or more after this motor starts.

Possible causes:
- LCT feed motor defective

SC508 - Abnormal tandem rear fence drive motor movement

Definition: [level: B]
It takes 10 seconds or more for the rear fence return sensor to detect the on condition after the rear fence drive motor starts.
It takes 10 seconds or more for the rear fence home position sensor to detect the on condition after this fence starts moving to the home position.
When the tray is set, the rear fence return sensor and the rear fence the home position sensor are on.

Possible causes:
- Rear fence drive motor defective
- Rear fence HP sensor defective
- Rear fence return sensor defective

SC510 - Abnormal tandem side fence home position detection - stays off

Definition: [level: B]
When the side fence goes back to the home position or the side fence drive motor works to open the fence, the side fence positioning sensor does not detect the on condition for 5 seconds or more.

Possible causes:
- Side fence drive motor defective
- Side fence positioning sensor open

SC511 - Abnormal tandem side fence home position detection - stays on

Definition: [level: B]
When the side fence goes back to the home position or the side fence drive motor works to close the fence, the side fence positioning sensor stays on for 5 seconds.

Possible causes:
- Side fence drive motor defective
- Side fence positioning sensor shorted

1.12 DUPLEX

SC520 - Abnormal fusing/duplex drive motor movement

Definition: [level: D]
The lock signal stays low for 1.0 second after the fusing/duplex drive motor starts.

Possible causes:
- Fusing/duplex drive motor defective

SC522 - Abnormal jogger home position sensor detection - stays off

Definition: [level: B]
The jogger home position sensor does not detect the on condition for 5 seconds or more after the fusing/duplex drive motor starts.

Possible causes:
- Jogger motor defective
- Jogger HP sensor open

SC523 - Abnormal jogger home position sensor detection - stays on

Definition: [level: B]
The jogger home position sensor does not detect the off condition for 1 second after its sensor detects the on condition in the initializing mode.

Possible causes:
- Jogger drive motor defective
- Jogger HP sensor shorted

1.13 FUSING

SC541 - Fusing thermistor open

Definition: [level: A]
Detects the fusing thermistor open condition for 2 msec or more after turning the main switch on.

Possible causes:
- Fusing thermistor open
- Optics control board defective

SC542 - Start key stays red

Definition: [level: A]
The fusing temperature does not reach the specified temperature after 5 minutes from turning the main switch on.

Possible causes:
- Fusing lamp defective
- AC Drive board defective
- Fusing thermistor defective

SC543 - Fusing overheat (detected by the main control board)
SC544 - Fusing overheat (detected by the optics control board)

Definition: [level: A]
The fusing temperature stays over 231 °C for 5 seconds.

Possible causes:
- AC drive board defective
- Fusing thermistor defective
- Optics control board defective
- Main control board defective

SC545 - Low fusing temperature (detected by the main control board)
SC546 - Low fusing temperature (detected by the optics control board)

Definition: [level: A]
The fusing temperature stays lower than 100 °C for 5 seconds after the machine becomes ready.

Possible causes:
- Fusing thermistor defective
- AC drive board defective
- Fusing lamp open
- Main control board defective
- Optics control board defective

SC547 - Fusing lamp continuously lit

Definition: [level: A]
Fusing lamp continuously lights for 70 seconds after the machine becomes ready. However, if the door is open, paper jams, or the fusing unit is out of position, the ready condition is canceled and the main relay opens.

Possible causes:
- AC drive board

SC548 - Unstable fusing temperature

Definition: [level: A]
If the fusing temperature changes by 21 °C/second four times in 1 minute, this SC is displayed.

Possible causes:
- AC drive board defective
- Thermistor defective

1.14 SYSTEM CONTROL

SC600 - Communication error (main control board and operation panel)

Definition: [level: D]
The main control board does not communicate with the operation panel.

Possible causes:
- Main control board defective
- Operation panel defective
- Harness defective

SC601 - Communication error (main control board and optics control board)

Definition: [level: D]
The main control board does not communicate with the optics control board.

Possible causes:
- Main control board defective
- Optics control board defective
- Harness defective

SC602 - Communication error (main control board and high voltage control board)

Definition: [level: D]
The main control board does not communicate with the high voltage control board.

Possible causes:
- Main control board defective
- High voltage control board defective
- Harness defective

SC603 - Main control board malfunction (CPU)

Definition: [level: D]
Communication to the main control board is not completed.

Possible causes:
- Main control board defective

SC620 - Communication error (main control board and DJF/RDH main board)

Definition: [level: B]
The main board does not communicate with the DJF/RDH main board.

Possible causes:
- Main control board defective
- DJF/RDH main board defective
- Harness defective
- Fiber optics defective

SC621 - Communication error (main control board and sorter staplers (A374/A377)/finisher main board)

Definition: [level: D]
The main control board does not communicate with the sorter stapler (A374/A377)/finisher main board.

Possible causes:
- Main control board defective
- Sorter stapler(A374/A377)/finisher main board defective
- Harness defective
- Fiber optics defective

1.15 DUAL JOB FEEDER

SC700 - Abnormal DJF/RDH feed-in motor movement
SC701 - Abnormal DJF/RDH transport belt motor movement
SC702 - Abnormal DJF/RDH feed out motor movement
SC703 - Abnormal RDH inverter motor movement

Definition: [level: B]
Encoder pulse is not detected by the DJF main board in the main motor on condition. The first time, a jam occurs. The second time, an SC is displayed.

Possible causes:
- DJF feed motor defective
- DJF transport motor defective
- DJF feed out motor defective
- DJF inverter motor defective

1.16 FINISHER / SORTER STAPLER

SC730 - Abnormal *transport motor (A374, A377 sorter staplers / A379 finisher) movement

Definition: [level: D]
When the encoder pulse is not detected by the SS (or finisher) main board for 200 msec after the *transport motor starts, a jam is displayed. If this occurs twice, an SC is displayed.

Possible causes:
- *Transport motor

	A374 Sorter Stapler	A377 Sorter Stapler	A379 Finisher
*	Roller drive motor	Main motor	Transport drive motor

SC731 - Abnormal bin drive (lift) motor movement (A374, A377 sorter staplers)

Definition: [level: B]
If the wheel sensor (bin lift timing sensors) is not off after 2 seconds from when the bin drive (lift) motor stars, jam "R2" is indicated.
If the wheel sensor (bin lift timing sensors) is not on after 2 seconds from when the wheel sensor (bin lift timing sensors) detects off, jam "R2" is indicated.
If the condition above occurs twice, an SC is displayed.

Possible causes:
- Wheel sensor (bin lift timing sensors) defective
- Bin drive (Lift) motor defective

SC732 - Tray shift motor (A379 Finisher)

Definition: [level: B]
The shift tray half turn sensor does not detect the on condition for 2 seconds after the finisher tray shift motor starts.
The first time, a jam is indicated. The 2nd time, an SC is displayed.

Possible causes:
- Tray shift motor defective
- Shift tray half turn sensor defective

SC733 - Shift tray lift motor (A379 finisher)

Definition: [level: B]
The stack height sensor 1 or 2 do not detect the on condition for the specified time after the finisher shift tray lift motor.

Possible causes:
- Shift tray lift motor defective
- Stack height sensor 1 or 2 defective

SC735 - Abnormal jogger motor movement (A374, A377 sorter staplers / A379 Finisher)

Definition: [level: B]

When the jogger moves back to the home position, the jogger home position sensor does not detect the on condition within 650 pulses. Then, a jam is indicated.
When the jogger moves from the home position forward, and moves back to the home position, the jogger home position sensor does not detect the on condition within 100 pulses. Then, a jam is indicated.
If the above condition occurs twice, an SC is displayed.

Possible causes:

- Jogger motor defective
- Jogger home position sensor defective

SC737 - Abnormal gripper motor movement (A374, A377 sorter staplers)

Definition: [level: B]

When the gripper moves to the staple position, the gripper home position sensor does not detect the on condition. Then a jam is indicated.
When the gripper moves from the staple position to the bin position, the gripper home position sensor does not detect the on condition within 1070 pulses. Then a jam is indicated.
When the gripper moves to the home position, the gripper home position sensor does not detect the on condition within 1.25 seconds. Then a jam is indicated.
When the gripper moves from the home position forward, and moves back to the home position, the gripper home position does not detect the on condition within 500 msec or more. Then a jam is indicated.
If the above condition occurs twice, an SC is displayed.

Possible causes:

- Gripper motor defective
- Gripper home position sensor defective

SC738 - Abnormal staple motor movement (A374, A377 sorter staplers)

Definition: [level: B]
The staple home position sensor does not detect the on condition within 600 msec after the motor starts. Then a jam is indicated. If this occurs twice, this SC is displayed.

Possible causes:
- Staple unit (staple motor) defective
- Staple is jammed in the staple unit.

SC740 - Abnormal staple unit drive motor movement (A377 sorter stapler / A379 finisher)

Definition: [level: B]
The staple unit home position sensor does not detect the on condition when the staple unit is in the home position. A jam is indicated.
The staple unit home position sensor does not detect the on condition (within 1640 pulses) when the staple unit moves to the home position. A jam is indicated.
The staple unit home position sensor does not detect the on condition (within 280 pulses) when the staple unit moves forward from the home position and moves back to the home position. A jam is indicated.
If the above condition occurs twice, this SC is displayed.

Possible causes:
- Staple unit drive motor defective
- Staple unit home position sensor defective

SC741 - Abnormal bin rear plate motor movement (A377 sorter stapler)

Definition: [level: B]
When the rear bin plate is open, the bin rear plate open sensor does not detect the on condition for 750 msec or more after the motor starts. Then a jam is indicated.
When the rear bin plate is closed, the bin rear plate home position sensor does not detect the on condition for 750 msec or more after the motor starts. Then a jam is indicated.
In the initial condition, the bin rear plate open sensor does not detect the on condition for 1.25 seconds or more after the motor starts. Then a jam is indicated.
If the above condition occurs twice, this SC is displayed.

Possible causes:
- Bin rear plate drive motor defective
- Bin rear plate open sensor defective
- Bin rear plate home position sensor defective

SC742 - Abnormal stack feed out motor movement (A379 finisher)

Definition: [level: B]
No encoder pulses is detected for 500 msec. or more.

Possible causes:
- Stack feed out motor defective

1.17 OTHERS

SC900 - Total counter failure (staying in the off condition)

Definition: [level: D]
The total counter stays in the off condition.

Possible causes:
- Total counter defective

SC901 - Total counter failure (staying in the on condition)

Definition: [level: D]
The total counter stays in the on condition.

Possible causes:
- Total counter defective

SC full used toner bottle

Definition: [level: A]
The toner overflow switch is activated.

Possible causes:
- Toner collection bottle is full
- Toner overflow switch defective

NOTE: Clear the SC full used toner bottle as follows:

1. While the main switch is on, open the front doors then take out the toner collection bottle (used toner bottle).
2. Remove the toner collection bottle then empty and clean the bottle.
3. Install the empty toner collection bottle.
4. Close the front doors.

2. ELECTRICAL COMPONENT DEFECTS

2.1 SENSORS

NOTE: All photo-interrupters go low (GND) when the actuator interrupts the gap between the LED and the photo transistor.

Component (Symbol)	CN	Condition	Symptom (when the main switch turns on)
Scanner HP (S-1)	512-1	Open	SC125 is displayed
		Shorted	SC121 is displayed
Platen Cover Position-1 (S-2)	512-7	Open	APS and AMS do not function correctly.
		Shorted	–
Platen Cover Position-2 (S-3)	518-1	Open	"Original is on the glass" indicator is displayed even if the original on the glass has already been removed.
		Shorted	–
Lens vertical HP (S-4)	512-5	Open	SC141 is displayed
		Shorted	SC140 is displayed
Lens Horizontal HP (S-5)	513-1	Open	SC143 is displayed
		Shorted	SC142 is displayed
3rd Scanner HP (S-6)	511-1	Open	SC145 is displayed
		Shorted	SC144 is displayed
By-Pass Paper End (S-7)	108-A5	Open	"Paper end" indicator is not displayed even if there is no paper on the by-pass feed table.
		Shorted	"Paper end" indicator is displayed even if paper is set on the by-pass feed table.
Guide Plate Position (S-8)	108-B9	Open	"Guide plate open" indicator is not displayed even if the guide plate is open.
		Shorted	"Guide plate open" indicator is displayed even if the guide plate is closed.
Jogger HP (S-9)	112-A10	Open	Jogger motor locks (SC522 counts up)
		Shorted	Jogger motor locks (SC523 counts up)
Vertical Transport (S-10)	108-A2	Open	–
		Shorted	–
Duplex Exit (S-11)	112-A8	Open	"Paper Jam T" indicator is displayed even if there is no paper.
		Shorted	Whenever a duplex copy is made, "Paper Jam T" occurs.

Component (Symbol)	CN	Condition	Symptom (when the main switch turns on)
Duplex Entrance Sensor (S-12)	112-A7	Open	"Paper Jam T" indicator is displayed even if there is no paper.
		Shorted	Whenever a duplex copy is made, "Paper Jam T" occurs.
Duplex Paper End (S-13)	112-A9	Open	"Copies left in the duplex tray...." indicator is displayed even if there is paper in the duplex tray.
		Shorted	Only one rear side copy is made regardless of the quantity of copies.
Duplex Transport (S-14)	109-A4	Open	"Paper Jam T" indicator is displayed even if there is no paper.
		Shorted	Whenever a duplex copy is made, "Paper Jam T" occurs.
Exit (S-15)	109-A2	Open	"Paper Jam E" indicator is displayed even if there is no paper.
		Shorted	Whenever the copy is fed out, "Paper Jam D" occurs.
Fusing Exit (S-16)	109-B7	Open	"Paper Jam D" indicator is displayed even if there is no paper.
		Shorted	Whenever a copy is made, "Paper Jam C and D" occurs.
Paper Guide (S-17)	109-B4	Open	–
		Shorted	Whenever a duplex copy is made, "Paper Jam T" occurs.
Auto Image Density (S-18)	507-1	Open	Image density will be abnormal.
		Shorted	
Original Length-1 (S-19)	508-8, 9, 10	Open	The CPU cannot properly detect original size. APS and AMS do not function correctly.
		Shorted	
Original Length-2 (S-20)	509-3, 4, 5	Open	The CPU cannot properly detect original size. APS and AMS do not function correctly.
		Shorted	
Original Width (S-21)	508-3, 4, 5	Open	The CPU cannot properly detect original size. APS and AMS do not function correctly.
		Shorted	
By-Pass Paper Size (S-22)	114-6	Open	The CPU recognizes that the paper width is 319 mm regardless of the side fence position.
		Shorted	The CPU recognizes that the paper width is 100 mm regardless of the side fence position.
Toner Density (S-23)	114-3	Open	Machine quits auto toner supply mode and enters fixed supply mode.
		Shorted	

Component (Symbol)	CN	Condition	Symptom (when the main switch turns on)
Registration (S-24)	108-A7	Open	"Paper Jam C" indicator is displayed even if there is no paper.
		Shorted	Whenever a copy is made, "Paper Jam C" occurs.
Toner End (S-25)	108-B14	Open	Toner is added even if there is too much toner in the toner hopper.
		Shorted	Toner is not supplied even if there is no toner in the toner hopper.
Auto-Response (S-26)	113-B3	Open	The machine does not exit "Screen Saver" mode even if an operator approaches the machine.
		Shorted	"Screen Saver" mode does not work.
Drum Potential (S-27)	110-10	Open	Machine quits auto process control and enters fixed toner supply mode.
		Shorted	
Image Density (S-28)	111-3	Open	Machine quits auto toner supply mode and enters detect mode.
		Shorted	
1st Paper End (S-29)	401-A5	Open	"Paper end" indicator is not displayed even if there is no paper on the paper tray.
		Shorted	"Paper end" indicator is displayed even if paper is set.
1st Paper Near End (S-30)	412-A2	Open	"Paper near end" indicator is not displayed even if the tray is almost empty.
		Shorted	"Paper near end" indicator is displayed even if there is enough paper on the paper tray.
1st Paper Feed (S-31)	402-A1	Open	Whenever paper is fed, it is folded.
		Shorted	"Paper jam A" indicator is displayed even if there is no paper.
2nd Paper Near End (S-32)	412-A5	Open	"Paper near end" indicator is not displayed even if the tray is almost empty.
		Shorted	"Paper near end" indicator is displayed even if there is enough paper on the paper tray.
1st Lift (S-33)	401-A2	Open	"Add paper" indicator is displayed even if there is paper on the tray.
		Shorted	The tray bottom plate locks at the upper position.
2nd Paper End (S-34)	401-B5	Open	"Paper end" indicator is not displayed even if there is no paper on the paper tray.
		Shorted	"Paper end" indicator is displayed even if paper is set.
Toner Collection Motor (S-35)	412-B5	Open	SC342 is displayed.
		Shorted	

Component (Symbol)	CN	Condition	Symptom (when the main switch turns on)
2nd Lift (S-36)	401-B2	Open	"Add paper" indicator is displayed even if there is paper on the tray.
		Shorted	The tray bottom plate locks at the upper position.
3rd Lift (S-37)	403-A2	Open	"Add paper" indicator is displayed even if there is paper on the tray.
		Shorted	The tray bottom plate locks at the upper position.
3rd Paper Near End (A095 copier only) (S-38)	412-A8	Open	"Paper near end" indicator is not displayed even if the tray is almost empty.
		Shorted	"Paper near end" indicator is displayed even if there is enough paper on the paper tray.
3rd Paper End (S-39)	403-A5	Open	"Paper end" indicator is not displayed even if there is no paper on the paper tray.
		Shorted	"Paper end" indicator is displayed even if paper is set.
3rd Paper Feed (S-40)	402-A8	Open	Whenever paper is fed, it is folded.
		Shorted	"Paper jam A" indicator is displayed even if there is no paper.
2nd Paper Feed (S-41)	402-B1	Open	Whenever paper is fed, it is folded.
		Shorted	"Paper jam A" indicator is displayed even if there is no paper.
Base Plate Down (A096 copier only) (S-42)	404-A10	Open	The bottom plate lift lever locks at the lowest position.
		Shorted	The bottom plate is not lowered when paper on the left tray shifts to the right tray and paper is set in the improper position.
Side Fence Positioning (A096 copier only) (S-43)	404-A13	Open	SC510 is displayed
		Shorted	SC511 is displayed
Rear Fence Return (A096 copier only) (S-44)	404-B10	Open	When the rear fence reaches the return position, the rear plate locks there then SC508 is displayed.
		Shorted	SC508 is displayed.
Rear Fence HP (A096 copier only) (S-45)	404-B6	Open	SC508 is displayed.
		Shorted	When the rear fence reaches the return position, SC508 is displayed.

Component (Symbol)	CN	Condition	Symptom (when the main switch turns on)
Left Tandem Paper End (A096 copier only) (S-46)	404-B12	Open	The rear fence moves back and forth continuously.
		Shorted	The paper on the left tray is not moved to the right tray.
LCT Near End (A096 copier only) (S-47)	412-A7	Open	"Paper near end" indicator is not displayed even if the tray is almost empty.
		Shorted	"Paper near end" indicator is displayed even if there is enough paper on the paper tray.
Tray Down (A096 copier only) (S-48)	403-B2	Open	When the bottom plate is lowered, it locks at the lowest position.
		Shorted	"Paper end" indicator is displayed even if there is paper on the tray.
Tray Paper End (A096 copier only) (S-49)	412-A11	Open	The bottom plate raises & lowers even if no paper is set.
		Shorted	The bottom plate does not raise even if paper is set on the tray.

2.2 SWITCHES

Component	CN No.	Condition	Symptom
By-Pass Table (SW-1)	108-B11	Open	"Open the by-pass tray" indicator is displayed even if the by-pass tray is opened. Print key stays red.
		Shorted	By-pass feed motor continuously turns.
Front Door Safety (SW-2)	–	Open	"Close the door" indicator lights even if the front door is closed.
		Shorted	Copier does not turn off when the front doors are open.
1st Tray Set (A095 copier only) (SW-3)	407-B8	Open	When the 1st tray is selected, SC502 is displayed.
		Shorted	The 1st tray cannot be selected even if the 1st tray is set in the machine.
2nd Paper Size (SW-4)	407-A2 ~ A6	Open	The CPU cannot detect proper paper size, and misfeeds may occur when a copy is made.
		Shorted	
Toner Overflow (SW-5)	412-B9	Open	SC "Full Used Toner Bottle" indicator lights even if the toner bottle is not full.
		Shorted	SC "Full Used Toner Bottle" indicator does not light even if the toner bottle becomes full.
Toner Collection Bottle Set (SW-6)	412-B7	Open	No caution is displayed on the LCD even if the toner collection bottle is set incorrectly.
		Shorted	SC343 is displayed.
Lower Front Door Safety (SW-7)	410-1	Open	Whenever paper is fed from the tray unit, SC501 is displayed.
		Shorted	—
3rd Tray Set (A095 copier only) (SW-8)	407-B1	Open	When the 3rd tray is selected, SC504 is displayed.
		Shorted	The 3rd tray cannot be selected even if the 3rd tray is set in the machine.
Main (SW-9)	—	Open	The copier does not turn on.
		Shorted	The copier does not turn off.
Tray Down (A096 copier only) (SW-10)	402-B14	Open	The 3rd tray bottom plate stays at the lowest position.
		Shorted	The 3rd tray bottom plate stays at the highest position.

2.3 FUSES

2.3.1 DC Power Supply Board

Component	Condition	Symptom
FU801 (125 V, 10 A)	Open	Power is not provided when the main switch is on (No indicator displayed on the operation panel).
FU802 (125 V, 5 A)	Open	Power is not provided when the main switch is on (No indicator displayed on the operation panel).
FU803 (125 V, 6.3 A)	Open	When the 3rd feed station is selected, SC504 is displayed.
FU804 (125 V, 6.3 A)	Open	When the main switch is turned on, SC900 is displayed.
FU805 (125 V, 6.3 A)	Open	When each feed station is selected, the following indication is displayed: 1st: SC510 2nd: Add Paper 3rd: SC504 When the paper is fed from the By-pass feed table, SC342 is displayed.
FU806 (125 V, 6.3 A)	Open	When the 3rd feed station is selected, SC504 is displayed. DJF (RDH) and Sorter Stapler (Finisher) do not operate.

RICOH

RICOH FT6645/6655/6665 (A095/A096/A097)

PARTS CATALOG

2nd Edition May 1994

RICOH COMPANY, LTD.

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.

INDEX to PARTS CATALOG

FT6645/FT6655/FT6665 (A095/A096/A097)

DF60 (A376)

ST25 (A377)

DH400 (A378)

SR400 (A379)

RT31 (A380)

ST24 (A374)

1) If a part is modified and the interchangeability is not o/o, the old part number is not removed from the parts catalog, but is listed below the new part number.

. If the part name changes, the old name, interchangeability and M/B number are listed in the description section beside the old part number.



. If the name does not change, only the interchangeability and M/B number are shown.



2) **If a new part is** added, **the M/B number is printed in the description section under the name.**

49	**54475510**	**Toner Overflow Sensor**	

MB35 (ADDED)

M/B Number

3) When a part is no longer used, the M/B number is printed in the description section beside the part name.

40	54241937	**Shaft-Platen Cover**	**MB29 (OBS)**

FT6645/6655/6665 (A095/A096/A097)

This parts catalog includes MB No. 1 to MB No. 24 (A095/A096).

PARTS CATALOG

INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine,

INDEX to PARTS CATALOG

Location of Unit 3
l. Exterior (A095/A096/A097) 12
2. Platen Cover (A095/A096/A097) 14
3.Operation Panel Ass'y(A095/A096/A097) 16
4. Optics Section 1 (A095/A096/A097) 18
5.Optics Section 2(A095/A096/A097) 20
6.Optics Section 3(A095/A096/A097) 22
7.Optics Section 4(A095/A096/A097) 24
8.Optics Section 5(A095/A096/A097) 26
9.Optics Section 6(A095/A096/A097) 28
10.Optics Section 7(A095/A096/A097) 30
11. By-pass Feed Table (A095/A096/A097) 32
12. Paper Registration 1 (A095/A096/A097) 34
13. Paper Registration 2 (A095/A096/A097) 36
14. Paper Feed Section (A095/A096/A097) 38
15. Paper Tray Section 1 (A095/A096/A097) 40
16. Paper Tray Section 2(A095/A096/A097) 42
17. Tandem Tray 1 (A095/A096/A097) 44
18. Tandem Tray2(A095/A096/A097) 46
19. LCT Tray 1(A095/A096/A097) 48
20. LCT Tray 2(A095/A096/A097) 50
21. Development Unit (A095/A096/A097) 52
22. Toner Hopper Section (A095/A096/A097) 54
23. Toner Bottle Holder Section (A095/A096/A097) 56
24. Drum Unit 1(A095/A096/A097) 58
25. Drum Unit2(A095/A096/A097) 60
26. Transfer Section (A095/A096/A097) 62
27. Fusing Unit1 (A095/A096/A097) 64
28. Fusing Unit2(A095/A096/A097) 66
29. Inverter Section 1 (A095/A096/A097) 68
30. Inverter Section 2(A095/A096/A097) 70
31. Duplex Unit 1(A095/A096/A097) 72
32. Duplex Unit2(A095/A096/A097) 74
33. Duplex Unit3(A095/A096/A097) 76
34. Drive Section 1 (A095/A096/A097) 78
35. Drive Section 2(A095/A096/A097) 80
36. Drive Section 3(A095/A096/A097) 82
37. Drive Section 4(A095/A096/A097) 84

38. Drive Section 5 (A095/A096/A097) 86
39. Electrical Section 1 (A095/A096/A097) 88
40. Electrical Section 2 (A095/A096/A097) 90
41. Electrical Section 3 (A095/A096/A097) 92
42. Electrical Section 4 (A095/A096/A097) 94
43. Frame Section 1 (A095/A096/A097) 96
44. Frame Section 2 (A095/A096/A097) 98
45. Frame Section 3 (A095/A096/A097) 100
46. Main Control Board (A095/A096/A097) 102
47. Decal and Document (A095/A096/A097) 106
48. Special Tool (A095/A096/A097) 108
Parts Index 111

LOCATION OF UNIT

1. **EXTERIOR (A095/A096/A097)**



See Page 12

2. **PLATEN COVER (A095/A096/A097)**



See Page 14

3. OPERATION PANEL ASS'Y (A095/A096/A097)



See Page 16

4. OPTICS SECTION 1 (A095/A096/A097)



See Page 18

5. **OPTICS SECTION 2 (A095/A096/A097)**



See Page **20**

6. **OPTICS SECTION 3 (A095/A096/A097)**



See Page 22

LOCATION OF UNIT

7. OPTICS SECTION 4 (A095/A096/A097)



See Page 24

8. OPTICS SECTION 5 (A095/A096/A097)



See Page 26

9. OPTICS SECTION 6 (A095/A096/A097)



See Page 28

10. OPTICS SECTION 7 (A095/A096/A097)



See Page 30

11. BY-PASS FEED TABLE (A095/A096/A097)



See Page 32

12. PAPER REGISTRATION 1 (A095/A096/A097)



See Page 34

LOCATION OF UNIT

13. PAPER REGISTRATION 2 (A095/A096/A097)



See Page 36

14. PAPER FEED SECTION (A095/A096/A097)



See Page 38

15. PAPER TRAY SECTION 1 (A095/A096/A097)



See Page 40

16. PAPER TRAY SECTION 2 (A095/A096/A097)



See Page 42

17. TANDEM TRAY 1 (A095/A096/A097)



See Page 44

18. TANDEM TRAY 2 (A095/A096/A097)



See Page 46

LOCATION OF UNIT

19. **LCT TRAY 1 (A095/A096/A097)**



See Page 48

20. **LCT TRAY 2 (A095/A096/A097)**



See Page 50

21. **DEVELOPMENT UNIT (A095/A096/A097)**



See Page 52

22. **TONER HOPPER SECTION (A095/A096/A097)**



See Page 54

23. **TONER BOTTLE HOLDER SECTION (A095/A096/A097)**



See Page **56**

24. **DRUM UNIT 1 (A095/A096/A097)**



See Page **58**

LOCATION OF UNIT

25. DRUM UNIT 2 (A095/A096/A097)



See Page 60

26. **TRANSFER SECTION (A095/A096/A097)**



See Page **62**

27. FUSING UNIT 1 (A095/A096/A097)



See Page 64

28. **FUSING UNIT 2 (A095/A096/A097)**



See Page 66

29. INVERTER SECTION 1 (A095/A096/A097)



See Page 68

30. INVERTER SECTION 2 (A095/A096/A097)



See Page 70

LOCATION OF UNIT

31. DUPLEX UNIT 1 (A095/A096/A097)



See Page 72

32. DUPLEX UNIT 2 (A095/A096/A097)



See Page 74

33. DUPLEX UNIT 3 (A095/A096/A097)



See Page 76

34. DRIVE SECTION 1 (A095/A096/A097)



See Page 78

35. DRIVE SECTION 2 (A095/A096/A097)



See Page 80

36. DRIVE SECTION 3 (A095/A096/A097)



See Page 82

LOCATION OF UNIT

37. **DRIVE SECTION 4 (A095/A096/A097)**



See Page 84

38. **DRIVE SECTION 5 (A095/A096/A097)**



See Page 86

39. ELECTRICAL SECTION 1 (A095/A096/A097)



See Page **88**

40. ELECTRICAL SECTION 2 (A095/A096/A097)



See Page 90

41. ELECTRICAL SECTION 3 (A095/A096/A097)



See Page **92**

42. ELECTRICAL SECTION 4 (A095/A096/A097)



See Page 94

LOCATION OF UNIT

43. FRAME SECTION 1 (A095/A096/A097)



See Page 96

44. FRAME SECTION 2 (A095/A096/A097)



See Page 98

45. FRAME SECTION 3 (A095/A096/A097)



See Page 100

1. EXTERIOR (A095/A096/A097)



1. EXTERIOR (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 1300	Decal - Main Switch	1
2	A096 1294	Upper Left Cover	1
3	A096 1302	Lower Left Cover	1
4	A096 1461	Operation Panel Ass'y - LT	1
4	A096 1462	Operation Panel Ass'y - A4	1
5	A096 5310	Auto Response Sensor	1
6	A096 1286	Top Cover	1
7	A096 1281	Rear Top Cover	1
8	A095 1360	Upper Rear Cover	1
9	A096 1364	Lower Rear Cover	1
10	A096 1282	Position Sensor Cap	1
11	A096 1362	Connector Cover	1
12	A096 1305	Upper Right Cover	1
13	A096 1308	Middle Right Cover	1
14	A096 1315	Lower Right Cover	1
15	A096 1309	Spring Plate	2
16	A096 1371	Inner Cover - Door Switch	1
17	A095 1368	Right Door (A095)	1
17	A096 1368	Right Door (A096)	1
17	A097 1368	Right Door (A097)	1
18	A096 1345	Lower Right Hinge	1
19	A096 1324	Grip Inner Cover	1
20	A096 1323	Grip Cover	1
21	A096 1328	Duplex Guide Lever	1
22	A096 1320	Left Door	1
23	A096 1376	Inner Cover - Main Switch	1
24	A096 1298	Cap - MAT20	3
25	A096 1317	Cap - 34x55	2
26	A024 1367	Small Cap - Left Cover	5
27	AG07 0004	Magnetic Catch	1
28	A096 1325	Left Switch Lever	1
29	A096 1327	Magnet Catch Plate'	1
30	A096 1338	Decal - Misfeed Removal	1
31	A096 1339	Decal - Add Toner	1
32	A096 1337	Hinge Shaft - Lower Left	1

Index No.	Part No.	Description	Q'ty Per Assembly
33	A096 1326	Lower Left Hinge	1
34	AA06 6110	Grip Spring	1
35	A096 1343	Upper Switch Lever	1
36	A096 1349	Magnet Catch Plate	1
37	A096 1348	Lower Switch Lever	1
38	A096 1367	Right Guide Lever	1
39	A007 6156	Lower Rear Cap	1
40	A096 1344	Upper Right Hinge	1
41	A096 5409	ARS Harness	1
42	A095 1363	Cap - 38x77	1
43	AA14 3416	Steped Screw - M4x3	8
44	A096 1299	Cap - M22	4
45	AA10 0006	Flat Nut - 3.6x9.5x0.8	1
46	A096 1313	Cover Bracket	2
47	A096 1297	Mirror Clamp Cover	1
48	A096 1377	Left Door Stoper	1
49	AA15 1862	Bottle Shield	1
50	A509 0010	Key Counter Holder Ass'y MB3 (ADDED) MB24 (OBS)	
51	A096 9520	Editing Sheet - A4 MB3 (ADDED)	1
51	A096 9521	Editing Sheet - LT MB3 (ADDED)	1
101	0972 4006W	Philips Polycarbonate Screw - M4x6	
102	0802 5094	Tapping Truss Head Screw - M4x8	
103	0802 5124	Tapping Screw - M3x8	
104	0344 0080W	Philips Truss Head Screw - M4x8	
105	0414 0082W	Tapping Screw With Flat Washer-M4x8	
106	0434 0082W	Tapping Screw - M4x8	
107	0324 0080W	Philips Sunken Head Screw - M4x8	
108	0414 0082B	Binding Self Tapping Screw - M4x8	
109	0951 4016W	Philips Screw W/Flat Washer-M4x16	
110	0801 1185	Philips Truss Head Screw - M4x8	
111	0434 0080B	Philips Tapping Screw - M4x8	

2. PLATEN COVER (A095/A096/A097)



2. PLATEN COVER (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A100 1321	Front Platen Cover	1
2	AA16 2053	Platen Cover Pad	1
3	A406 9505	Platen Cover Sheet - 10Sheet/1 Set	1
4	A100 1323	Original Holder	1
5	A100 1322	Rear Platen Cover	1
6	A053 1957	Flex Hinge - Platen Cover	2
7	5215 2838	Rubber Magnet	1
8	A100 1324	Positioning Sensor Shutter	1
9	A100 1310	Platen Cover Hinge Ass'y	1
10	A100 1325	Hinge Spacer	1
11	A095 1394	Mounting Bracket - Platen Cover	1
12	A095 1363	Cap - 38x77	1
13	5215 1667	Platen Cover Stud	2
14	A095 1391	Positioning Sensor Bracket	1
15	AW02 0067	Photointerrupter - EESX4019 - P15	1
16	AW02 0062	Photointerrupter - EESX4019 - P15	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0142W	Tapping Screw - M4x14	
102	0314 0100W	Philips Pan Head Screw - M4x10	
103	0344 0080W	Philips Truss Head Screw - M4x8	

3. OPERATION PANEL ASS'Y (A095/A096/A097)



3. OPERATION PANEL ASS'Y (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 1461	Operation Panel Ass'y - LT	1
*	A096 1462	Operation Panel Ass'y - A4	1
1	A096 1487	Operation Panel Case - A4	1
1	A096 1486	Operation Panel Case - LT	1
2	A096 1491	Keytop - Start	1
3	A096 1492	Keytop - C/S	1
4	A096 1493	Keytop - Set 1	1
5	A096 1494	Keytop - Interrupt	1
6	A096 1498	Keytop - Mode Clear	1
7	A096 1496	Keytop - Set 2	1
8	A096 1497	LCD Display Dial	1
9	A096 1506	Right Keytop Sheet	1
10	A096 1507	Left Keytop Sheet	1
11	A096 1508	Grounding Plate	1
12	A096 1509	Cushion -1	2
13	A096 1510	Cushion -2	2
14	A096 1511	Grounding Harness -1	2
15	A096 1521	Grounding Harness -2	1
	A096 1512	x/o MB1	
16	A096 1513	LCD Display Sheet	1
17	A096 7711	IC - AM27C4096-150DC (ASIA)	1
17	A096 7701	IC-AM27C4096-150DC (115V)	1
18	A096 1518	Key Board - 220/230V	1
18	A096 1517	Key Board - 115V	1
19	AW50 0016	Touch Panel	1
20	AX30 0001	LCD Display	1
21	A096 7712	IC - AM27C1024-150DC (ASIA)	1
21	A096 7702	IC-AM27C1024-150DC (115V)	1
22	A096 7714	IC - AM27C010-150DC (ASIA)	1
22	A096 7704	IC-AM27C010-150DC(115V)	1
23	A096 7571	Operation Panel Board - 220/230V	1
23	A096 7570	Operation Panel Board (ASIA)	1
23	A096 7560	Operation Panel Board - 115V	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0432 0060B	Philips Tapping Screw - M2x6	
102	0432 0100B	Philips Tapping Screw - M2x10	
103	0432 0080B	Philips Tapping Screw - M2x8	

4. OPTICS SECTION 1 (A095/A096/A097)



4. OPTICS SECTION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 1901	Left Scale - A4	1
	A096 1741	x/o MB1	
1	A096 1904	Left Scale - LT	1
	A096 1742	x/o MB1	
2	AC04 2072	Rear Scale - A4	1
2	AC04 2076	Rear Scale - LT	1
3	AA06 0519	Tension Spring - 62mm	1
4	AC01 2034	Exposure Glass (A095)	1
4	AC01 2035	Exposure Glass (A096)	1
5	A096 1825	Main Optics Cover	1
6	AA15 0305	Seal - 20mm	4
7	A096 5472	Optics Harness	1
8	A096 1874	Harness Guide Plate	1
9	A096 1736	Cushion -1x13x41	1
10	A096 1738	Seal - 0.05x26x285	1
	A096 1737	x/o MB16	
11	AW01 0033	Original Sensor Asss'y - H =3-50	1
12	A096 1842	Rear Optics Cover	1
13	A096 1832	Front Optics Cover	1
14	A096 1848	Cover Guide Plate	1
15	A007 1920	Cushion - Exposure Glass	4
16	AA16 1076	Scanner Stopper	4
17	AA15 0628	Seal - 0.19x15x34	2
18	A096 1735	VD/ADS Pattern	1
19	AW10 0022	Optics Thermistor	1
20	AA15 0629	Seal - 0.19x28x108	1
21	A096 1821	2nd Optics Cover	1
22	AA14 3416	Stepped Screw - M4x3	2
23	AA13 2163	Idler Shaft	1
24	AA14 3417	Shoulder Screw - M4x4	3
25	AA15 2229	Seal - 9x114	1
26	A096 1749	Grounding Plate	1
27	A096 1739	Small VL Pattern	1
		MB21 (ADDED)	

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060W	Philips Pan Head Screw - M4x6	
102	1105 0267	Wire Clamp	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0314 0040W	Philips Pan Head Screw - M4x4	
105	1105 0278	Harness Clamp	
106	0951 4006W	Philips Screw With Flat Washer-M4x6	
107	0313 0050W	Philips Pan Head Screw - M3x5	
108	0323 0050W	Philips Sunken Head Screw - M3x5	

5. OPTICS SECTION 2 (A095/A096/A097)



5. OPTICS SECTION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA01 2073	Filter	1
	AA01 2061	o/o MB5	
2	A097 1727	Cooling Fan Filter	1
	A096 1725	o/o MB5	
3	AA15 1816	Seal - 5x14x212	1
4	A096 1727	Guide Plate	1
5	A096 1819	3rd Scanner Guide	1
6	AX65 0013	Optics Cooling Fan	1
7	A096 1828	Cover Angle - Front Left	1
8	A096 1827	Cover Angle - Front Right	1
9	A096 1290	Left Support Bracket - ADF	1
10	A096 1291	Right Support Bracket - ADF	1
11	A096 1994	Filter Holder	1
12	A096 1995	Filter	1
13	A096 1713	Front Right Angle	1
14	A096 1714	Front Left Angle	1
15	AX40 0048	Anticondensation Heater - 15W 220/230V	1
15	AX40 0047	Anticondensation Heater - 15W115V	1
16	A096 1678	Left Rail - Drum Unit	1
17	A096 1677	Right Rail - Drum Unit	1
18	A096 1676	Development Unit Rail	1
19	A096 1716	Optics Heater Cover	1
20	A096 1715	Optics Heater Bracket	1
21	A096 1829	Cover Rear Angle	2
22	AA15 0333	Seal - 0.19x14x74	1
23	AA15 0334	Seal -0.19x40x48	1
24	A096 1679	Development Grounding Plate	1
25	A096 5536	ARS Harness Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060W	Tapping Screw - M4x6	
102	0951 3005W	Philips Screw With Flat Washer-M3x5	
103	0314 0060W	Philips Pan Head Screw - M4x6	
104	0314 0040W	Philips Pan Head Screw - M4x4	
105	0951 4008W	Philips Screw With Flat Washer-M4x8	
106	1105 0278	Harness Clamp	
107	1106 0459	Bushing - 20.2mm	
108	0434 0060B	Philips Tapping Screw - M4x6	
109	0434 0080W	Tapping Screw - M4x8	
110	0434 0080B	Philips Tapping Screw - M4x8	
111	1105 0199	Clamp	

6. OPTICS SECTION 3 (A095/A096/A097)



6. OPTICS SECTION 3 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 1921	Scanner Drive Shaft	1
2	A096 1925	Front Wire Pulley	1
3	A096 1682	Rear Scanner Guide	1
4	A096 1729	Left Harness Guide	1
5	A096 1687	Wire Guide	2
6	AA06 0386	Pressure Spring	1
7	AA05 0078	Rear Scanner Drive Wire	1
8	AA05 0077	Front Scanner Drive Wire	1
9	A096 1680	Front Scanner Guide	1
10	A096 1940	Tension Bracket	1
11	AB03 0425	Belt Tension Pulley	2
12	AA06 0530	Belt Tension Spring - 29.3mm	1
13	AB03 0424	Timing Pulley - 40Z	1
14	AA04 3227	Timing Belt -	1
15	A096 1934	Motor Bracket	1
16	AX07 0008	DC Motor - 53W	1
17	A096 1692	ADS Case	1
18	A096 5230	ADS Board	1
19	A096 1694	ADS Bracket - A4 (A095)	1
19	A096 1695	ADS Bracket (A096)	1
20	A096 1693	ADS Cover	1
21	A096 1816	Sensor Bracket - Lens Position	1
22	A096 1939	Timing Pulley Ring	1
23	AB03 0450	Timing Pulley - 24Z	1
24	A096 1927	Front Wire Bracket	1
25	A096 1876	Harness Clamp	4
26	5446 1865	Bushing - 5x9x5.5mm	1
27	AA10 1010	Plate Nut - M5	1
28	5205 1853	Mylar Seal - Base	4
29	AA15 0332	Seal -0.19x18x22	4
30	A096 5474	Platen Cover Harness	1
31	A096 5473	Outer Optics Harness	1
32	AW02 0056	Photointerrupter - EE-SX4235A-P1	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0805 3341	Ball Bearing - 10x22x6	
103	0434 0060W	Tapping Screw - M4x6	
104	0574 0050W	Hexagon Headless Set Screw - M4x5	
105	0960 4006W	Philips Flange Screw - M4x6	
106	1105 0278	Harness Clamp	
107	0313 0050W	Philips Pan Head Screw - M3x5	
108	1105 0087	Clamp	
109	0434 0080W	Tapping Screw - M4x8	
110	0951 4008B	Philips Screw With Washer - M4x8	
111	0710 0050W	Hexagon Nut - M5	
112	0434 0060B	Philips Tapping Screw - M4x6	
113	1105 0291	Wire Saddle	
114	0951 3005W	Philips Screw With Fiat Washer-M3x5	
115	0413 0062W	Tapping Screw - M3x6	
116	0314 006W	Philips Pan Head Screw - M4x6	
117	1102 6245	Connector - 2P	
118	1102 6274	Connector - Yellow 3P	
119	1102 6260	Connector - Red 3P	
120	1102 6247	Connector - 4P	

7. OPTICS SECTION 4 (A095/A096/A097)





7. OPTICS SECTION 4 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 1802	Left Holder - X	1
2	AC05 1013	Lens Guide Rod - X	1
3	A096 1801	Lens Slider - X	1
4	AA04 3219	Timing Belt - B40S2M1066	1
5	AB01 7299	Pulley - 77Z	1
6	AB01 7284	Gear - 34/68Z	1
7	AX05 0063	Stepping Motor -11W	1
8	A096 1811	Motor Bracket	1
9	A096 1717	Front Sensor Cover	1
10	A096 1718	Rear Sensor Cover - A4	1
10	A096 1719	Rear Sensor Cover - LT	1
11	AW01 0035	Original Sensor Ass'y - H =3-125	1
12	AW01 0038	Original Sensor Ass'y - H = 125 (LT)	1
12	AW01 0035	Original Sensor Ass'y - H = 3-125 (A4)	1
13	AC03 5050	Rear Spring Plate - 6th	1
14	AC03 0094	6th Mirror	1
15	A096 1992	Rear 6th Mirror Holder	1
16	A096 1991	Front 6th Mirror Holder	1
17	AC03 5049	Front Spring Plate - 6th	1
18	A096 1689	Scanner Sensor Bracket	1
19	AW02 0061	Photointerrupter - EE - SX4019-P1	1
20	A096 1807	Lens Driver Pulley - X	1
21	AA06 0514	Tension Spring -21.5mm	1
22	A096 1804	Right Holder - X	1
23	A096 7633	Lower Optics Harness - 115V	1
23	A096 5471	Lower Optics Harness - 230V	1
24	AA10 0007	Ring - 7x13x5.5	1
25	5205 1694	Adjusting Cam - Start Lever	1
26	A079 1693	Guide Feeler	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 4006W	Philips Screw With Flat Washer-M4x6	
102	0313 0050W	Philips Pan Head Screw - M3x5	
103	0434 0060W	Tapping Screw - M4x6	
104	0433 0060W	Tapping Screw - M3x6	
105	0314 0060W	Philips Pan Head Screw - M4x6	
106	0314 0120W	Philips Pan Head Screw - M4x12	
107	1105 0292	Wire Saddle	
108	1105 0291	Wire Saddle	
109	1105 0278	Harness Clamp	
110	0414 0082W	Tapping Screw With Flat Washer-M4x8	
111	0951 4008W	Philips Screw With Flat Washer-M4x8	

8. OPTICS SECTION 5 (A095/A096/A097)



8. OPTICS SECTION 5 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A027 1769	Exposure Adjusting Plate - Side	2
2	A069 1855	Exposure Adjusting Plate - Center	1
3	A096 1866	Sub-reflector	1
4	AC03 0089	1st Mirror	1
5	A048 1721	Spring Plate A	2
6	AX52 0018	Exposure Lamp - 220/230V (A095/A096)	1
6	AX52 0022	Exposure Lamp - 220/230V (A097)	1
6	AX52 0016	Exposure Lamp - 115V	1
7	5215 1702	Clip - Exposure Lamp	1
8	A097 1860	1st Scanner Position Bracket	1
	A096 1857	x/o MB2	
9	A096 1861	Main Reflector	1
10	A096 1879	1st Mirror Cushion	1
11	A096 1855	1st Scanner Bracket	1
12	A096 1878	1st Mirror Support Plate	1
13	A096 1859	Wire Clamp	2
14	A096 5477	Exposure Lamp Harness	1
15	A096 1862	Lamp Terminal Insurator	2
	A096 1856	o/o MB5	
16	5215 1700	Exposure Lamp Terminal - Fix	1
17	5420 1682	Supporter - Lamp Terminal	2
18	A007 1868	Spacer - Lamp Terminal	2
19	A096 1858	1st Scanner Holder	2
20	A096 1865	Reflector Cover	1
21	A069 1883	Shoe - Scanner	4
	A069 1854	Bushing - 5mm o/o MB6	
22	A096 1871	Thermostat Holder	1
23	AW11 0011	Thermostat 140°C AC120V 15A	1
24	A096 5476	Exposure Support Harness	1
25	5442 1705	Exposure Lamp Terminal - Release	1
26	A096 1873	Scanner Shoe Pin	4
27	A096 1875	Guard Sheet	1
		MB16 (ADDED)	

Index No.	Part No.	Description	Q'ty Per Assembly
101	0313 0050W	Philips Pan Head Screw - M3x5	
102	0353 0040W	Philips Pan Head Bind Screw - M3x4	
103	0951 4006W	Philips Screw With Flat Washer-M4x6	
104	0951 3012W	Philips Screw With Flat Washer-M3x1	
105	0313 0080W	Philips Pan Head Screw - M3x8	
106	0313 0120W	Philips Pan Head Screw - M3x12	

9. OPTICS SECTION 6 (A095/A096/A097)



9. OPTICS SECTION 6 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AC03 5041	Front Spring Plate - 2nd	1
2	AC03 0090	2nd Mirror	1
3	AC03 5042	Rear Spring Plate - 2nd	1
4	A096 1891	2nd Scanner Bracket	1
5	A069 1883	Shoe-Scanner	4
	A069 1854	Bushing-5mm o/o MB6	
6	AC03 5044	Rear Spring Plate - 3rd	1
7	AC03 5043	Front Spring Plate - 3rd	1
8	AC03 0091	3rd Mirror	1
9	A096 1986	Sensor Bracket	1
10	AW02 0067	Photointerrupter -EESX4019 - P15	1
11	AA06 0515	Tension Spring - 23.4mm	1
12	AX05 0064	Stepping Motor - DC 7W	1
13	AC03 0092	4th Mirror	1
14	AC03 0093	5th Mirror	1
15	AC03 5045	Front Spring Plate - 4th	1
16	AC03 5046	Rear Spring Plate - 4th	1
17	AC03 5048	Rear Spring Plate - 5th	1
18	AC03 5047	Front Spring Plate - 5th	1
19	A096 1961	Slider Bracket - 3rd Scanner	1
20	5209 1694	Guide Roller - 1st Scanner	1
21	A096 1963	Slider Shaft	1
22	5205 1694	Adjusting Cam - Start Lever	1
23	A096 1956	3rd Scanner Bracket	1
24	A096 1981	3rd Scanner Holder	1
25	AC05 1015	Guide Rod - 3rd Scanner	1
26	A096 1983	Right Holder - Guide Rod	1
27	A096 1984	Left Holder -. Guide Rod	1
28	A096 1982	Holder Fixing Plate	1
29	A096 1971	Drive Bracket - 3rd Scanner	1
30	AB01 7301	Pulley - 25Z	1
31	AB01 7039	Gear - 24/48T	1
32	AA04 3221	Timing Belt - B40S2M280	1
33	AB03 0412	Pulley - 25Z	1
34	A096 1976	Pulley Bracket	1
35	A096 5470	Right Optics Harness	1
36	AA14 3062	Shoulder Screw - M4	1
37	A096 1873	Scanner Shoe Pin	4
101	0313 0060W	Philips Pan Head Screw - M3x6	
102	0951 4006W	Philips Screw With Flat Washer-M4x6	
103	0414 0082W	Tapping Screw With Flat Washer-M4x8	
104	0434 0060W	Tapping Screw - M4x6	
105	1105 0087	Clamp	
106	0314 0120W	Philips Pan Head Screw - M4x12	
107	0314 0060W	Philips Pan Head Screw - M4x6	
108	0314 0080W	Philips Pan Head Screw - M4x8	
109	0952 4008W	Philips Screw - M4x8	
110	0720 0040E	Retaining Ring - M4	
111	0574 0060E	Hexagon Headless Set Screw - M4x6	
112	0951 4008W	Philips Screw With Flat Washer-M4x8	
113	0313 0050W	Philips Pan Head Screw - M3x5	
114	0720 0070E	Retaining Ring - M7	

10. OPTICS SECTION 7 (A095/A096/A097)





10. OPTICS SECTION 7 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 1773	Lens Cover	1
2	A096 1835	Optics Shielding Belt	1
3	AA06 0516	Tension Spring - 42mm	2
4	A096 1760	Lens Ass'y	1
5	A096 1792	Rear Shielding Bracket	1
6	AA15 0337	Rear Shielding Mylar	1
7	AA15 0336	Front Shielding Mylar	1
8	A096 1767	Lens Position Bracket - Y	1
9	A053 1725	Lens Bracket Cam	1
10	AA13 2161	Lens Roller	1
11	A096 1766	Lens Slider	1
12	AA15 2228	Brush Seal - 4x5x120	1
13	A096 1787	Lens Position Bracket - X	1
14	5209 1694	Guide Roller - 1st Scanner	1
15	AC05 1014	Lens Guide Rod - Y	1
16	A096 1778	Rear Belt Holder	1
17	AA04 3220	Timing Belt - B40S2M560	1
18	A096 1775	Lens Driven Pulley - Y	1
19	AA06 3253	Tension Spring - 20mm	1
20	AB01 7300	Lens Drive Pulley	1
21	A096 1777	Front Belt Holder	1
22	A096 1781	Lens Bracket	1
23	AB01 7039	Gear - 24/48T	1
24	AA15 2225	Brush Seal - 6x10 - 288	1
25	A096 1782	Harness Cover	1
26	A096 1796	Harness Bracket A	1
27	A096 1797	Harness Bracket B	1
28	A096 5482	Lens Drive Harness	1
29	AX04 0065	Stepped Motor - DC 13W	1
30	A096 1791	Lens Sensor Bracket - Y	1
31	A096 1876	Harness Clamp	1
32	AW02 0061	Photointerrupter - EE - SX4019-P1	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0313 0050W	Philips Pan Head Screw - M3x5	
102	0314 0060W	Philips Pan Head Screw - M4x6	
103	1105 0278	Harness Clamp	
104	0951 4010W	Philips Screw With Flatwasher-M4x10	
105	0720 0040E	Retaining Ring - M4	
106	0314 0120W	Philips Pan Head Screw - M4x12	
107	0951 4012W	Philips Screw With Washer - M4x12	
108	0951 4006W	Philips Screw With Flat Washer-M4x6	

11. BY-PASS FEED TABLE (A095/A096/A097)



11. BY-PASS FEED TABLE (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A053 2770	Holder - Manual Feed Table	1
2	A007 2803	Manual Feed Table Holder	1
3	A096 2706	By-pass Feed Cover	1
4	AW50 0012	Push Switch	1
5	AA02 1025	Magnet Catch	1
6	A096 2707	Upper Guide - By-pass	1
7	A096 2708	By-pass Feed Table - A4	1
	A096 2811	x/o MB13	
7	A096 2810	By-pass Feed Table - LT	1
8	A096 2761	Front Support Guide	1
9	A096 2741	Front Feed Guide	1
10	A096 2711	Feed Table	1
11	AA00 2175	Decal - Paper Size - A4	1
11	AA00 2192	Decal - Paper Size - LT	1
12	A096 2751	Rear Feed Guide	1
13	A096 2771	Rear Support Guide	1
14	A096 2782	Size Switch Bracket	1
15	A096 5335	Paper Size Switch	1
16	A053 2837	Paper Guide - Manual Feed	1
17	AB01 3492	Gear - 16Z	1
18	A096 2780	Feed Guide Gear	2
19	A096 2721	By-pass Feed Cover	1
20	A053 2773	Holder - Manual Feed Table	1
21	A069 2645	Seal - 0.2x16x47	2
22	A096 2781	By-pass Table Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0965 3008B	Tapping Screw With Washer - M3x8	
104	0965 3008F	Tapping Screw With Washer - M3x8	

12. PAPER REGISTRATION 1 (A095/A096/A097)



12. PAPER REGISTRATION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 5200	Registration Sensor Board	1
2	A096 2606	Resist Sensor Guide	1
3	A096 2607	Paper Dust Cleaner	1
4	A096 2612	Lower Registration Guide	1
5	AF02 0255	Upper Registration Roller	1
6	AF02 0242	Lower Registration Roller	1
7	A096 2626	Front Upper Registration Guide	1
8	5447 2706	Gear-15T	1
9	A096 2622	Front Lower Registration Guide	1
10	A096 2604	Magnetic Clutch Stopper	1
11	5215 2672	Bushing	2
12	AX21 0036	Magnetic Clutch - Registration	1
13	AX20 0090	Magnetic Clutch - By-pass	1
14	AW02 0056	Photointerrupter-EE-SX4235A-P1	1
15	A096 2699	Sensor Bracket-Paper End	1
16	A096 2700	Paper End Shutter	1
17	A096 2692	Pick-up Solenoid - By-pass	1
18	A096 2695	Pick-up Roller Link	1
19	AA06 0517	Pick-up Release Spring	1
20	A096 2687	Upper Feed Stay	1
21	A096 2697	Paper End Feeler	1
22	AA14 0489	Shaft-Feed	1
23	AA06 6213	Feeler Spring	1
24	5443 2668	Bushing - 4x6x7mm	2
25	AA06 0518	Pick-up Pressure Spring	1
26	A096 2690	Pick-up Roller Arm	1
27	AF03 0021	Pick-up Roller	1
28	AF03 1021	Paper Feed Roller	1
29	A060 2512	Registration Roller Knob	1
30	A096 2598	Front Connector Bracket	1
31	5442 2754	Spring - Registration Roller	2
32	5205 2697	Bushing - Upper Registration Roller	2
33	A096 2701	Clutch Stopper - By-pass	1
34	5442 1659	Stepped Screw - M4	2
35	5053 0223	Bushing - 8mm	3
36	5205 2865	Bushing - Paper Feed Roller	1
37	AA13 2129	Spacer - 8x12x4.5	1
38	5447 2681	Snap Ring	2
101	0434 0060B	Philips Tapping Screw - M4x6	
102	1102 6247	Connector - 4P	
103	1102 6246	Connector - 3P	
104	0951 4008B	Philips Screw With Washer - M4x8	
105	0720 0060B	Retaining Ring - M6	
106	0314 0060B	Philips Pan Head Screw - M4x6	
107	0720 0050B	Retaining Ring - M5	
108	1105 0278	Harness Clamp	
109	0720 0030E	Retaining Ring - M3	
110	0574 0060E	Hexagon Headless Set Screw - M4x6	
111	0314 0080B	Philips Pan Head Screw - M4x8	
112	0701 0040B	Flat Washer - M4	
		MB22 (ADDED)	

13. PAPER REGISTRATION 2 (A095/A096/A097)



13. PAPER REGISTRATION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 2661	Paper Bank Relay Guide	1
2	A469 2123	Rubber Cushion -1 x10x10mm	2
3	**A096 2672**	Duplex Exit Guide	1
4	AF02 0288	Duplex Exit Roller	1
5	AA08 0034	Bushing - 4x5x7	2
6	AA14 0486	Lock Shaft	1
7	A096 2632	Middle Shutter Guide	1
8	A096 2634	Rear Lock	1
9	5443 2668	Bushing - 4x6x7mm	2
10	AA06 6211	Rear Lock Spring	1
11	AW02 0056	Photointerrupter - EE-SX4235A-P1	1
12	A096 2636	Sensor Bracket	1
13	AB01 1127	Gear - 52Z	1
14	A096 2642	Guide Shutter Solenoid	1
15	AB01 1128	Gear - 40Z	1
16	5205 2697	Bushing - Upper Registration Roller	2
17	A096 5405	By-pass Feed Harness	1
18	A096 2703	Lower Guide - By-pass	1
19	A053 2916	Friction Pad - B	1
20	A096 2704	Guide Holder	2
21	AF02 0287	Transport Driven Roller	1
22	A096 2651	LCT Exit Guide ,	1
23	AF02 0286	Transport Drive Roller	1
24	AB01 3420	Gear - 18Z	2
25	AA14 0488	Separation Drive Shaft	1
26	A096 2682	Separation Roller Bracket	1
27	AW02 0058	Photointerrupter	1
28	A096 2683	Sensor Bracket	1
29	A096 2684	Separation Roller Shaft	1
30	AF03 2021	Separation Roller	1
31	A060 2617	Separation Torque Limiter	1
32	A096 2593	Front Support Plate	1
33	A060 2512	Registration Roller Knob	1
34	A096 2633	Front Lock	1
35	A096 2635	Lock Release Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	5053 0447	Bushing - 6mm	2
37	AA08 0037	Bushing -6 mm	1
38	AA06 3164	Pressure Spring	1
39	A096 2600	Rear Connector Bracket	1
40	5053 0223	Bushing - 8mm	5
41	AA06 3254	Driven Roller Spring	2
42	5447 2681	Snap Ring	1
43	AA06 3255	Exit Roller Spring	2
44	AA00 1213	Decal - B2	1
45	A096 5432	Duplex Relay Harness	2
46	A096 3408	Grounding Plate	1
101	0720 0040B	Retaining Ring - M4	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0951 4008B	Philips Screw With Washer- M4x8	
104	0720 0060B	Retaining Ring - M6	
105	0314 0080B	Philips Pan Head Screw - M4x8	
106	0964 4008B	Tapping Screw With Flat Washer-M4x8	
107	1105 0005	Nylon Clip - 3N	
108	1102 6248	Connector - 5P	
109	0720 0030B	Retaining Ring - M3	
110	0313 0080B	Philips Pan Head Screw - M3x8	
111	0314 0060B	Philips Pan Head Screw - M4x6	
112	0632 0100G	Pin - 2x10mm	
113	1105 0087	Clamp	
114	1105 0291	Wire Saddle	
115	1102 6250	Connector - 7P	
116	1102 6256	Connector - 13P	

14. PAPER FEED SECTION (A095/A096/A097)



14. PAPER FEED SECTION (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 5411	Upper Feed Unit Harness	3
2	A096 6344	Paper End Actuater	3
3	A096 6345	End Sensor Bracket	3
4	AW02 0056	Photointerrupter - EE-SX4235A-P1	6
5	54472681	Snap Ring	15
6	A096 6358	Photointerrupter Bracket	3
7	A096 6355	Pick-up Solenoid	3
8	A096 6346	Paper Feed Stay	3
9	A096 6342	Paper End Feeler	3
10	AA06 0523	Pick-up Pressure Spring	3
11	AA14 0498	Feed Roller Shaft	3
12	A096 6353	Feed Roller Lever	3
13	AA06 0522	Stopper Spring	3
14	A096 6337	Paper Feed Guide	3
15	A096 6351	Pick-up Arm	3
16	A096 6352	Feed Roller Bracket	3
17	AA08 2047	Bushing - 8x16x7	6
18	AF03 1022	Paper Feed Roller	3
19	AF03 0020	Pick-up Roller	3
20	AF02 0290	3rd Grip Roller	1
21	AF02 0289	Grip Drive Roller	2
22	A096 6338	Separation Guide	3
23	A096 6360	Paper Flatenner	6
24	AX21 0037	Magnetic Clutch	3
25	AB01 3775	Gear - 33Z	3
26	AB01 3774	Gear - 18Z	3
27	A096 6366	Clutch Stopper Arm	3
28	AB01 3777	Gear - 32Z	2
29	AB01 3776	Gear - 30Z	3
30	A096 5412	Lower Feed Unit Harness	3
31	AA08 2046	Bushing - 6x12x6	9
32	A096 6330	Rear Side Plate	3
33	AB01 3773	Gear - 18Z	3
34	A096 6306	Separation Drive Shaft	3
35	A096 6315	Release Solenoid	3

Index No.	Part No.	Description	Q'ty Per Assembly
36	A096 6311	Release Lever	3
37	AA06 6216	Release Spring	3
38	AF02 0280	Driven Roller	3
39	AA08 0156	Bushing - M4	6
40	A096 6369	Vertical Transport Guide	3
41	AA06 3487	Spring -10mm	6
42	A096 6308	Separation Pressure Lever	3
43	AA06 0520	Lever Spring - 24.4mm	3
44	A096 6303	Separation Roller Stay	3
45	AB01 3729	Gear - 18Z	3
46	AA06 6189	Feed Sensor Spring	3
47	A096 6307	Separation Driver Shaft	3
48	A060 2617	Separation Torque Limiter (A095/A096)	3
48	A097 6000	Separation Torque Limiter (A097)	3
49	AF03 2023	Separation Roller	3
50	A096 6321	Position Sensor Bracket	3
51	A096 6322	Position Sensor Feeler	3
52	AW02 0061	Photointerrupter - EE - SX4019-P1	3
53	A096 6381	Unit Fixing Plate - 3rd	1
54	A096 6375	Unit Fixing Plate	2
55	AB01 3779	Gear - 32Z	1
56	A096 6335	Front Side Plate	3
57	5447 2706	Gear - 15T	3
58	AB01 3780	Gear - 28/16Z	1
59	AA06 0521	Lower Release Spring	1
60	AB01 3778	Gear - 32Z	1
61	AA16 1095	Pad - 2x8x8x	1

Index No.	Part No.	Description	Q'ty Per Assembly
01	0434 0060B	Philips Tapping Screw - M4x6	
02	0720 0060B	Retaining Ring - M6	
03	0742 3808	Ball Bearing - 8x16x5	
04	1102 6265	Connector - Red 8P	
05	1102 6250	Connector - 7P	
06	0720 0040B	Retaining Ring - M4	
07	0805 3145	Ball Bearing - 6x12x4mm	
08	0574 0050E	Hexagon Headless Set Screw - M4x5	
09	1105 0087	Clamp	
10	0314 0120B	Philips Pan Head Screw - M4x12	
11	0720 0030B	Retaining Ring - M3	
12	0573 0040B	Hexaqon Headless Set Screw - M3x4	
13	1102 6245	Connector -2P	

Index No.	Part No.	Description	Q'ty Per Assembly

15. PAPER TRAY SECTION 1 (A095/A096/A097)



15. PAPER TRAY SECTION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 6549	Front Side Fence	2
2	A029 7904	Pad - CFF	4
3	AF01 7010	End Fence	2
4	A096 6568	Positioning Plate - End Fence	2
5	A048 2838	Nylon Rivet	4
6	A096 6556	Tray Bottom Plate	2
7	A096 6550	Rear Side Fence	2
8	AA00 2010	Decal - Paper Level	2
9	A096 6551	Positioning Plate - Side Fence	2
10	A096 6524	Lift Shaft	2
11	A096 6526	Lift Lever	2
12	A096 6527	Paper Guide Feeler	2
13	A096 6589	Paper Tray Cover - Short	1
13	A096 6620	Paper Tray Cover - Long	1
14	AA00 0139	Decal - No.3	1
14	AA00 0143	Decal - No.1	1
15	AA15 1804	Lever Cushion	2
16	AA15 1805	Bottom Plate Cushion	2
17	A095 1383	Lower Front Cover	1
18	A095 1384	Bracket - Lower Front Cover	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082F	Philips Truss Head Screw - M4x8	
102	0965 4008B	Tapping Screw - M4x8	
103	0952 4008W	Philips Screw - M4x8	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0314 0080B	Philips Pan Head Screw - M4x8	
106	0720 0060B	Retaining Ring - M6	
107	0354 0050F	Philips Pan Head Bind Screw-M4x5	

16. PAPER TRAY SECTION 2 (A095/A096/A097)



16. PAPER TRAY SECTION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 6512	Universal Tray - A4	1
*	A096 6511	Universal Tray - LT	1
1	A096 6563	End Fence Cover	1
2	A096 6537	Stopper Lever	2
3	A096 6562	End Fence	1
4	A096 6564	End Fence Plate	1
5	A096 6589	Paper Tray Cover - Short	1
6	AA00 0138	Decal - No.2	1
7	AA00 0134	Decal - Tray Universal	1
8	A096 6534	Front Side Fence	1
9	A048 2838	Nylon Rivet	2
10	A096 6556	Tray Bottom Plate	1
11	A096 6541	Rear Side Fence	1
12	A096 6544	Side Fence Plate - A4	1
12	A096 6545	Side Fence Plate - LT	1
13	A096 6539	Side Fence Gear	2
14	AB01 3492	Gear - 16Z	1
15	A096 6578	Size Sensor Plate	1
16	A096 6577	Size Sensor Slider	1
17	AA00 2010	Decal - Paper Level	1
18	A096 6553	Side Fence Pad	2
19	AA00 2184	Decal - A4	1
19	AA00 2181	Decal - LT	1
20	AA00 2178	Decal - End Fence - A4	1
20	AA00 2179	Decal - End Fence - LT	1
21	A096 6524	Lift Shaft	1
22	A096 6527	Paper Guide Feeler	1
23	A096 6526	Lift Lever	1
24	AA15 1805	Bottom Plate Cushion	2
25	AA15 1804	Lever Cushion	1
26	AF01 3002	Bottom Plate Pad	1
27	AA06 3379	Stopper Spring - 22mm	2
28	A096 6536	Side Fence Cover	1
29	AA00 2176	Decal - Side Fence - A4	1
29	AA00 2177	Decal - Side Fence - LT	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082F	Philips Truss Head Screw - M4x8	
102	0413 0082B	Tapping Screw - M3x8	
103	0965 4008B	Tapping Screw - M4x8	
104	0354 0050F	Philips Pan Head Bind Screw-M4x5	
105	0952 4008W	Philips Screw - M4x8	
106	0805 0073	Retaining Ring - M5	
107	0433 0082B	Tapping Screw - M3x8	
108	0313 0060B	Philips Pan Head Screw - M3x6	
109	0314 0080B	Philips Pan Head Screw - M4x8	
110	0720 0060B	Retaining Ring - M6	

17. TANDEM TRAY 1 (A095/A096/A097)



17. TANDEM TRAY (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 6600	Tandem Tray	1
1	A096 6672	Motor Cover	1
2	A096 6658	Rear End Fence Gear	1
3	A096 6659	Front End Fence Gear	1
4	A096 5301	Tandem Tray Motor - DC 17W	1
5	A048 2838	Nylon Rivet	**4**
6	A096 6673	Bottom Plate	1
7	A096 6654	Lift Lever	1
8	A096 6652	Lift Shaft	1
9	A096 6656	Paper Volume Feeler	1
	A096 6655	x/o MB1	
10	A096 6653	Lift Shaft Bracket	1
11	A096 5419	Right Tandem Tray Harness	1
12	A096 6647	Rear End Fence Guide	1
13	A096 6666	Right Rear End Fence	1
14	AA06 6219	Tray Lock Spring	1
15	A096 6668	Release Pawl	1
16	AW02 0056	Photointerrupter - EE-SX4235A-P1	2
17	A096 6648	Right Rear Side Fence	1
18	A096 6671	Paper Guide Plate	4
19	AA00 2010	Decal - Paper Level	1
20	5205 2777	Cushion - Lower Pick up Guide	1
21	A096 6669	LCT Stopper	1
22	A096 6674	Right Tandem Tray	1
23	A096 6645	Right Front Side Fence	1
24	A096 6662	Right Front End Fence	1
25	A096 6646	Front End Fence Guide	1
26	AA16 2062	Bottom Plate Cushion	2
27	A096 6676	Side Fence Support Plate	2
28	AA13 2169	Spacer - 5.7x16x1.5	1
29	AA00 0144	Decal - Right Tandem Tray	1
30	AF01 3002	Bottom Plate Pad	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0960 3006B	Philips Flange Screw - M3x6	
102	0965 4008B	Tapping Screw - M4x8	
103	0805 0083	Retaining Ring - M4	
104	0720 0060B	Retaining Ring - M6	
105	0805 3389	Bushing - 8x10x6mm	
106	0314 0080B	Philips Pan Head Screw - M4x8	
107	0965 3012W	Tapping Screw With Flat Washer - M3	
108	0354 0050F	Philips Pan Head Bind Screw-M4x5	
109	0314 0080W	Philips Pan Head Screw - M4x8	

18. TANDEM TRAY 2 (A095/A096/A097)



18. TANDEM TRAY 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF01 6062	Left Front Side Fence	1
2	AA00 0136	Decal - Left Tandem Tray	1
3	A096 6641	Grounding Plate 1	1
4	A096 6629	Middle Bottom Plate	1
5	A096 6634	Left Rod Holder	1
6	AA14 0499	Guide Rod	2
7	A096 6633	Right Rod Holder	1
8	A096 6632	Tandem Tray Slider	1
9	AF01 7011	Left End Fence	1
10	A096 6644	Left Rear Side Fence	1
11	AA00 2010	Decal - Paper Level	1
12	AA04 3345	Timing Belt - B30S3M888	1
13	AB03 0417	Timing Pulley - 32Z	1
14	A096 5418	Left Tandem Tray Harness	1
15	AB03 0418	Timing Pulley - 12Z	3
16	AA06 0542	Tension Spring	1
17	A096 6636	Tightener Bracket	1
18	A096 5300	Tandem Tray Motor -DC 11W	1
19	A096 6607	Rear Bottom Plate	1
20	A096 6642	Grounding Plate 2	1
21	A096 6640	Front Bottom Plate	1
22	AW02 0056	Photointerrupter - EE-SX4235A-P1	2
23	AW02 0008	Photointerrupter	1
24	A096 6670	Timing Belt Roller	1
25	A096 6620	Paper Tray Cover - Long	1
26	AA00 0137	Decal - Tandem Tray 1	1
27	AF01 0063	Left Tandem Tray	1
28	A096 6649	Grounding Spring Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0414 0082F	Philips Truss Head Screw - M4x8	
102	0965 4008B	Tapping Screw - M4x8	
103	0720 0040B	Retaining Ring - M4	
104	0354 0050F	Philips Pan Head Bind Screw-M4x5	
105	0965 3012W	Tapping Screw With Flat Washer - M3	
106	1102 6245	Connector - 2P	
107	0965 3010W	Tapping Screw With Flat Washer-M3x1	
108	0965 4010B	Tapping Screw - M4x10	

19. LCT TRAY 1 (A095/A096/A097)



19. LCT TRAY 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5446 2698	Worm Gear	1
2	AX06 0051	DC Motor-24V11.2W	1
3	A096 6784	LCT Drive Shaft	1
4	5053 0223	Bushing - 8mm	2
5	5446 2702	Gear-22T	1
6	A096 6782	Motor Bracket	1
7	A096 6760	End Fence	1
8	A096 6752	End Fence Rail	1
9	A096 6753	Rail Shaft	1
10	A096 6765	Tray Bottom Plate	1
11	5442 2117	Shoulder Screw - Hinge	2
12	5201 2858	Friction Pad	1
13	AF01 6057	Side Fence	2
14	A096 6745	Right Side Plate	1
15	5446 2638	Decal -Paper Lower Limit	1
16	A096 6669	LCT Stopper	1
17	A096 6808	LCT Inner Cover	1
18	A096 6806	LCT Front Cover	1
19	A096 6811	Push Switch Bracket	1
20	A079 5794	Push Switch -Paper Tray	1
21	AA00 0139	Decal - No.3	1
22	5408 2035	Stepped Screw - M4	1
23	A096 6758	End Fence Slider	1
24	A096 9533	Fuse - 125V/4A MB10 (ADDED)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0414 0080B	Tapping Screw - M4x8	
103	0574 0050E	Hexagon Headless Set Screw - M4x5	
104	0720 0060E	Retaining Ring - M6	
105	0930 0400G	Parallel Key - 4x4x10	
106	0965 4008B	Tapping Screw - M4x8	
107	0801 0146	Bind Screw - M4x4	

20. LCT TRAY 2 (A095/A096/A097)





20. LCT TRAY 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA14 0529	Drive Wire Shaft	1
2	A096 6736	Front Side Plate	1
3	AB03 2058	Wire Pulley - M10	12
4	5446 2671	Drive Pulley - Paper Tray	2
5	5403 1030	Tension Spring	2
6	A028 3356	Rear Wire Tightener	2
7	A096 7632	LCT Harness	1
8	A096 6770	Bottom Plate Stay	2
9	AW02 0008	Photointerrupter	1
10	A096 6799	Paper Sensor Bracket	1
11	A096 6789	Lower Sensor Bracket	1
12	AW02 0056	Photointerrupter - EE-SX4235A-P1	2
13	A096 6794	Upper Sensor Bracket	1
14	A096 6741	Rear Side Plate	1
15	5053 0419	Bushing - 10mm	2
16	5415 2642	Lock Arm	1
17	AA05 0083	LCT Drive Wire - 1785mm	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0575 0050E	Hexagon Headless Set Screw - M5x5	
104	0313 0080B	Philips Pan Head Screw - M3x8	
105	1105 0278	Harness Clamp	
106	1105 0291	Wire Saddle	

21. DEVELOPMENT UNIT (A095/A096/A097)



21. DEVELOPMENT UNIT (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A097 3050	Development Unit (A095/A096/A097)	1
	A096 3049	o/o MB20 (A095/A096)	
	A096 3050	o/o MB5 (A095/A096)	
1	A096 3104	Development Guide Rail	1
2	AA01 2060	Development Filter	1
3	A096 3141	Development Filter Case	1
4	A096 3100	Entrance Seal	1
5	AD03 1247	Upper Development Roller	1
6	AD03 1248	Lower Development Roller	1
7	AD03 8052	Paddle Roller	1
8	AA15 2227	Rear Drum Seal	1
9	A096 3126	Bearing Case	1
10	AB01 3791	Gear - 17Z	2
11	AB01 3786	Gear - 18Z	1
12	AB01 3788	Gear - 23Z	1
13	AB01 3783	Gear - 34Z	1
14	AA08 0152	Bushing - 4x12x13	2
15	AA14 3416	Stepped Screw - M4x3	1
16	A096 3057	Lower Rear Side Plate	1
17	AA14 3430	Shoulder Screw - M4x16	1
18	AA06 3272	Grounding Spring	1
	AA06 3263	o/o MB19	
19	AA08 0150	Bushing - 6x16x12.8	4
20	AD03 8053	Mixing Paddle Roller	1
21	A096 3052	Lower Development Casing	1
22	A096 3059	Toner Sensor Guide	1
23	AW23 0006	Toner Density Sensor	1
24	AA15 2142	Seal -11x7x3.8mm	4
25	AD03 7035	Mixing Auger	1
26	A096 3056	Lower Front Side Plate	1
27	AB01 3785	Gear - 43Z	1
28	A096 3069	Development Knob	1
29	A096 3125	Adjusting Plate	1
30	AA15 2226	Front Drum Seal	1
31	AA14 3426	Stopped Screw - M4x17	1
32	AA13 2024	Spacer - M6	2
33	AD03 6047	Back Spill Plate (A095/A096/A097)	1
	A096 3086	o/o MB20 (A095/A096)	
34	AA13 2025	Spacer - 1x8x12	2
35	AB01 3790	Gear - 25Z	1
101	0314 0080B	Philips Pan Head Screw - M4x8	
102	0720 0040B	Retaining Ring - M4	
103	0951 3006B	Philips Screw With Flat Washer-M3x6	
104	0720 0030B	Retaining Ring - M3	
105	0314 0060B	Philips Pan Head Screw - M4x6	
106	0622 5160E	Spring Pin - 2.5x16	
107	0951 4008B	Philips Screw With Washer - M4x8	

22. TONER HOPPER SECTION (A095/A096/A097)





22. TONER HOPPER SECTION (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 3150	Toner Supply Unit	1
1	**A096 3183**	Hopper Shutter	1
2	**AA15 1791**	Hopper Entrance Seal	1
3	AW31 0003	Toner End Sensor	1
4	AA15 1794	Seal - **3x5x322**	1
5	AA15 1792	**Seal - 3x15x85**	2
6	AA15 1793	seal - 3X35X211	1
7	A096 3181	Slitter	1
8	A096 3182	Plate Nut	1
9	AA06 0291	Spring	1
10	AB01 3749	Gear - 15Z	1
11	AB01 3747	Gear -162	1
12	AB01 3748	Joint Gear -152	1
13	A096 3175	Bushing - 8x14x8	1
14	A096 3176	Bushing - 6x12x8.5	1
15	AA15 0361	Slitter Cover Seal	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0413 0082W	Tapping Screw - M3x8	
102	0951 4006B	Philips Screw With Washer- M4x6	
103	0727 0080	C-ring - M8	
104	0720 0040B	Retaining Ring - M4	
105	0314 0050B	Philips Pan Head Screw - M4x5	

23. TONER BOTTLE HOLDER SECTION (A095/A096/A097)



23. TONER BOTTLE HOLDER SECTION (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 3230	Shutter Joint	1
2	A096 3225	Bottle Stopper - A4	1
2	A096 3241	Bottle Stopper - LT	1
3	AA15 1798	Seal - 2x40x63	2
4	AA15 0355	Handle Bracket Cover	1
5	A096 3243	Lever Bushing	1
6	A096 3224	Bottle Roller	2
7	A096 3235	Holder Cover	1
8	AA15 1797	Holder Base Seal	1
9	A096 3222	Bottle Holder	1
10	A096 3236	Shutter Lever	1
11	AA06 6209	Shutter Spring	1
12	A096 3231	Shutter Lever	1
13	A096 3233	Holder Shutter	1
14	A096 3210	Bottle Hinge Bracket	1
15	A096 3401	Upper Hinge	1
16	AA06 3170	Drive Change Spring	1
17	AA13 2158	Collar	1
18	A096 3216	Bottle Holder Bracket	1
19	A096 3239	Development Inner Cover	1
20	A096 5325	Bottle Drive Motor - DC 5.2W	1
21	A096 3238	Toner Tray	1
22	A096 3217	DC Motor Bracket	1
23	AB01 5011	Gear - 32Z	1
24	AB01 7278	Gear - 14/40Z	1
25	A096 3404	Lower Hinge	1
26	AA14 3290	Stepped Screw - M4	1
27	AA00 1323	Decal - Bottle Shutter	1
28	AA00 1322	Decal - Bottle Set	1
29	AG07 0007	Magnet Catch	1
30	AA14 8361	Click Guide	1
31	AA15 1796	Stopper Seal	1
32	AA15 1795	Holder Seal	1
33	AA06 0262	Spring	1
34	A096 3245	Bottle Guide Plate	1

Index No.	Part No.	De p on	Q'ty Per Assembly
		MB9 (ADDED)	
101	0965 4008W	Tapping Screw With Flat Washer - M4x8	
102	0344 0080W	Philips Truss Head Screw - M4x8	
103	0720 0040B	Retaining Ring - M4	
104	0964 4008B	Tapping Screw With Flat Washer-M4x8	
105	1105 0263	Wire Saddle	
106	0725 0120B	Retaining Ring - M12	
107	0964 4012B	Tapping Screw With Flat Washer-M4	
108	0434 0080B	Philips Tapping Screw - M4x8	
109	0720 0060B	Retaining Ring - M6	
110	0313 0040B	Philips Pan Head Screw - M3x4	

24. DRUM UNIT 1 (A095/A096/A097)



24. DRUM UNIT 1 **(A095/A096/A097)**

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 2251	Upper Drum Unit	1
1	A096 2260	Upper Unit Cover	1
2	A096 5210	Erase Lamp Unit	1
3	AZ32 0067	High-voltage Supply Board - C	1
4	A096 2271	Grounding Plate	1
5	A096 5442	Corona Cleaner Harness	1
6	A096 2282	Connector Bracket	1
7	A096 2266	Corona Unit Bracket	1
8	A096 2261	Eraser Cover	1
9	AD00 4069	Charge Corona Unit	1
10	A096 2302	Upper Drum Shield	1
11	AA08 0148	Rear Bushing	1
12	A096 2061	Screw Shaft	1
13	A096 2063	Corona Wire Cleaner	1
14	A096 2062	Wire Cleaner Slider	1
15	AA08 0147	Front Bushing	1
16	A096 2053	Cleaner Motor Cover	1
17	A096 2054	Grounding Plat	1
18	AD02 3106	Charge Corona Casing	1
19	AD02 0053	Charge Corona Wire	1
20	AD02 2285	Rear End Block	1
21	AA06 3248	Charge Terminal Spring	1
22	AA06 3249	Grid Terminal Spring	1
23	AD02 2286	Rear End Block Cover	1
24	A096 2051	Rear Grid Anchor	1
25	A096 2057	Charge Corona Grid	1
26	A096 2052	Front Grid Anchor	1
27	AD02 2284	'Front End Block Cover	1
28	5442 2108	Spring - Corona Wire	1
29	AD02 2283	Front End Block	1
30	A096 2055	Motor Grounding Plate	1
31	AX04 0061	Cleaner Motor - DC 0.5W	1
32	AB01 0087	Gear - 20Z	1
33	A096 2065	Slider Ring	1
34	AD02 1091	Charge Corona Receptacle	1
35	A096 2301	Grounding Plate	1
36	AW33 0003	Drum Potential Sensor	1
37	A096 5320	Quenching Lamp	1
38	5409 1855	Mounting Pin	2
39	AA15 0350	Seal - 40x130	1
40	AA15 1802	Eraser Cover Seal	1
41	AA15 1780	Potential Sensor Cover	2
42	AA16 1034	Cleaner Cushion	1
		MB18 (ADDED)	
101	0413 0082W	Tapping Screw - M3x8	
102	0965 3008W	Tapping Screw With Washer - M3x8	
103	0951 4010W	Philips Screw With Flatwasher-M4xl10	
104	1102 6245	Connector - 2P	
105	0720 0025B	Retaining Ring - M2.5	
106	0971 4006A	Philips Polycarbonate Screw - M4x6	
107	0960 4006B	Philips Flange Screw - M4x6	

25. DRUM UNIT 2 (A095/A096/A097)





25. DRUM UNIT 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A097 3511	Lower Drum Unit (A097)	1
*	A097 3510	Lower Drum Unit (A095/A096)	1
	A096 3510	x/o MB7 (A095/A096)	
	A096 3500	x/o MB1 (A095/A096)	
1	AA08 0155	Rear Pawl Bushing	1
2	A096 3575	Blade Release Lever	1
3	AA06 3384	Pick-off Pawl Shaft Spring	1
	AA06 3373	Spring - 60mm x/o MB17	1
4	A096 3624	Drum Grounding Plate	1
5	AB01 7323	Cam Gear - 35Z	1
6	A096 9510	OPC Drum	1
7	A096 3588	Gear - 19Z	1
8	AB01 7296	Gear - 30/47Z	1
9	A096 3661	Gear - 15/35Z	3
10	AB01 7288	Cam Gear - 35Z	1
11	A096 3656	Gear Bracket	1
12	A096 3581	Cleaning Blade	1
13	5853 1190	Spring - Click Plate	1
14	A096 3565	Cleaning Blade Bracket	1
15	A096 3631	Cleaning Seal	1
16	A096 3607	Brush Roller Bracket	1
	A096 3606	Cleaning Brush Seal x/o MB11	
17	AD04 3030	Toner Collection Coil	1
18	5894 2540	Arm Screw	2
19	AA06 3380	Spring - 16mm	1
20	AA06 3374	Toner Receiving Spring	1
21	A096 3664	Toner Receiving Pipe	1
22	AA08 2045	Cleaning Brush Bushing	1
23	A096 3594	Joint Gear - 14Z	1
24	AD04 2023	Cleaning Brush	1
25	A096 3586	Cleaning Brush Drive Shaft	1
26	AA15 0344	Mylar Seal - 11x350	1
27	AA13 2024	Spacer - M6	3
28	AA15 2314	Front Drum Seal	1
29	A096 3642	Pick-off Pawl Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
30	A096 5220	ID Sensor Board	1
31	AA15 2323	Rear Drum Seal	1
32	A096 5315	Pre-transfer Lamp	1
33	A096 3621	Entrance Seal	1
34	A096 3646	Pick-off Pawl Shaft	1
35	AD02 5018	Pick-pawl	2
	AD02 5015	x/o MB7	
36	AA06 6215	Rear Pawl Spring	1
37	AA06 6214	Front Pawl Spring	1
38	A096 3666	Harness Cover	1
39	A096 3558	PTL Cover	1
40	AA08 0154	Rear Bushing	1
41	AA13 2025	Spacer - 1X8X12	1
42	5324 1658	Bushing- 4x8x4.5mm	1
43	A352 2138	Slide Collar - 0.6x4.5x6	2
44	A096 5440	Drum Unit Harness	1
45	A096 3677	PTL Harness Cover	1
46	AA15 1811	Inner Casing Seal	2
47	AA08 2059	Agitator Bushing	1
		MB11 (ADDED)	
48	AB01 0340	Gear - 32Z	1
		MB11 (ADDED)	
49	AD03 9057	Cleaning Agitator	1
		MB11 (ADDED)	
50	AA15 1925	Cleaning Seal 1	3
		MB15 (ADDED)	
51	AA15 1926	Cleaning Seal 2	2
		MB15 (ADDED)	
52	AA15 1927	Cleaning Seal 3	1
		MB15 (ADDED)	
53	AA15 1928	Cleaning Seal 4	1
		MB15 (ADDED)	
54	A097 3644	Transport Guide Bracket (A097)	1
55	A048 2274	Front Transport Bracket (A097)	1
56	A048 2277	Rear Transport Bracket (A097)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0413 0082B	Tapping Screw - M3x8	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0720 0040B	Retaining Ring - M4	
104	0413 0062B	Tapping Screw - M3x6	
105	0720 0030B	Retaining Ring - M3	
106	0951 3006B	Philips Screw With Flat Washer-M3x6	
107	0960 3005B	Philips Flange Screw - M3 X 5	
108	0951 3005B	Philips Screw With Flat Washer M3x5	
109	0807 3092	Spacer - 4x5x3	

Index No.	Part No.	Description	Q'ty Per Assembly

26. TRANSFER SECTION (A095/A096/A097)



26. TRANSFER SECTION (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 3852	Transfer Belt	1
	A096 3851	x/o MB1	
2	A096 3875	Belt Drive Roller	1
3	A096 3862	Rear Arm	1
4	AA08 0157	Bushing - 8x32x9	1
5	AB01 0333	Gear - 26Z	1
6	A096 3861	Front Arm	1
7	AB01 3807	Gear - 20Z	1
8	A096 3856	Grounding Plate	1
9	A096 3867	Front Bushing - 4.5x6x21	1
10	A096 3863	Spacer - 4x6x1	2
11	G013 4566	Thermistor Spring	1
12	A096 3870	Transfer Bias Roller	1
13	A096 3853	Transfer Belt Frame	1
14	A096 3859	Front Spring Plate	1
15	A096 3864	Transfer Belt Terminal	1
16	A096 3860	Rear Spring Plate	1
17	A096 3868	Rear Bushing - 4.5x6x13.5	1
18	A096 3865	Terminal Cover	1
19	A096 3871	Belt Driven Roller	1
20	A096 3916	Belt Lever Arm	1
21	A096 3915	Transfer Belt Lever	2
22	A096 3911	Transfer Belt Solenoid	1
23	A096 3918	Solenoid Bracket	1
24	A096 5443	Transfer Unit Harness	1
25	AZ30 0036	High Voltage Supply Board - T	1
26	AA06 3489	Spring - 45mm	1
27	A096 3931	Belt Cleaning Blade	1
28	A096 3934	Cleaning Blade Stay	1
29	A096 3906	Rear Casing Guide	1
30	AA15 3376	Brush Seal - 4.5x17x358	1
31	AA15 1902	Belt Exit Seal	1
	AA15 3377	Brush Seal - 7x7.1x358 x/o MB2	
32	A096 3901	Transfer Belt Casing	1
33	AD04 3030	Toner Collection Coil	1
34	A096 3907	Spring Plate	2
35	AB01 0334	Gear - 34Z	1
36	AB01 0335	Gear - 22/48Z	1
37	A096 3935	Transport Guide Holder	1
38	AA06 6239	Cleaning Blade Spring	1
	AA06 6217	x/o MB2	
39	AB01 0336	Gear - 22/36Z	1
40	A096 3929	Gear Cover	1
41	A096 3936	Blade Stay Bushing	1
42	5447 2681	Snap Ring	2
43	AA15 0632	Mylar Seal - 0.05x80x145	1
44	A096 3857	Grounding Terminal	1
101	0720 0040B	Retaining Ring - M4	
102	0951 3008B	Philips Screw With Flat Washer-M3x8	
103	0965 3008B	Tapping Screw With Washer - M3x8	
104	0720 0060B	Retaining Ring - M6	
105	0313 0060B	Philips Pan Head Screw - M3x6	
106	1105 0196	Harness Clamp	
107	0951 3006B	Philips Screw With Flat Washer-M3x6	
108	0965 3006B	Tapping Screw With Washer - M3x6	

27. FUSING UNIT 1 (A095/A096/A097)



27. FUSING UNIT 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 4005	FusingUnit-220/230V (A095/A096)	1
*	A097 4007	FusingUnit-220/230V (A097)	1
*	A096 4003	FusingUnit-115V(A095/A096)	1
*	A097 4009	Fusing Unit- 115V(A097)	1
1	A096 41 55	Rail Cover	1
2	A096 4225	Thermofuse169°C	1
2	A097 4225	Thermofuse169°C - 120V(A097)	1
3	A096 4221	Thermistor	1
4	A096 4121	Fusing Unit Rail	1
5	A096 4151	Fusing Cover	1
6	5216 4145	Thermofuse Decal	1
7	AA17 2012	Heat Shielding Sheet	1
8	A096 4115	Fusing Left Stay	1
9	AX44 0070	Heater - 950W (220/230V) (A095/A096)	1
9	AX45 0014	Heater - 1100W (220/230V) (A097)	1
9	AX44 0069	Heater - 950W (115V) (A095/A096)	1
9	AX43 0021	Heater - 550W(120V) (A097)	2
10	AE01 1020	Hot Roller	1
11	AE02 0037	Pressure Roller	1
12	AA12 0005	Antistatic Brush	1
13	A096 4173	Rear Heater Holder	1
13	A097 4173	Rear Heater Holder - 120V (A097)	1
14	A096 4231	Fusing Connector Bracket	1
15	A096 5420	Fusing Unit Harness	1
15	A097 5420	Fusing Unit Harness - 120V (A097)	1
16	AB01 7357	Gear - 31Z	1
16	AB01 7292	x/o MB8	
17	AE03 0017	Ball Bearing - 35x50x10	2
18	AB01 3792	Gear - 49Z	1
19	AA12 0064	Antistatic Spacer	2
20	AE03 0018	Ball Bearing - 12x28x8	2
21	A096 4105	Rear Fusing Bracket	1
22	A096 4177	Rear Pressure Lever	1
23	A096 4185	Rear Release Bracket	1
24	AA06 0540	Pressure Spring (A095/A096)	2

Index No.	Part No.	Description	Q'ty Per Assembly
24	AA06 0562	Pressure Spring (A097)	2
25	A096 4111	Fusing Right Stay	1
26	A096 4135	Lower Entrance Guide	1
27	A096 4161	Lower Fusing Cover	1
28	A097 4132	Upper Guide Bracket - 115V (A095/A096)	1
28	A096 4141	Upper Guide Bracket (A095/A096 EU,A097 NA)	1
28	A097 4141	Upper Guide Bracket (A097 EU)	1
29	A096 4131	Upper Entrance Guide	1
30	A096 4181	Front Release Bracket	1
31	A096 4175	Front Pressure Lever	1
32	A096 4101	Front Fusing Bracket	1
33	AG05 0066	Fusing Unit Knob	1
34	A413 1670	Antistatic Brush	1
35	A096 4171	Front Heater Holder	1
35	A097 4170	Front Heater Holder - 120V (A097)	1
36	A096 4224	Thermistor Pressuer Plate	1
37	AE03 2014	Bushing - 30x35x13.5	2
37	AE03 2011	o/o MB5	
38	AE04 0006	Oil Supply Roller (A095/A096)	1
38	AE04 0009	Oil Supply Roller (A095/A096 EU,A097)	1
39	AE03 1014	Bushing - Oil Supply Roller	2
40	AA06 3266	Pressure Spring -1KGF (A095/A096 EU,A097 NA)	2
40	AA06 3266	Pressure Spring - 1.8KGF (A097 EU)	2
41	A097 4133	Lock Lever	1
42	5215 4444	Pin	1
43	AA06 6232	Lock Lever Spring MB1 (OBS)	
44	AE04 2005	Fusing Cleaning Roller MB1 (OBS)	
45	A097 4252	Cleaning Roller Bracket MB1 (OBS)	
46	A097 4256	Spring Plate - Cleaning Roller MB1 (OBS)	
47	AE03 0020	Ball Bearing - 4x10x4 MB1 (OBS)	
48	A097 4258	Rear Hinge Bracket MB1 (OBS)	
49	A097 4254	Front Hinge Bracket MB1 (OBS)	
50	A097 4261	Fusing Cleaning Roller (A095/A096) MB1	1
51	AE04 2012	Lower Cleaning Roller (A097)	1

Index No.	Part No.	Description	Q'ty Per Assembly
52	AA08 2063	Bushing - 8x10X5 (A097)	1
53	A097 4122	Cleaning Roller Bracket (A097)	1
54	A097 4126	Left Holder (A097)	1
55	A097 4129	Right Holder (A097)	1
56	AE03 1018	Bushing - 4x6x10 (A095/A096 EU,A097)	2
57	AE04 2007	Upper Cleaning Roller (A095/A096 EU,A097)	1
58	A096 4142	Spring Plate (A095/A096 EU,A097 NA)	2
58	A097 4142	Spring Plate (A097 EU)	2
59	A097 4143	Cleaning Roller Blade (A097 EU)	1
60	A096 4080	Oil Supply Unit (A095/A096 EU,A097 NA)	1
60	A097 4080	Oil Supply Unit (A097 EU)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0314 0080B	Philips Pan Head Screw - M4x8	
104	0725 0300E	Retaining Ring C - M30	
105	0313 0050B	Philips Pan Head Screw - M3x5	
106	0951 4008W	Philips Screw With Flat Washer-M4x8	
107	0807 5056	Washer -8.1 mm	
108	0720 0060B	Retaining Ring - M6	
109	0950 3005M	Philips Screw With Lock Washer M3x5	
110	0313 0080B	Philips Pan Head Screw - M3x8	
111	1101 0473	Connector - 3P	
112	0314 0100B	Philips Pan Head Screw - M4x10	

28. FUSING UNIT 2 (A095/A096/A097)





28. FUSING UNIT 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 4041	Fusing Exit Unit	1
1	A096 4301	Fusing Exit Cover	1
2	G619 4028	Slider Pressure Spring	2
3	A096 4304	Grip Spring Plate	1
4	AB01 3793	Gear - 19Z	1
5	AB01 3794	Gear - 19Z	1
6	AA08 0184	Bushing - Fusing Unit	2
	5424 4142	Bushing - Cleaning Roller o/o MB5	
7	A096 4303	Fusing Exit Grip	1
8	AF02 0302	Lower Fusing Exit Roller	1
9	AA06 0539	Stripper Pawl Spring	5
10	5506 6111	Stepped Screw - M4	2
11	A096 4316	Stripper Release Slider	1
12	AA02 1026	Magnet Catch	1
13	A096 4313	Stripper Stay	1
14	A096 9500	Hot Roller Stripper 5pcs/set	1
15	AA13 2024	Spacer - M6	1
16	A096 4319	Exit Roller Holder	2
17	AF02 1016	Lower Fusing Exit Roller	2
18	A096 4322	Upper Fusing Exit Guide	1
19	A096 4309	Lower Fusing Exit Guide	1
20	AA14 3037	Development Cover Screw	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0414 0082W	Tapping Screw With Flat Washer-M4x8	
104	0951 4006B	Philips Screw With Washer - M4x6	
105	0960 4008W	Philips Flange Screw - M4x8	

29. INVERTER SECTION 1 (A095/A096/A097)



29. INVERTER SECTION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AF02 2073	Exit Driven Roller	2
2	AA08 0034	Bushing - 4x5x7	4
3	5205 4527	Spring - Exit	4
4	A316 4513	Lower Exit Sensor Bracket	1
5	AW02 0057	Paper Exit Sensor	1
6	5206 2808	Antistatic Brush - Duplex Transport	1
7	A096 4423	Upper Exit Guide	1
8	A096 4487	Upper Exit Guide	1
9	AA06 6229	Left Guide Spring	1
10	AA06 6230	Right Guide Spring	1
11	A096 4472	Junction Gate	1
12	AF02 0303	Exit Transport Roller	1
13	AW02 0060	Entrance Exit Sensor	1
14	A096 4477	Lower Exit Guide	1
15	AW02 0064	Duplex Entrance Sensor	1
16	A096 4488	Entrance Sensor Bracket	1
17	AA08 2046	Bushing - 6x12x6	2
18	AB01 9474	Gear - 20Z	1
19	A096 4473	Junction Gate Solenoid	1
20	5413 1812	Spring - Drum Return Arm	1
21	AA14 3020	Stepped Screw - M4	2
22	A096 4495	Inverter Guide Lever	1
23	AA00 1331	Decal - E2	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0414 0082W	Tapping Screw With Flat Washer-M4x8	
103	0434 0080B	Philips Tapping Screw - M4x8	
104	0720 0030B	Retaining Ring - M3	
105	0434 0060B	Philips Tapping Screw - M4x6	
106	1105 0283	Clamp	
107	0805 3384	Bushing - 5mm	

30. INVERTER SECTION 2 (A095/A096/A097)



30. INVERTER SECTION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 4468	Exit Sensor Bracket	1
2	AW02 0008	Photointerrupter	1
3	A096 5422	Exit Sensor Harness	1
4	A096 4417	Exit Cover	1
5	AF04 0048	Exit Drive Roller	1
6	AF02 0291	2nd Inverter Drive Roller	1
7	A096 4461	3rd Inverter Drive Roller (A095/A096)	1
7	A097 4461	3rd Inverter Drive Roller (A097)	1
8	A096 4457	Outer Inverter Guide	1
9	A096 4406	Rear Exit Bracket	1
10	AA04 3229	Timing Belt - 302P2M	1
11	AB01 7293	Pulley Gear - 27/29Z	1
12	AB03 0392	Pulley - 18Z	2
13	AB01 7294	Pulley Gear - 18/20Z	1
14	AB01 3795	Gear - 38Z	1
15	AB01 3796	Gear - 38Z	1
16	5360 1711	Pressure Spring	1
17	AB03 0395	Idle Pulley	1
18	A096 4427	Pulley Tightener	1
19	AA14 3074	Stepped Screw - M4x5	2
20	AA12 0065	Antistatic Brush - Duplex	1
21	A096 4453	Upper Inverter Guide	1
22	AA16 2056	Pad - 7x12x22	1
23	A096 4434	Inner Inverter Guide	1
24	AF02 2065	2nd Inverter Driven Roller	1
25	5205 4527	Spring - Exit	2
26	AA08 0034	Bushing - 4x5x7	2
27	A096 4446	Sensor Feeler	1
28	A096 4441	Inverter Weight	1
29	AF02 2066	Transport Driven Roller	3
30	A096 4408	Front Exit Bracket	1
31	AA08 2046	Bushing - 6x12x6	6
32	A096 5421	Exit Unit Harness	1
33	AA02 0001	Drawer Tray Magnet	2
34	AA16 1070	Cushion - 5x6.5x12	1
35	AA15 1877	Outer Inverter Guide Seal	1
101	0720 0040B	Retaining Ring - M4	
102	0434 0080B	Philips Tapping Screw - M4x8	
103	1105 0278	Harness Clamp	
104	0720 0025B	Retaining Ring - M2.5	
105	0720 0030B	Retaining Ring - M3	
106	0434 0060B	Philips Tapping Screw - M4x6	
107	1105 0283	Clamp	
108	0720 0060B	Retaining Ring - M6	

31. DUPLEX UNIT 1 (A095/A096/A097)



31. DUPLEX UNIT 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
*	A096 4501	Duplex Unit (A095/A096)	1
*	A097 4502	Duplex Unit (A097)	1
1	A096 4884	Duplex Release Lever	1
2	A096 4882	Release Bracket	1
3	A096 4883	Duplex Lock Lever	1
4	AA06 6223	Grip Spring	1
5	A096 4912	Duplex Inner Cover	1
6	AA14 0504	Release Lever Shaft	1
7	A096 4649	Paper End Feeler (A095/A096)	1
8	A096 4650	Pressure Plate	1
9	A096 4646	Pressure Plate Arm	1
10	A096 4742	Front Jogger Fence	1
11	A096 4750	Front Paper Flatenner	1
12	5206 2686	Snap Ring	1
13	A096 4897	Harness Cover	1
14	AW02 0056	Photointerrupter - EE-SX4235A-P1 (A095/A096)	1
15	A469 2123	Rubber Cushion - 1x10x10mm	1
16	A096 4611	Feed Roller Stay	1
17	A096 4760	Rear Jogger Fence	1
18	A096 4622	Feed Roller Arm (A095/A096)	1
18	A097 4622	Feed Roller Arm (A097)	1
19	A096 4876	Front Support Bracket	1
20	AA04 2008	Pick-Up Belt	1
21	A096 4630	Feed Roller Shaft	1
22	A096 4765	Rear Paper Flatenner	1
23	AF03 1001	Duplex Positioning Roller	1
24	5447 2681	Snap Ring	2
25	AB03 3052	Pick-Up V Pulley	1
26	5053 0447	Bushing - 6mm	3
27	AB01 7298	Gear - 21/55Z	1
28	AB01 3802	Gear - 30Z	1
29	AB01 7297	Gear - 21/32z	1
30	A096 4673	Pressure Plate Solenoid	1
31	A096 4665	Release Lever - Pressure Plate	1
32	AA06 0537	Release Spring - Pressure Plate	1
33	A096 5432	Duplex Relay Harness (A095/A096)	1
34	AA06 0536	Release Spring - Feed Roller	1
35	A096 4666	Release Lever - Feed Roller	1
36	A096 4658	Feed Roller Solenoid	1
37	A096 4657	Solenoid Bracket	1
38	A096 4674	Solenoid Bracket	1
39	A096 4745	Front Jogger Fence Guide	1
40	GB01 3035	Gear - 28Z	2
41	AB01 0089	Gear - 35Z	1
42	AB01 3569	Gear - 20Z	1
101	0344 0060W	Philips Truss Head Screw - M4x6	
102	0313 0040B	Philips Pan Head Screw - M3x4	
103	0434 0060B	Philips Tapping Screw - M4x6	
104	0720 0040B	Retaining Ring - M4	
105	0720 0060B	Retaining Ring - M6	
106	0802 5094	Tapping Truss Head Screw - M4x8	
107	0720 0030B	Retaining Ring - M3	
108	0434 0080B	Philips Tapping Screw - M4x8	
109	0965 3008B	Tapping Screw With Washer - M3x8	
110	0323 0050B	Screw - M3x5	
111	1105 0278	Harness Clamp	
112	0701 0030B	Flate Washer - M3	

32. DUPLEX UNIT 2 (A095/A096/A097)



32. DUPLEX UNIT 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H006 1091	Pin - Contact Point - Front	2
2	A096 4844	Release Lever	1
3	A096 4849	Rear Turn Guide (A095/A096)	1
3	A097 4849	Rear Turn Guide (A097)	1
4	A096 4836	Separation Belt Stay	1
5	AA06 0469	Lock Spring	1
6	A096 4840	Hook	2
7	AA06 6222	Hook Spring	2
8	A096 4848	Front Turn Guide (A095/A096)	1
8	A097 4848	Front Turn Guide (A097)	1
9	AF02 0297	Friction Belt Roller	1
10	AA06 0581	Spring - 18.8mm	3
	AA06 0276	Spring x/o MB1	
11	A096 4865	Friction Belt Lever	3
12	A499 1135	Tension Roller	3
13	AA14 5201	Friction Belt Shaft	1
14	A096 4861	Friction Belt Bracket	1
15	A096 4867	Separation Entrance Guide	1
16	5447 2681	Snap Ring	6
17	A096 9501	Duplex Friction Belt - 3pcs/set	1
18	A096 4935	Transport Guide Holder	2
19	A096 4810	Inner Separation Guide	1
20	A096 4731	Jogger Table	1
21	AW02 0059	Duplex Paper Sensor	1
22	A096 4732	Right Sensor Bracket	1
23	A096 4733	Sensor Harness Bracket	1
24	A096 4819	Lower Turn Guide	1
25	A096 5430	Duplex Unit Harness (A095/A096)	1
25	A097 7630	Duplex Unit Harness (A097)	1
26	A096 4894	Duplex Harness Bracket	1
27	AA02 1025	Magnet Catch	1
28	A096 4923	Right Spring Plate	3
29	A096 4927	Lower Transport Guide	1
30	AF02 2066	Transport Driven Roller	6
31	AF02 2067	Guide Stopper Roller	2

Index No.	Part No.	Description	Q'ty Per Assembly
32	A096 4924	Guide Plate Stopper	2
33	A096 4928	Guide Plate Band	1
34	5206 4478	Spring - Driven Roller	4
35	AA06 3378	Driven Roller Spring	4
36	AF02 0301	Guide Driven Roller	1
37	A096 4929	Guide Plate Lever	1
38	A096 4933	Guide Plate Lever Hook	1
40	A096 4937	Driven Roller Guide	3
41	A096 4925	Driven Roller Holder	2
42	A096 4926	Roller Holder Bracket	1
43	AA08 3003	Bushing - 6x18x5mm	1
44	AA14 3183	Stepped Screw	2
45	AA14 3307	Stepped Screw - M3x4	2
46	AA00 1324	Decal - Duplex Lever	1
47	AA15 0357	Seal - 31x35	1
48	AA13 2171	Spacer - 6x20x1	2
49	5053 0447	Bushing - 6mm	1
50	A097 4735	Harness Cover (A097)	1
51	A097 7631	Duplex Relay Harness (A097)	1
52	AW01 0050	Paper End Sensor (A097)	1
101	0965 4008B	Tapping Screw - M4x8	
102	0414 0082B	Binding Self Tapping Screw - M4x8	
103	0805 0083	Retaining Ring - M4	
104	0720 0040B	Retaining Ring - M4	
105	0434 0082B	Tapping Screw - M4x8	
106	0314 0080B	Philips Pan Head Screw - M4x8	
107	0434 0080B	Philips Tapping Screw - M4x8	
108	0434 0060B	Philips Tapping Screw - M4x6	
109	1102 6246	Connector - 3P	
110	0313 0080B	Philips Pan Head Screw - M3x8	
111	0413 0082B	Tapping Screw - M3x8	
112	0964 4008B	Tapping Screw With Flat Washer-M4x8	
113	1105 0278	Harness Clamp	
114	0720 0050B	Retaining Ring - M5	

33. DUPLEX UNIT 3 (A095/A096/A097)



33. DUPLEX UNIT 3 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5215 2621	Snap Ring - M6	1
2	AA08 3005	Roller Clutch - 8x18x11	1
3	AF03 2024	Separation Roller- Duplex	1
4	AA14 0503	Separation Roller Shaft	1
5	AF02 0296	Pick-up Roller	1
6	AF02 0293	Transport Drive Roller - Grip	1
7	AW02 0059	Duplex Paper Sensor	1
8	A096 4941	Upper Transport Guide	1
9	5206 2876	Spring - Wire	1
10	A096 4718	Wire Fixing Plate	2
11	A096 4715	Jogger Support Bracket	2
12	A096 4705	Lower Jogger Stay	1
13	A096 4711	Jogger Guide	2
14	AF02 0294	Transport Drive Roller	3
15	A096 4891	Lever Exit Guide	1
16	A060 2633	Guide Plate Holder	1
17	AX20 0092	Magnetic Clutch - Separation	1
18	A096 4896	Rear Left Harness Bracket	1
19	AB01 7291	Gear - 36Z	1
20	AX20 0091	Magnetic Clutch - Transport	1
21	5053 0223	Bushing - 8mm	5
22	5887 4162	Screw - Driven Guide Plate	2
23	AW02 0056	Photointerrupter - EE-SX4235A-P1	1
24	5053 0447	Bushing - 6mm	6
25	A096 4805	Gear Bracket	1
26	AB03 0429	Timing Pulley - 22Z	1
27	AB03 0430	Pulley - 16Z	3
28	AB03 0428	Timing Pulley - 20Z	3
29	AA04 3228	Timing Belt - 710P2M6	1
30	AA06 0328	Pressure Spring	1
31	A096 4901	Transport Tightener	1
32	AB03 0431	Transport Pulley	2
33	A096 4693	Jogger Motor bracket	1
34	AB03 2031	Jogger Pulley	1
35	AX05 0061	Jogger Motor - DC 6.5W	1
36	AB03 2030	Pulley	1
37	A096 4936	Guide Positioning Plate	1
38	A096 4595	Duplex Guide	2
39	A469 2123	Rubber Cushion - 1x10X10mm	2
40	AA05 0058	Jogger Drive Wire	1
41	AB01 3467	Gear - 30Z	1
42	AA14 3074	Stepped Screw - M4x5	2
43	GB01 3035	Gear - 28Z	1
101	0434 0080B	Philips Tapping Screw - M4x8	
102	0720 0040B	Retaining Ring - M4	
103	0951 4008B	Philips Screw With Washer - M4x8	
104	1102 6249	Connector - 6P	
105	1102 6245	Connector - 2P	
106	1105 0278	Harness Clamp	
107	0313 0050B	Philips Pan Head Screw - M3x5	
108	0574 0050E	Hexagon Headless Set Screw - M4x5	
109	0720 0060B	Retaining Ring - M6	
110	1102 6246	Connector - 3P	
111	0805 3291	Ball Bearing - 8x16x5mm	

34. DRIVE SECTION 1 (A095/A096/A097)



34. DRIVE SECTION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 5305	Development Drive Motor - DC 4.1 W (A095/A096)	1
1	A097 5305	Development Drive Unit (A097)	1
2	A096 5307	Paper Feed Motor - DC 10.7/8.22W	1
3	AB01 1131	Gear - 48Z	1
4	A096 1165	Fusing Drive Bracket	1
5	A096 1155	Duplex Drive Bracket	1
6	AB03 0427	Pulley - 81Z	2
7	AA14 5213	Duplex Drive Shaft	1
8	AA06 3490	Spring -21.6mm	2
9	AB01 7290	Joint Gear - 31Z	1
10	AD04 3031	Toner Collection Coil	1
11	A096 3688	Rear Collection Casing	1
12	A096 3681	Front Collection Casing	1
13	AA15 1814	Joint Seal - 21x32x10	1
14	AB03 0416	Timing Pulley - 40Z	1
15	A096 1173	Fusing Drive Joint	1
	A096 1169	x/o MB8	
16	AA14 5214	Fusing Drive Shaft	1
17	A096 3697	Ratch	1
18	AA04 3346	Timing Belt - 560P2M6	1
19	A096 5306	Brushless Motor -DC 16W (A095/A096)	1
19	A097 5306	Brushless Motor -DC 24V 29.6W (A097)	1
20	A096 1172	Tightener	1
	A096 1170	x/o MB2	
21	AA16 1014	Cushion Motor	3
22	AA06 0244	Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0060B	Philips Tapping Screw - M4x6	
102	0434 0080B	Philips Tapping Screw - M4x8	
103	0720 0060B	Retaining Ring - M6	
104	0964 4008B	Tapping Screw With Flat Washer-M4x8	
105	0623 0140E	Spring Pin - 3x14mm	
106	0414 0082B	Binding Self Tapping Screw - M4x8	
107	0951 4010B	Philips Screw With Washer - M4x10	
108	0707 4050	Bushing - 4x5	
109	0960 4006B	Philips Flange Screw - M4x6	
110	0720 0040B	Retaining Ring - M4	

35. DRIVE SECTION 2 (A095/A096/A097)



35. DRIVE SECTION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 2341	Drum Grounding Plate	1
2	A096 2342	Grounding Plate Cover	1
3	A096 2317	Bearing Grounding Plate	1
4	A096 2314	Drum Shaft Stay	1
5	AB03 0415	Pulley - 25Z	1
6	A096 2316	Drum Pulley - 125Z	1
7	A096 2311	Drum Shaft	1
8	AA14 5204	Cleaning Drive Shaft	1
9	AB01 3772	Gear - 20Z	1
10	AA14 5205	Cleaning Relay Shaft	1
11	AA06 3490	Spring -21.6mm	1
12	AA13 2024	Spacer - M6	1
13	AB01 7287	Joint Gear - 16Z	1
14	A096 1128	Registration Drive Bracket	1
15	A096 1143	Drive Support Bracket	1
16	A096 1115	Tightener	1
17	AA04 3223	Timing Belt - 426P2M4	1
18	AA04 3222	Timing Belt - 525P3M6	1
19	AB03 2716	Idle Pulley - MI 8	2
20	AA16 1014	Cushion Motor	4
21	A096 1112	Main Motor Bracket	1
22	AB03 3048	Timing Pulley - 31/32Z	1
23	AX06 0072	Main Motor - DC 21 W (A095/A096)	1
23	AX06 0095	Main Motor - DC 24V 27W (A097)	1
24	A096 1123	Belt Drive Bracket	1
25	A096 1133	Timing Belt Bracket	1
26	A096 1136	Tightener	1
27	AA06 6220	Tension Spring - 0.3	1
28	A096 1146	Tightener Lever	1
29	AA06 0532	Tension Spring - 24.5mm	1
30	AA06 0543	Tension Spring - 34.4mm	1
31	AA04 3224	Timing Belt -310P2M3	1
32	AB03 0414	Pulley - 25Z	1
33	AA14 5203	Registration Drive Shaft	1
34	AB01 3771	Gear - 32Z	1
35	AB01 3770	Gear - 24Z	1
36	A096 1125	Belt Drive Shaft	1
37	AB03 0458	Pulley - 28Z	1
38	A096 1149	Support Plate - Cleaning Drive	1
101	0414 0082B	Binding Self Tapping Screw - M4x8	
102	0413 0062W	Tapping Screw - M3x6	
103	0964 4012B	Tapping Screw With Flat Washer-M4	
104	0574 0050E	Hexagon Headless Set Screw - M4x5	
105	0720 0060B	Retaining Ring - M6	
106	0633 0160E	Pin - 3x16mm	
107	0720 0040B	Retaining Ring - M4	
108	0964 4008B	Tapping Screw With Flat Washer-M4x8	
109	0434 0080B	Philips Tapping Screw - M4x8	
110	0707 4050	Bushing - 4x5	
111	0951 4010B	Philips Screw With Washer - M4x10	
112	0573 0050E	Hexagon Headless Set Screw - M3x5 MB3 (ADDED)	

36. DRIVE SECTION 3 (A095/A096/A097)



36. DRIVE SECTION 3 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5053 0709	Bushing - 6x10x6mm	1
2	AA13 2024	Spacer - M6	1
3	AA06 3375	Spring - 24.3mm	1
4	AB01 1129	Gear - 45Z	1
5	A096 3729	Toner Collection Joint	1
6	AD04 3032	Toner Collection Coil	1
7	A096 3722	Toner Collection Bracket	1
8	AB01 7289	Gear - 17/45Z	1
9	A096 3752	Shutter Plate	1
10	AA06 0525	Tension Spring - 43MM	1
11	A096 6188	Upper Tightener - P/B	1
12	A423 4432	Shoulder Screw - M2.5	1
13	A423 4433	Spring	1
14	AW02 0056	Photointerrupter - EE-SX4235A-P1	1
15	A096 3742	Sensor Bracket	1
16	AW50 0012	Push Switch	1
17	A096 3763	Push Switch Bracket	1
18	A096 5330	Toner Collection Motor - DC 12W	1
19	AB03 0391	Timing Pulley - 22Z	4
20	A096 5517	Angle - DC PSU Board	1
21	AB03 2716	Idle Pulley - M18	3
22	A096 6186	Lower Tightener - P/B	1
23	AA06 0524	Tension Spring - 24.8mm	1
24	AA16 1014	Cushion Motor	4
25	AA04 3344	Timing Belt - P3M675	2
26	AA14 5212	Upper Drive Shaft - P/F	2
27	A096 6198	Paper Feed Drive Shaft	2
28	AB01 3781	Gear - 30Z	4
29	A096 5308	Bank Drive Motor - DC 23.5W	1
30	A096 3715	Tank Cover	1
31	A096 5414	Toner Collection Harness	1
32	A095 5413	Motor Control Harness (A095)	1
32	A096 5413	Motor Control Harness (A096)	1
33	A096 3736	Steel Ball - M11	1
		MB4 (ADDED)	

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	0960 4006B	Philips Flange Screw - M4x6	
103	0434 0080B	Philips Tapping Screw - M4x8	
104	0314 0060B	Philips Pan Head Screw - M4x6	
105	1204 2363	Microswitch - AH735454N	
106	1102 6250	Connector - 7P	
107	1102 6248	Connector - 5P	
108	0720 0060B	Retaining Ring - M6	
109	0707 4050	Bushing - 4x5	
110	0960 4012B	Philips Flange Screw - M4 X 12	
111	0742 3808	Ball Bearing - 8x16x5	

37. DRIVE SECTION 4 (A095/A096/A097)



37. DRIVE SECTION 4 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 6171	Sensor Support Plate	1
2	A096 6172	Volume Sensor Bracket	1
3	AW02 0056	Photointerrupter - EE-SX4235A-P1	2
4	A096 6168	Lift Motor Bracket	3
5	AX04 0063	Tray Lift Motor -DC 3.6W	3
6	AA06 3167	Pressure Spring	3
7	A096 6169	Lift Motor Joint	3
8	A096 6177	Paper Size Bracket	1
9	AW50 0010	Push Switch	1
10	AA16 1096	Stopper Cushion	2
11	A096 6164	Push Switch Bracket	2
12	AW50 0012	Push Switch	2
13	A096 6174	Paper Tray Stopper	2
14	A096 5416	Paper Size Harness	1
15	A096 5415	Tray Set Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0080B	Philips Tapping Screw - M4x8	
102	0965 4010B	Tapping Screw - M4 X 10	
103	0727 0080	C-ring - M8	
104	1102 6249	Connector - 6P	
105	0951 3008B	Philips Screw With Flat Washer-M3x8	

38. DRIVE SECTION 5 (A095/A096/A097)



38. DRIVE SECTION 5 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 6687	Lock Solenoid Arm (A096/A097)	1
3	A096 6681	Lock Solenoid Bracket (A096/A097)	1
4	AA06 0535	Lock Solenoid Spring (A096/A097)	1
5	A096 6683	Tray Lock Solenoid (A096/A097)	1
6	A096 6691	Sensor Bracket (A096/A097)	1
7	AW02 0056	Photointerrupter - EE-SX4235A-P1 (A096/A097)	3
8	A096 6169	Lift Motor Joint (A096/A097)	3
9	AA06 3167	Pressure Spring (A096/A097)	3
10	A096 6170	Support Side Plate (A096/A097)	1
11	AX04 0063	Tray Lift Motor - DC 3.6W (A096/A097)	3
12	A096 6168	Lift Motor Bracket (A096/A097)	2
13	A096 6689	Right Connector Bracket (A096/A097)	1
14	A096 5417	Tandem Tray Harness (A096/A097)	1
15	A096 6690	Left Connector Bracket (A096/A097)	1
16	A096 6177	Paper Size Bracket (A096/A097)	1
17	AW50 0010	Push Switch (A096/A097)	1
18	AA16 1096	Stopper Cushion (A096/A097)	1
19	A096 6174	Paper Tray Stopper (A096/A097)	1
20	A096 6164	Push Switch Bracket (A096/A097)	1
21	AW50 0012	Push Switch (A096/A097)	1
22	A096 5415	Tray Set Harness (A096/A097)	1
23	A096 6274	Middle Rail 1	2
24	A096 6273	Middle Rail Stay	1
25	A096 6271	Middle Stay 1	1
26	A096 6277	Middle Slide Rail 2	1
27	A096 6276	Middle Stay 2	1
28	A096 6270	Tandem Tray Stay	1
29	A096 6278	Middle Rail Stopper	1
30	A096 6101	Upper Heat Sink	1
31	AX40 0022	Anti-condensation Heater - 240V 18W	1
31	AX40 0021	Anti-condensation Heater-115V 18W	1
32	AA06 3268	Connector Spring	4
33	A096 5463	Anticondensation Heater Harness 2	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0040B	Retaining Ring - M4	
102	1102 6245	Connector - 2P	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0727 0080	C-ring - M8	
105	0434 0080B	Philips Tapping Screw - M4x8	
106	0965 4010B	Tapping Screw - M4 X 10	
107	0803 0058	Stepped Screw	
108	0950 4008M	Screw - M4x8	
109	1105 0291	Wire Saddle	
110	0434 0060B	Philips Tapping Screw - M4x6	
111	0313 0050B	Philips Pan Head Screw - M3x5	

39. ELECTRICAL SECTION 1 (A095/A096/A097)



39. ELECTRICAL SECTION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 5140	Optics Control Board (A095/A096)	1
1	A097 5140	Optics Control Board (A097)	1
2	A096 5509	Upper Support Plate	1
3	A096 1949	Optics Board Bracket	1
4	A096 1947	Optics Board Hinge	1
5	A096 2089	Vacuum Duct Bracket	1
6	A096 2088	Vacuum Duct Bracket	1
7	A096 2083	Middle Duct	1
8	AA15 1770	Middle Duct Seal	1
9	A096 5130	High Voltage Control Board	1
10	A095 5112	Main Control Board - 115V (A095)	1
	A095 5110	x/o MB12	
10	A095 5117	Main Control Board - 230V (A095)	1
	A095 5115	x/o MB12	
10	A096 5117	Main Control Board - 115/230V(A096 EU/A097)	1
	A096 5115	x/o MB12	
10	A096 5112	Main Control Board - 115V (A096)	1
	A096 5110	x/o MB12	
11	A096 5125	RAM Board	1
12	A096 5501	Main Board Bracket	1
13	A096 2110	Ozone Fan Motor	1
14	A096 2101	Rear Duct Bracket	1
15	AA15 1774	Rear Duct Seal	1
16	A096 2097	Rear Duct	1
17	A096 2109	Exhaust Duct Bracket	1
18	A096 2100	Exhaust Duct	1
19	A069 5352	Harness - Ground Wire - Scanner	1
20	A096 7580	AC Drive Board - 230V	1
20	A096 5175	AC Drive Board - 115V	1
21	A096 5516	AC Drive Board Bracket	1
22	A096 5121	IC - AM27C020-150DC	1
23	A096 5123	IC - AM27C512-120DC	1
24	A028 3146	Paper Feed Guide Spacer	1
25	AA15 1771	Seal - 5x10x138	1
26	A097 5540	Fan Motor Bracket (A097)	1
27	AX64 0049	Fan Motor - DC24V 2.4W (A097)	1
28	A097 5541	Filter Bracket (A097)	1
29	AA01 2075	Filter (A097)	1
30	AX64 0045	Fan Motor - DC24V 1.68W (A097)	1
101	0434 0080B	Philips Tapping Screw - M4x8	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	1105 0192	Locking Support	
104	0314 0080B	Philips Pan Head Screw - M4x8	
105	0951 4008B	Philips Screw With Washer - M4x8	
106	0414 0082B	Binding Self Tapping Screw - M4x8	
107	0434 0060W	Tapping Screw - M4x6	
108	1105 0292	Wire Saddle	
109	1105 0087	Clamp	
110	1105 0367	Spacer	
111	1105 0378	Clamp	
112	0314 0300B	Philips Pan Head Screw - M4x30	
113	0314 0140B	Philips Pan Head Screw - M4x14	

40. ELECTRICAL SECTION 2 (A095/A096/A097)



40. ELECTRICAL SECTION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 5515	Board Bracket - Paper Feed	1
2	A095 5185	Paper Feed Board (A095)	1
2	A096 7450	Paper Feed Board (A096/A097)	1
3	A096 5410	Paper Feed Control Harness (A095)	1
3	A096 7630	LCT Harness (A096/A097)	1
4	A096 1365	Upper Cover Bracket	3
5	A096 1366	Lower Cover Bracket	2
6	AZ24 0021	DC Power Supply Unit - 220/230V (A095/A096)	1
6	AZ24 0024	DC Power Supply Unit - 220/230V (A097)	1
6	AZ24 0019	DC Power Supply Unit - 115V (A095/A096)	1
6	AZ24 0023	DC Power Supply Unit - 115V (A097)	1
7	A096 7500	Lightning Arrester Board - 220/230V	1
7	A096 5195	Lightning Arrester Board - 115V	1
8	A096 7601	Power Supply Cord - 220/230V	1
8	A096 7600	Power Supply Cord - 115V	1
9	A096 7662	Circuit Breaker Bracket - 220/230V	1
9	A096 5511	Circuit Breaker Bracket - 115V	1
10	A096 5510	Power Supply Bracket	1
11	A096 5462	Circuit Breaker Harness	1
12	A096 7661	Bracket - Power Supply Cord	1
13	A096 5461	Noise Filter Harness	1
14	A096 7605	Paper Bank AC Harness - 220/230V	1
14	A096 5460	Paper Bank AC Harness - 115V	1
15	A096 7631	LCT Relay Harness	1
16	A096 6815	Harness Bracket	1
17	AA06 3259	Connector Spring	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0367	Spacer	
102	1105 0192	Locking Support	
103	0434 0080B	Philips Tapping Screw - M4x8	
104	1105 0310	Wire Clamp	
105	1105 0291	Wire Saddle	
106	1107 0693	Circuit Breaker - 18A 250V	
107	1602 7068	Noise Filter - VC-210FA(220/230V)(A095/A096)	
107	1602 0946	Noise Filter - VC-210FA(220/230V)(A097)	
107	1602 0897	Noise Filter (115V)	
108	0964 4008B	Tapping Screw With Flat Washer-M4x8	
109	1107 0785	Fuse - 125V 10A (115V)	
110	1107 0391	Fuse - 5A 125V (115V)	
111	1107 0392	Fuse - 6.3A (115V)	
112	1107 0752	Fuse - 5A 250V (230V)	
113	1107 0753	Fuse - 6.3A 250V (230V)	
114	0803 0058	Stepped Screw	
115	1107 0794	Fuse - 6.3A 250V (115V) (A097)	

41. ELECTRICAL SECTION 3 (A095/A096/A097)



41. ELECTRICAL SECTION 3 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 4493	Release Arm Bracket	1
2	AA06 6224	Arm Release Spring	1
3	A096 4492	Lever Release Arm	1
4	A096 4497	Front Exit Unit Bracket	1
5	A096 1380	Left Support Bracket	1
6	A096 1330	Main Switch Bracket	1
7	A096 1336	Hinge Plate - Lower Left	1
8	A096 1289	Right Support Bracket	1
9	A096 1354	Hinge Plate - Upper Right	1
10	A096 1355	Hinge Shaft	1
11	A096 7660	Total Counter Bracket	1
12	AX31 0018	Total Counter	1
13	A096 7634	Total Counter Harness	1
14	A096 5406	Upper Switch Harness	1
15	A096 5530	Upper Switch Bracket	1
16	A096 5533	Upper Switch Arm	1
17	A096 5532	Upper Switch Lever	1
18	A096 3966	Belt Unit Support Plate	1
19	A096 2320	Drum Stay	1
20	A096 2325	Drum Stay Sleeve	1
21	A053 2135	Development Unit Holder	1
22	A096 2330	Drum Shaft Knob	1
23	A096 5450	AC Harness	1
24	AA06 3052	Turret Spring	1
25	5442 1659	Stepped Screw - M4	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0080B	Philips Tapping Screw - M4x8	
102	0720 0030B	Retaining Ring - M3	
103	0802 5094	Tapping Truss Head Screw - M4x8	
104	0434 0080W	Tapping Screw - M4x8	
105	1204 1545	Main Switch	
106	1105 0328	Harness Clamp - ES-0505	
107	1102 6247	Connector - 4P	
108	1105 0009	Nylon Clip - 5N	
109	0720 0040B	Retaining Ring - M4	
110	1204 2277	Push Switch	
111	0413 0062W	Tapping Screw - M3x6	
112	0314 0060W	Philips Pan Head Screw - M4x6	
113	0314 0140W	Philips Pan Head Screw - M4x14	

42. ELECTRICAL SECTION 4 (A095/A096/A097)



42. ELECTRICAL SECTION 4 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 7636	DF Harness - 115V	1
1	A096 5404	DF Harness - 230V	1
2	A096 5525	DF Connector Bracket	1
3	A096 5505	Right Hnge - Main Board	1
4	A096 5507	Left Angle - Main Board	1
5	A096 5506	Left Hinge - Main Board	1
6	A096 5521	AC Harness Bracket	1
7	A096 5519	Relay Bracket	1
8	A096 5524	Option Connector Bracket	1
9	AA08 4043	Rear Development Unit Holder	1
10	A096 5520	Connector Support Plate	1
11	A096 5522	Connector Bracket - DC PSU	1
12	A096 5523	Connector Bracket	1
13	A096 5508	Right Angle - Main Board	1
14	A095 5400	DC Main Harness (A095)	1
14	A096 5400	DC Main Harness (A096)	1
14	A097 5400	DC Main Harness (A097)	1
15	A096 7606	Fusing Harness - 230V	1
15	A096 5452	Fusing Harness - 115V	1
16	5446 5832	Connector Guide Pin	2
17	AA06 3068	Spring Connector	6
18	A096 5441	Drum Unit Harness	1
19	A096 5450	AC Harness	1
20	AW03 0029	Fiber Cable - 800	1
21	A096 5446	Development Bias Cable	1
22	AW03 0030	Fiber Cable - 400	1
23	A096 7635	Main Relay Harness - 115/230V	1
	A096 5451	o/o MB23	
24	A096 5431	Duplex Extension Harness	1
25	AA00 0149	Decal - Fuse - 115V	1
26	A096 5518	Harness Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0434 0080B	Philips Tapping Screw - M4x8	
102	1105 0316	Clamp	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0313 0120W	Philips Pan Head Screw - M3x12	
105	0313 0060B	Philips Pan Head Screw - M3x6	
106	1102 6418	Fiber Cable - CA1002	
107	1105 0291	Wire Saddle	
108	1104 0224	Relay Bracket	
109	1208 0479	Power Relay - DC24V	
110	1102 6254	Connector - 11P	
111	1102 6256	Connector - 13P	
112	1102 6268	Connector - Red 11P	

43. FRAME SECTION 1 (A095/A096/A097)



43. FRAME SECTION 1 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 1078	Left Fixing Plate	1
2	A096 1075	Base Cover	1
3	A096 1076	Lower Fixing Plate	1
4	A096 1293	Middle Support Bracket	1
5	A096 1077	Right Fixing Plate	1
6	A096 1095	Front Grip Bracket	2
7	A096 1094	Grip Base	4
8	A096 1072	Upper Middle Stay	1
9	A096 1096	Rear Grip Bracket	2
10	A096 6076	Upper Rear Fixing Plate	1
11	5446 2560	Cushion - Paper Tray	1
12	A096 6075	Lower Rear Fixing Plate	1
13	A096 6079	Right Rear Frame Joint	1
14	A096 6081	Collection Bottle Stopper	1
15	5424 1064	Screw Stand	4
16	5415 1053	Caster	4
17	A096 6078	Right Front Frame	1
18	A096 6080	Left Frame Joint	2
19	A096 6266	Tray Lock Arm	1 (3)
19	A096 6247	Tray Lock Arm - Tandem Tray (A096/A097) MB14	2
20	A096 6261	Left Rail	1 (3)
20	A096 6241	Left Rail - Tandem Tray (A096/A097) MB14	2
21	A096 6250	Right Rail	3
22	A096 6077	Upper Front Fixing Plate	1
23	AX40 0049	Anti-condensation Heater - 240V 18W	1
23	AX40 0021	Anti-condensation Heater - 115V 18W	1
24	A096 6100	Lower Heat Sink	1
25	A096 3710	Collection Tank Guide	1
26	A096 6818	Stopper Bracket	1
27	A096 6110	Harness Cover	1
28	A096 5535	Key Counter Stay	1
29	A096 6181	Front Side Plate - P/B	1
30	AA06 0592	Lock Spring - Tandem Tray	2
	AA06 0570	Tray Lock Spring - 20mm(Tandem) x/o MB14	

Index No.	Part No.	Description	Q'ty Per Assembly
30	AA06 0534	Tray Lock Spring - 19mm	1 (3)
31	5301 1662	Hexagon Bolt	12
32	AH01 3008	Leveling Foot Guide	4
	5446 1086	o/o MB5	
33	C201 5125	Shoulder Screw - M4	8
34	A096 6111	4th Tray Cover	1
35	A096 6246	Left Rail Bracket MB14	2
101	0434 0080B	Philips Tapping Screw - M4x8	
102	0720 0040B	Retaining Ring - M4	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0964 4008B	Tapping Screw With Flat Washer-M4x8	
105	1105 0291	Wire Saddle	
106	0960 4012B	Philips Flange Screw - M4 X 12	

44. FRAME SECTION 2 (A095/A096/A097)



44. FRAME SECTION 2 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 2103	Ozone Filter	1
2	A096 2092	Main Duct	1
3	AA15 1772	Duct Seal	1
4	AA15 1773	Rear Duct Seal	1
5	A300 2134	Guide Roller - B	2
6	A096 4587	**Left Duplex Rail**	1
7	6754 2866	Roller - Positioning Guide	2
8	A096 4498	Rear Exit Unit Bracket	1
9	5446 3648	Stepped Screw - M4	1
10	AA06 0541	Bushing Lock Spring	1
11	A096 4261	Fusing Lock **Lever**	1
12	A096 4251	Fusing Unit Rail	1
13	A096 4271	Fusing Unit Stopper	1
14	A096 3951	Belt Unit Holder	1
15	A096 3955	Front Holder	1
16	A096 3961	Belt Unit Knob	1
17	AA06 6218	Unit Release Spring	1
18	A096 5444	Transfer Belt Harness	1
19	A096 3958	Release Arm	1
20	5447 2681	Snap Ring	2
21	AA08 0158	Bushing - 12x16x12.1	1
22	A096 4591	Right Duplex Rail	1
23	A096 3956	Heater Cover	1
24	AX40 0048	Anticondensation Heater - 15W 220/230V	1
24	AX40 0047	Anticondensation Heater- 15W 115V	1
25	A096 5590	Right Upper Harness Cover	1
26	A096 5453	Anticondensation Heater Harness 1	1
27	AA13 2017	Pressuer Roller	1
28	AA17 2013	Heater Cover	1

Index No.	Part No.	Description	**Q'ty Per** Assembly
101	0414 0082B	Binding Self Tapping Screw - M4x8	
102	0434 0060B	Philips Tapping Screw - M4x6	
103	0314 0060B	Philips Pan Head Screw - M4x6	
104	0314 0080B	Philips Pan Head **Screw -** M4x8	
105	1102 6249	Connector - 6P	
106	0951 4008B	Philips Screw With Washer - M4x8	
107	1105 0278	Harness Clamp	
108	0313 0050B	Philips Pan Head Screw - M3x5	
109	0720 0040B	Retaining Ring - M4	
110	0434 0080B	Philips Tapping Screw - M4x8	
111	1105 0310	Wire Clamp	
112	1102 6251	Connector - 8P	

45. FRAME SECTION 3 (A095/A096/A097)



45. FRAME SECTION 3 (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A096 6421	Upper Front Side Plate	1
2	A096 6423	Upper Transport Guide	1
3	A096 6422	Upper Rear Side Plate	1
4	AF02 0295	Vertical Driven Roller	3
5	AA08 0156	Bushing - M4	6
6	AA06 3487	Spring -10mm	6
7	A096 6402	Pressure Plate Driven Roller	3
8	A096 6404	Rear Side Plate	1
9	A096 1352	Magnet Catch Bracket	1
10	A096 6405	Lower Transport Guide	1
11	AG05 0067	Knob - Transport Roller	1
12	A096 6184	Bank Inner Cover	1
13	AA03 2020	Toner Collection Tank	1
14	A423 4433	Spring	1
15	A007 3751	Cap Large - Toner Collection Tank	1
16	AA00 0059	Caution Decal - English	1
17	AA15 2315	Tank Seal	1
18	A096 3711	Collection Tank Holder	1
19	A096 3712	Ratch	1
20	A096 6408	Guide Pressure Stay	1
21	A096 6412	Spring Plate	1
22	A096 6403	Front Side Plate	1
23	A096 6413	Release Lever Cover	1
24	A029 2984	Decal - Grip	1
25	A096 6411	Release Lever Bracket	1
26	A029 2858	Release Lever	1
27	5446 2846	Release Spring - Vertical Transport	1
28	5403 6246	Stepped Screw - Cleaning	1
29	A096 1358	Hinge Plate - Lower Right	1
30	AG07 0004	Magnetic Catch	2
31	A096 5529	Micro Switch Bracket	1
32	A423 4432	Shoulder Screw - M2.5	1
33	AA00 1326	Decal - A1	1
34	A096 6190	Middle Guide Plate	1
35	A096 5528	Micro Switch Sheet	1
36	5201 1796	Stepped Screw - M4	1
37	A097 5552	Fan Plate (A097)	1
38	A097 5550	Fan Motor Bracket (A097)	1
39	A097 5553	Cooling Fan Motor - DC24V 9.6W (A097)	1
40	A097 5551	Fan Motor Duct (A097)	1
101	0434 0060B	Philips Tapping Screw - M4x6	
102	1204 2355	Microswitch - AM51632A531	
103	0960 4006B	Philips Flange Screw - M4x6	
104	0434 0080B	Philips Tapping Screw - M4x8	

46. MAIN CONTROL BOARD (A095/A096/A097)

CAPACITOR

SYMBOL NO.	INDEX NO.
C101	149
C102	149
C103	143
C104	151
C105	151
C106	151
C107	151
C108	151
C109	142
C110	143

SYMBOL NO.	INDEX NO.
C111	151
C112	143
C114	143
C115	146
C116	146
C117	144
C118	144
C119	145
C120	145

SYMBOL NO.	INDEX NO.
C121	143
C123	148
C124	148
C125	148
C126	149
C127	151
C128	148
C129	151
C130	151

SYMBOL NO.	INDEX NO.
C131	148
C132	148
C133	151
C134	151
C135	151
C136	146
C137	146
C138	151
C139	148
C140	151

SYMBOL NO.	INDEX NO.
C141	150
C142	150
C143	148
C144	151
C145	148
C146	151
C147	151
C148	149
C149	149
C150	148

SYMBOL NO.	INDEX NO.
C151	148
C152	149
C153	149
C154	148
C155	151
C157	148
C158	148
C159	148
C160	148

SYMBOL NO.	INDEX NO.
C161	151
C162	151
C163	151
C164	151
C165	151
C167	151
C168	151
C169	153
C170	153

SYMBOL NO.	INDEX NO.
C171	149
C172	151
C173	151
C174	151
C175	151
C176	151
C177	151
C178	147
C179	147
C180	148

SYMBOL NO.	INDEX NO.
C181	151
C182	148
C183	151
C184	151
C185	148
C186	151
C187	151
C188	151
C189	151
C190	151

SYMBOL NO.	INDEX NO.
C191	151
C192	151
C193	151
C194	151
C195	151
C196	151
C197	151
C198	151
C199	151
C200	

SYMBOL NO.	INDEX NO.
C201	148
C203	148
C204	151
C205	148
C206	151
C207	151
C208	151
C209	151
C210	151

SYMBOL NO.	INDEX NO.
C211	151
C212	151
C213	151
C214	151
C215	151
C216	151
C217	151
C218	148
C219	149
C220	151

SYMBOL NO.	INDEX NO.
C221	149
C222	151
C223	151
C224	151
C225	151
C226	151
C227	151
C228	151
C229	151
C230	151

SYMBOL NO.	INDEX NO.
C231	151
C232	151
C233	148
C234	151
C235	151
C236	151
C237	151
C238	151
C239	151
C240	151

46. MAIN CONTROL BOARD (A095/A096/A097)

SYMBOL NO.	INDEX NO.
C241	148
C242	148
C243	149
C244	151
C245	151
C246	148
C247	148
C248	151
C249	151
C250	151

SYMBOL NO.	INDEX NO.
C251	151
C252	143
C253	151
C254	151
C255	151
C256	151
C257	151
C258	151
C259	151
C260	151

CONNECTOR

SYMBOL NO.	INDEX NO.
CN200	4
CN201	4

DPS

SYMBOL NO.	INDEX NO.
DPS101	101

DAY

SYMBOL NO.	INDEX NO.
DAY101	107
DAY102	107
DAY103	107
DAY104	107
DAY105	107
DAY106	107

DIODE

SYMBOL NO.	INDEX NO.
D101	104
D102	109
D103	109
D104	109
D105	109
D106	109
D107	109
D108	109
D109	109
D110	109

SYMBOL NO.	INDEX NO.
D111	106
D112	109
D113	109
D115	106
D116	106
D117	106
D118	106
D119	106
D120	106

SYMBOL NO.	INDEX NO.
D121	106
D122	106
D123	106
D124	106
D125	106
D126	104
D127	104

FIB

SYMBOL NO.	INDEX NO.
FIB101	152
FIB102	152
FIB103	152
FIB104	152
FIB105	152
FIB106	152
FIB107	152
FIB108	152
FIB109	152

IC

SYMBOL NO.	INDEX NO.
IC101	112
IC102	130
IC103	121
IC104	134
IC105	124
IC106	128
IC107	128
IC108	117
IC109	112
IC110	130

SYMBOL NO.	INDEX NO.
IC111	114
IC112	128
IC113	134
IC114	123
IC115	115
IC116	127
IC117	134
IC118	124
IC120	1

SYMBOL NO.	INDEX NO.
IC122	132
IC123	123
IC124	123
IC125	117
IC126	116
IC127	124
IC128	120
IC129	119
IC130	3

SYMBOL NO.	INDEX NO.
IC131	113
IC132	105
IC134	131
IC135	122
IC136	135
IC137	135
IC138	123
IC139	133
IC140	121

SYMBOL NO.	INDEX NO.
IC141	137
IC142	123
IC143	129
IC144	128
IC145	126
IC146	127
IC147	116
IC148	125
IC149	136
IC150	121

SYMBOL NO.	INDEX NO.
IC151	124
IC152	123
IC153	121
IC154	118
IC155	112
IC156	127

LED

SYMBOL NO.	INDEX NO.
LED101	111

OSC

SYMBOL NO.	INDEX NO.
OSC101	138
OSC102	139
OSC103	140

TRANSISTOR

SYMBOL NO.	INDEX NO.
Q101	102
Q102	102
Q103	102
Q104	102
Q105	102
Q106	102
Q107	102
Q108	102
Q109	103
Q110	103

RAY

SYMBOL NO.	INDEX NO.
RAY101	141
RAY102	141
RAY103	141

RESISTOR

SYMBOL NO.	INDEX NO.
R101	170
R102	165
R103	160
R104	155
R105	155
R106	155
R107	155
R108	155
R109	155
R110	155

SYMBOL NO.	INDEX NO.
R111	167
R112	167
R113	167
R114	167
R115	167
R116	167
R117	167
R118	167
R119	170
R120	167

SYMBOL NO.	INDEX NO.
R121	167
R122	167
R123	167
R124	157
R125	157
R126	157
R127	157
R128	157
R129	157
R130	157

SYMBOL NO.	INDEX NO.
R131	157
R132	157
R133	157
R134	157
R135	157
R136	170
R137	170
R138	157
R139	156
R140	172

SYMBOL NO.	INDEX NO.
R141	156
R142	156
R143	156
R144	156
R145	156
R146	156
R147	157
R148	156
R149	156
R150	156

SYMBOL NO.	INDEX NO.
R151	156
R152	156
R153	156
R154	156
R155	156
R156	165
R157	165
R158	165
R159	165
R160	157

SYMBOL NO.	INDEX NO.
R161	157
R162	170
R163	171
R164	156
R165	156
R166	161
R167	156
R168	167
R169	157
R170	156

SYMBOL NO.	INDEX NO.
R171	156
R172	170
R173	172
R174	172
R175	158
R176	157
R177	162
R178	156
R179	166
R180	156

SYMBOL NO.	INDEX NO.
R181	157
R182	156
R183	157
R184	160
R185	157
R186	157
R187	157
R188	157
R189	157

SYMBOL NO.	INDEX NO.
R191	166
R192	160
R193	160
R194	158
R195	157
R196	167
R197	154
R198	170
R199	156
R200	156

SYMBOL NO.	INDEX NO.
R201	162
R202	158
R203	164
R204	157
R205	157
R206	164
R207	170
R208	170
R209	170
R210	170

46. MAIN CONTROL BOARD (A095/A096/A097)

SYMBOL NO.	INDEX NO.
R211	170
R212	168
R214	170
R215	170
R216	170
R217	157
R218	157
R219	157
R220	157

SYMBOL NO.	INDEX NO.
R221	157
R224	170
R225	170
R226	170
R227	170
R228	156
R229	170
R230	167

SYMBOL NO.	INDEX NO.
R231	168
R232	159
R233	157
R234	164
R235	156
R236	166
R237	160
R238	156
R239	156
R240	156

SYMBOL NO.	INDEX NO.
R241	156
R242	156
R243	156
R244	156
R245	156
R246	170
R247	170
R248	170
R249	163
R250	169

SYMBOL NO.	INDEX NO.
R251	157
R252	170
R253	170
R254	170
R255	170
R256	170
R257	170
R258	170
R259	170
R260	170

SYMBOL NO.	INDEX NO.
R261	157
R262	157
R263	157
R264	157
R265	170
R266	170
R267	170
R268	170
R269	170
R270	170

SYMBOL NO.	INDEX NO.
R271	170
R272	157
R273	157
R274	170
R275	157
R276	157
R277	167
R278	167
R279	167
R280	167

SYMBOL NO.	INDEX NO.
R281	167
R282	157
R283	157
R284	157
R285	157
R286	156
R287	167
R288	170
R289	170

SYMBOL NO.	INDEX NO.
R293	170
R294	170
R295	170
R296	157
R297	157
R298	157
R299	157
R300	155

SYMBOL NO.	INDEX NO.
R301	166
R302	160
R303	167
R304	170
R305	167
R306	170
R307	166
R308	157
R309	157
R310	156

SYMBOL NO.	INDEX NO.
R311	170
R312	170
R313	170
R314	167
R315	170
R316	157
R317	170
R318	157
R319	156
R320	157

SYMBOL NO.	INDEX NO.
R321	156
R322	156
R323	157
R324	172
R387	172
R389	172
R390	172

SYMBOL NO.	INDEX NO.
R391	172
R392	172
R393	172
R394	172
R395	172

ZD

SYMBOL NO.	INDEX NO.
ZD101	108
ZD102	110

46. MAIN CONTROL BOARD (A095/A096/A097)

Index No.	Part No.	Description	Q'Sty Per Assembly
*	A095 5112	Main Control Board - 115V (A095)	1
	A095 5110	x/o MB12	
*	A095 5117	Main Control Board - 230V (A095)	1
	A095 5115	x/o MB12	
*	A096 5117	Main Control Board - 115/230V(A096EU/A097)	1
	A096 5115	x/o MB12	
*	A096 5112	Main Control Board - 115V (A096)	1
	A096 5110	x/o MB12	
1	A096 5151	IC - AM27C040-150DC	1
	A096 5121	IC - AM27C020-150DC x/o MB12	
2	A096 5153	IC - AM27C010-120DC	1
	A096 5123	IC - AM27C512-120DC x/o MB12	
3	A096 5129	IC - M37409M2-155FP	1
4	A096 5125	RAM Board	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1204 1542	Dip Switch	
102	1400 0528	Transistor - DTB113EK	
103	1401 0298	Transistor - 2SC2712Y	
104	1401 0835	Diode - 1SS190	
105	1401 0986	Transistor - µPA1552H	
106	1402 0476	Diode - 1SS184	
107	1402 0492	Diode - DICA20	
108	1402 0687	Diode - RD12P	
109	1402 1122	Diode - MA159A	
110	1402 1152	Diode - RD7.5P	
111	1403 0558	LED - SEI2110RTP3	
112	1407 1311	IC - LS32	
113	1407 1596	IC - SN74LS14NS	
114	1407 1925	IC - SN15189ANS	
115	1407 1926	IC - SN75188NS	
116	1407 2052	IC - SN74LS7ANS	
117	1407 2081	IC - SN74LS08NS	
118	1407 2135	TTLIC - 74F74SJ	
119	1407 2137	IC - 74F138SJ : TTL	
120	1407 2138	TTLIC - 74F139SJ	
121	1407 2187	IC - SN74LS07NS	
122	1407 2218	IC - SN74LS06NS	
123	1407 2231	IC - TD62308AF	
124	1407 2344	IC - TD62382F	
125	1407 2463	IC - SN74ALS08NS	
126	1407 2464	IC - SN74ALS7ANS	
127	1407 2588	IC - SN74ALS04BNS	
128	1407 2817	IC - SN74ALS32NS	
129	1407 3224	IC - LH5164LN-10	
130	1407 3852	IC - MB89371AH	
131	1407 4137	IC - MM1035XF	
132	1407 4143	IC - MC68331FC	
133	1407 4144	IC - H81532-HD6435328A00M	
134	1407 4146	LSI - MB89255AHPFS	
135	1407 4147	IC - M66320FP	

Index No.	Part No.	Description	Q'ty Per Assembly
136	1408 0595	IC - NJM2904M	
137	1408 0826	IC - TA8428K	
138	1503 0194	Crystal Oscillator -32.768 KHz	
139	1503 0261	Oscillator - 9.8304MHz	
140	1503 0307	Oscillator - 20 MHz	
141	1601 7374	Resistor Array - 4.7K OHM	
142	1604 1377	Capacitor - 0.47µF 50V	
143	1604 1382	Capacitor - 10µF 50V	
144	1604 1385	Capacitor - 47µF 50V	
145	1604 1386	Capacitor - 100µF ±20% 50V	
146	1605 0113	Capacitor - 4700PF 50V	
147	1605 0233	Capacitor - 15PF 50V	
148	1605 0636	Capacitor - 0.1µF	
149	1606 1135	Capacitor - 470PF 50V	
150	1606 1450	Capacitor - 10PF 50V	
151	1606 1452	Capacitor - 0.01µF 50V	
152	1607 0551	Inductor - BIM32A07PB	
153	1610 0286	Capacitor -100PF 50V ±10%	
154	1630 1101	Resistor -100 OHM 1/4W ±5%	
155	1630 1151	Resistor -150 OHM ±5% 1/4W	
156	1630 2102	Resistor -1 K OHM 1/8W ±5%	
157	1630 2103	Resistor - 10K OHM 1/8W	
158	1630 2104	Resistor - 100K OHM 1/8W ±5%	
159	1630 2105	Resistor -1M OHM 1/8W	
160	1630 2121	Resistor -120 OHM ±5% 1/8W	
161	1630 2123	Resistor - 12K OHM 1/8W ±5%	
162	1630 2154	Resistor - 150K OHM ±50% 1/8W	
163	1630 2206	Resistor - 20M OHM 1/8W ±5%	
164	1630 2220	Resistor - 22 OHM 1/8W ±5%	
165	1630 2221	Resistor - 220 OHM	
166	1630 2222	Resistor - 2.2K OHM 1/8W	
167	1630 2223	Resistor - 22K OHM 1/8W ±5%	
168	1630 2330	Resistor - 33 OHM 1/8W ±5%	
169	1630 2331	Resistor - 330 OHM 1/8W ±5%	
170	1630 2472	Resistor - 4.7K OHM 1/8W ±5%	

Index No.	Part No.	Description	Q'ty Per Assembly
171	1630 2473	Resistor - 47K OHM 1/8W ±5%	
172	1630 2910	Resistor - 91 OHM 1/8W ±5%	

47. DECAL AND DOCUMENT (A095/A096/A097)

1



2

3

4

6



5



7

WARNING

- Do not incinerate waste toner.
- Toner dust may cause flashback when exposed to open flame.

8



9

10

11



12



15



16



17

18

13

14



19

20

25



21



20



22



23

24



26



47. DECAL AND DOCUMENT (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5216 4145	Thermofuse Decal	1
2	5446 2638	Decal - Paper Lower Limit	1
3	A029 2984	**Decal - Grip**	1
4	A096 1300	Decal - Main Switch	1
5	A096 1338	**Decal -** Misfeed Removal	1
6	A096 1339	Decal - Add Toner	1
7	AA00 0059	Caution Decal - English	1
8	AA00 0136	Decal - Left Tandem Tray	1
9	AA00 0137	**Decal -** Tandem Tray 1	1
10	AA00 0138	Decal - No.2	1
11	AA00 0139	**Decal -** No.3	1
12	AA00 0144	Decal - Right Tandem Tray	1
13	AA00 1213	Decal - B2	1
14	AA00 1322	Decal - Bottle Set	1
15	AA00 1323	**Decal -** Bottle Shutter	1
16	AA00 1324	**Decal -** Duplex Lever	1
17	AA00 1326	**Decal -** A1	1
18	AA00 1327	Decal - Misfed Removal A2	1
19	AA00 2010	**Decal -** Paper Level	3
20	AA00 2176	Decal - Side Fence - A4	1
20	AA00 2177	Decal - Side Fence - LT	1
21	AA00 2178	Decal - End Fence - A4	1
21	AA00 2179	Decal - End Fence - LT	1
22	AA00 2184	Decal - A4	1
22	AA00 2181	Decal - LT	1
23	AA00 2175	Decal - Paper Size - A4	1
23	AA00 2192	Decal - Paper Size - LT	1
24	AA00 0134	Decal - Tray Universal	1
25	A096 8607	Operating Instructions - English LT	1
26	AA00 1331	Decal - E2	1

Index No.	Part No.	Description	Q'ty Per Assembly

48. SPECIAL TOOL (A095/A096/A097)

1.7.	2 	3 	4 
5 	6	8	9 

48. SPECIAL TOOL (A095/A096/A097)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A028 9300	Grease KOK Barrierta - JFE5 5/2	1
2	A008 9502	Silicone Grease - G40M	1
3	5203 9501	Grease 501	1
4	5420 9516	Test Chart - OS - A3 (10pts/set)	1
5	5442 9101	Setting Powder	1
6	5442 9103	Launa Oil	1
7	5447 9078	Heat Resisting Grease MT-78	1
8	A096 1337	Hinge Shaft - Lower Left	1
9	G004 9668	Grease: KS660:SHIN-ETSU	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

Part No.	Description	Page and Index No.
A095 1360	Upper Rear Cover	13- 8
A095 1363	Cap - 38x77	13-42
A095 1363	Cap - 38x77	15- 12
A095 1368	Right Door (A095)	13- 17
A095 1383	Lower Front Cover	41- 17
A095 1384	Bracket - Lower Front Cover	41- 18
A095 1391	Positioning Sensor Bracket	15- 14
A095 1394	Mounting Bracket - Platen Cover	15- 11
A095 5110	x/o MB12	89- 10
A095 5110	x/o MB12	105- *
A095 5112	Main Control Board - 115V (A095)	89- 10
A095 5112	Main Control Board - 115V (A095)	105- *
A095 5115	x/o MB12	89- 10
A095 5115	x/o MB12	105- *
A095 5117	Main Control Board - 230V (A095)	89- 10
A095 5117	Main Control Board - 230V (A095)	105- *
A095 5185	Paper Feed Board (A095)	91- 2
A095 5400	DC Main Harness (A095)	95- 14
A095 5413	Motor Control Harness (A095)	83-32
A096 1072	Upper Middle Stay	97- 8
A096 1075	Base Cover	97- 2
A096 1076	Lower Fixing Plate	97- 3
A096 1077	Right Fixing Plate	97- 5
A096 1078	Left Fixing Plate	97- 1
A096 1094	Grip Base	97- 7
A096 1095	Front Grip Bracket	97- 6
A096 1096	Rear Grip Bracket	97- 9
A096 1112	Main Motor Bracket	81-21
A096 1115	Tightener	81- 16
A096 1123	Belt Drive Bracket	81-24
A096 1125	Belt Drive Shaft	81-36
A096 1128	Registration Drive Bracket	81- 14
A096 1133	Timing Belt Bracket	81-25
A096 1136	Tightener	81-26
A096 1143	Drive Support Bracket	81- 15

Part No.	Description	Page and Index No.
A096 1146	Tightener Lever	81-28
A096 1149	Support Plate - Cleaning Drive	81-38
A096 1155	Duplex Drive Bracket	79- 5
A096 1165	Fusing Drive Bracket	79- 4
A096 1169	x/o MB8	79- 15
A096 1170	x/o MB2	79-20
A096 1172	Tightener	79-20
A096 1173	Fusing Drive Joint	79- 15
A096 1281	Rear Top Cover	13- 7
A096 1282	Position Sensor Cap	13- 10
A096 1286	Top Cover	13- 6
A096 1289	Right Support Bracket	93- 8
A096 1290	Left Support Bracket - ADF	21- 9
A096 1291	Right Support Bracket - ADF	21- 10
A096 1293	Middle Support Bracket	97- 4
A096 1294	Upper Left Cover	13- 2
A096 1297	Mirror Clamp Cover	13-47
A096 1298	Cap - MAT20	13-24
A096 1299	Cap - M22	13- 44
A096 1300	Decal - Main Switch	13- 1
A096 1300	Decal - Main Switch	107- 4
A096 1302	Lower Left Cover	13- 3
A096 1305	Upper Right Cover	13- 12
A096 1308	Middle Right Cover	13- 13
A096 1309	Spring Plate	13- 15
A096 1313	Cover Bracket	13- 46
A096 1315	Lower Right Cover	13- 14
A096 1317	Cap - 34x55	13-25
A096 1320	Left Door	13-22
A096 1323	Grip Cover	13-20
A096 1324	Grip Inner Cover	13- 19
A096 1325	Left Switch Lever	13-28
A096 1326	Lower Left Hinge	13-33
A096 1327	Magnet Catch Plate	13-29
A096 1328	Duplex Guide Lever	13-21

Part No.	Description	Page and Index No.
A096 1330	Main Switch Bracket	93- 6
A096 1336	Hinge Plate - Lower Left	93- 7
A096 1337	Hinge Shaft - Lower Left	13-32
A096 1337	Hinge Shaft - Lower Left	109- 8
A096 1338	Decal - Misfeed Removal	13-30
A096 1338	Decal - Misfeed Removal	107- 5
A096 1339	Decal - Add Toner	13-31
A096 1339	Decal - Add Toner	107- 6
A096 1343	Upper Switch Lever	13- 35
A096 1344	Upper Right Hinge	13-40
A096 1345	Lower Right Hinge	13- 18
A096 1348	Lower Switch Lever	13-37
A096 1349	Magnet Catch Plate	13-36
A096 1352	Magnet Catch Bracket	101- 9
A096 1354	Hinge Plate - Upper Right	93- 9
A096 1355	Hinge Shaft	93- 10
A096 1358	Hinge Plate - Lower Right	101- 29
A096 1362	Connector Cover	13- 11
A096 1364	Lower Rear Cover	13- 9
A096 1365	Upper Cover Bracket	91- 4
A096 1366	Lower Cover Bracket	91- 5
A096 1367	Right Guide Lever	13-38
A096 1368	Right Door (A096)	13- 17
A096 1371	Inner Cover - Door Switch	13- 16
A096 1376	Inner Cover - Main Switch	13- 23
A096 1377	Left Door Stoper	13-48
A096 1380	Left Support Bracket	93- 5
A096 1461	Operation Panel Ass'y - LT	13- 4
A096 1461	Operation Panel Ass'y - LT	17- *
A096 1462	Operation Panel Ass'y - A4	13- 4
A096 1462	Operation Panel Ass'y - A4	17- *
A096 1486	Operation Panel Case - LT	17- 1
A096 1487	Operation Panel Case - A4	17- 1
A096 1491	Keytop - Start	17- 2
A096 1492	Keytop - C/S	17- 3

Part No.	Description	Page and Index No.
A096 1493	Keytop - Set1	17- 4
A096 1494	Keytop - Interrupt	17- 5
A096 1496	Keytop - Set2	17- 7
A096 1497	LCD Display Dial	17- 8
A096 1498	Keytop - Mode Clear	17- 6
A096 1506	Right Keytop Sheet	17- 9
A096 1507	Left Keytop Sheet	17- 10
A096 1508	Grounding Plate	17- 11
A096 1509	Cushion -1	17- 12
A096 1510	Cushion -2	17- 13
A096 1511	Grounding Harness -1	17- 14
A096 1512	x/o MB1	17- 15
A096 1513	LCD Display Sheet	17- 16
A096 1517	Key Board - 115V	17- 18
A096 1518	Key Board - 220/230V	17- 18
A096 1521	Grounding Harness -2	17- 15
A096 1676	Development Unit Rail	21- 18
A096 1677	Right Rail - Drum Unit	21- 17
A096 1678	Left Rail - Drum Unit	21- 16
A096 1679	Development Grounding Plate	21-24
A096 1680	Front Scanner Guide	23- 9
A096 1682	Rear Scanner Guide	23- 3
A096 1687	Wire Guide	23- 5
A096 1689	Scanner Sensor Bracket	25- 18
A096 1692	ADS Case	23- 17
A096 1693	ADS Cover	23-20
A096 1694	ADS Bracket - A4 (A095)	23- 19
A096 1695	ADS Bracket (A096)	23- 19
A096 1713	Front Right Angle	21- 13
A096 1714	Front Left Angle	21- 14
A096 1715	Optics Heater Bracket	21-20
A096 1716	Optics Heater Cover	21- 19
A096 1717	Front Sensor Cover	25- 9
A096 1718	Rear Sensor Cover - A4	25- 10
A096 1719	Rear Sensor Cover - LT	25- 10

Part No.	Description	Page and Index No.
A096 1725	o/o MB5	21- 2
A096 1727	Guide Plate	21- 4
A096 1729	Left Harness Guide	23- 4
A096 1735	VD/ADS Pattern	19- 18
A096 1736	Cushion - 1x13x41	19- 9
A096 1737	x/o MB16	19- 10
A096 1738	Seal - 0.05x26x285	19- 10
A096 1739	Small VL Pattern MB21 (ADDED)	19- 27
A096 1741	x/o MB1	19- 1
A096 1742	x/o MB1	19- 1
A096 1749	Grounding Plate	19- 26
A096 1760	Lens Ass'y	31- 4
A096 1766	Lens Slider	31- 11
A096 1767	Lens Position Bracket - Y	31- 8
A096 1773	Lens Cover	31- 1
A096 1775	Lens Driven Pulley - Y	31- 18
A096 1777	Front Belt Holder	31-21
A096 1778	Rear Belt Holder	31- 16
A096 1781	Lens Bracket	31-22
A096 1782	Harness Cover	31-25
A096 1787	Lens Position Bracket - X	31- 13
A096 1791	Lens Sensor Bracket - Y	31-30
A096 1792	Rear Shielding Bracket	31- 5
A096 1796	Harness Bracket A	31-26
A096 1797	Harness Bracket B	31-27
A096 1801	Lens Slider - X	25- 3
A096 1802	Left Holder - X	25- 1
A096 1804	Right Holder - X	25-22
A096 1807	Lens Driver Pulley - X	25-20
A096 1811	Motor Bracket	25- 8
A096 1816	Sensor Bracket - Lens Position	23-21
A096 1819	3rd Scanner Guide	21- 5
A096 1821	2nd Optics Cover	19-21
A096 1825	Main Optics Cover	19- 5
A096 1827	Cover Angle - Front Right	21- 8

Part No.	Description	Page and Index No.
A096 1828	Cover Angle - Front Left	21- 7
A096 1829	Cover Rear Angle	21-21
A096 1832	Front Optics Cover	19- 13
A096 1835	Optics Shielding Belt	31- 2
A096 1842	Rear Optics Cover	19- 12
A096 1848	Cover Guide Plate	19- 14
A096 1855	1st Scanner Bracket	27- 11
A096 1856	o/o MB5	27- 15
A096 1857	x/o MB2	27- 8
A096 1858	1st Scanner Holder	27- 19
A096 1859	Wire Clamp	27- 13
A096 1861	Main Reflector	27- 9
A096 1862	Lamp Terminal Insurator	27- 15
A096 1865	Reflector Cover	27-20
A096 1866	Sub-reflector	27- 3
A096 1871	Thermostat Holder	27-22
A096 1873	Scanner Shoe Pin	27-26
A096 1873	Scanner Shoe Pin	29-37
A096 1874	Harness Guide Plate	19- 8
A096 1875	Guard Sheet MB16 (ADDED)	27-27
A096 1876	Harness Clamp	23-25
A096 1876	Harness Clamp	31-31
A096 1878	1st Mirror Support Plate	27- 12
A096 1879	1st Mirror Cushion	27- 10
A096 1891	2nd Scanner Bracket	29- 4
A096 1901	Left Scale - A4	19- 1
A096 1904	Left Scale - LT	19- 1
A096 1921	Scanner Drive Shaft	23- 1
A096 1925	Front Wire Pulley	23- 2
A096 1927	Front Wire Bracket	23-24
A096 1934	Motor Bracket	23- 15
A096 1939	Timing Pulley Ring	23-22
A096 1940	Tension Bracket	23- 10
A096 1947	Optics Board Hinge	8 9 - 4
A096 1949	Optics Board Bracket	89- 3

Part No.	Description	Page and Index No.
A096 1956	3rd Scanner Bracket	29-23
A096 1961	Slider Bracket - 3rd Scanner	29- 19
A096 1963	Slider Shaft	29-21
A096 1971	Drive Bracket - 3rd Scanner	29-29
A096 1976	Pulley Bracket	29-34
A096 1981	3rd Scanner Holder	29-24
A096 1982	Holder Fixing Plate	29-28
A096 1983	Right Holder - Guide Rod	29-26
A096 1984	Left Holder - Guide Rod	29-27
A096 1986	Sensor Bracket	29- 9
A096 1991	Front 6th Mirror Holder	25- 16
A096 1992	Rear 6th Mirror Holder	25- 15
A096 1994	Filter Holder	21- 11
A096 1995	Filter	21- 12
A096 2051	Rear Grid Anchor	59-24
A096 2052	Front Grid Anchor	59-26
A096 2053	Cleaner Motor Cover	59- 16
A096 2054	Grounding Plat	59- 17
A096 2055	Motor Grounding Plate	59-30
A096 2057	Charge Corona Grid	59-25
A096 2061	Screw Shaft	59-12
A096 2062	Wire Cleaner Slider	59- 14
A096 2063	Corona Wire Cleaner	59- 13
A096 2065	Slider Ring	59-33
A096 2083	Middle Duct	89- 7
A096 2088	Vacuum Duct Bracket	89- 6
A096 2089	Vacuum Duct Bracket	89- 5
A096 2092	Main Duct	99- 2
A096 2097	Rear Duct	89- 16
A096 2100	Exhaust Duct	89- 18
A096 2101	Rear Duct Bracket	89- 14
A096 2103	Ozone Filter	99- 1
A096 2109	Exhaust Duct Bracket	89- 17
A096 2110	Ozone Fan Motor	89- 13
A096 2251	Upper Drum Unit	59- *

Part No.	Description	Page and Index No.
A096 2260	Upper Unit Cover	59- 1
A096 2261	Eraser Cover	59- 8
A096 2266	Corona Unit Bracket	59- 7
A096 2271	Grounding Plate	59- 4
A096 2282	Connector Bracket	59- 6
A096 2301	Grounding Plate	59-35
A096 2302	Upper Drum Shield	59- 10
A096 2311	Drum Shaft	81- 7
A096 2314	Drum Shaft Stay	81- 4
A096 2316	Drum Pulley - 125Z	81- 6
A096 2317	Bearing Grounding Plate	81- 3
A096 2320	Drum Stay	93- 19
A096 2325	Drum Stay Sleeve	93-20
A096 2330	Drum Shaft Knob	93-22
A096 2341	Drum Grounding Plate	81- 1
A096 2342	Grounding Plate Cover	81- 2
A096 2593	Front Support Plate	37-32
A096 2598	Front Connector Bracket	35-30
A096 2600	Rear Connector Bracket	37-39
A096 2604	Magnetic Clutch Stopper	35- 10
A096 2606	Resist Sensor Guide	35- 2
A096 2607	Paper Dust Cleaner	35- 3
A096 2612	Lower Registration Guide	35- 4
A096 2622	Front Lower Registration Guide	35- 9
A096 2626	Front Upper Registration Guide	35- 7
A096 2632	Middle Shutter Guide	37- 7
A096 2633	Front Lock	37-34
A096 2634	Rear Lock	37- 8
A096 2635	Lock Release Lever	37-35
A096 2636	Sensor Bracket	37- 12
A096 2642	Guide Shutter Solenoid	37- 14
A096 2651	LCT Exit Guide	37-22
A096 2661	Paper Bank Relay Guide	37- 1
A096 2672	Duplex Exit Guide	37- 3
A096 2682	Separation Roller Bracket	37-26

Part No.	Description	Page and Index No.
A096 2683	Sensor Bracket	37-28
A096 2684	Separation Roller Shaft	37-29
A096 2687	Upper Feed Stay	35-20
A096 2690	Pick-up Roller Arm	35-26
A096 2692	Pick-up Solenoid - By-pass	35- 17
A096 2695	Pick-up Roller Link	35- 18
A096 2697	Paper End Feeler	35-21
A096 2699	Sensor Bracket - Paper End	35- 15
A096 2700	Paper End Shutter	35- 16
A096 2701	Clutch Stopper - By-pass	35-33
A096 2703	Lower Guide - By-pass	37- 18
A096 2704	Guide Holder	37-20
A096 2706	By-pass Feed Cover	33- 3
A096 2707	Upper Guide - By-pass	33- 6
A096 2708	By-pass Feed Table - A4	33- 7
A096 2711	Feed Table	33- 10
A096 2721	By-pass Feed Cover	33- 19
A096 2741	Front Feed Guide	33- 9
A096 2751	Rear Feed Guide	33- 12
A096 2761	Front Support Guide	33- 8
A096 2771	Rear Support Guide	33- 13
A096 2780	Feed Guide Gear	33- 18
A096 2781	By-pass Table Bracket	33-22
A096 2782	Size Switch Bracket	33- 14
A096 2810	By-pass Feed Table - LT	33- 7
A096 2811	x/o MB13	33- 7
A096 3049	o/o MB20 (A095/A096)	53- *
A096 3050	o/o MB5 (A095/A096)	53- *
A096 3052	Lower Development Casing	53-21
A096 3056	Lower Front Side Plate	53-26
A096 3057	Lower Rear Side Plate	53- 16
A096 3059	Toner Sensor Guide	53-22
A096 3069	Development Knob	53-28
A096 3086	o/o MB20 (A095/A096)	53-33
A096 3100	Entrance Seal	53- 4

Part No.	Description	Page and Index No.
A096 3104	Development Guide Rail	53- 1
A096 3125	Adjusting Plate	53-29
A096 3126	Bearing Case	53- 9
A096 3141	Development Filter Case	53- 3
A096 3150	Toner Supply Unit	55- *
A096 3175	Bushing - 8x14x8	55- 13
A096 3176	Bushing - 6x12x8.5	55- 14
A096 3181	Slitter	55- 7
A096 3182	Plate Nut	55- 8
A096 3183	Hopper Shutter	55- 1
A096 3210	Bottle Hinge Bracket	57- 14
A096 3216	Bottle Holder Bracket	57- 18
A096 3217	DC Motor Bracket	57-22
A096 3222	Bottle Holder	57- 9
A096 3224	Bottle Roller	57- 6
A096 3225	Bottle Stopper - A4	57- 2
A096 3230	Shutter Joint	57- 1
A096 3231	Shutter Lever	57- 12
A096 3233	Holder Shutter	57- 13
A096 3235	Holder Cover	57- 7
A096 3236	Shutter Lever	57- 10
A096 3238	Toner Tray	57-21
A096 3239	Development Inner Cover	57- 19
A096 3241	Bottle Stopper - LT	57- 2
A096 3243	Lever Bushing	57- 5
A096 3245	Bottle Guide Plate MB9 (ADDED)	57-34
A096 3401	Upper Hinge	57- 15
A096 3404	Lower Hinge	57-25
A096 3408	Grounding Plate	37-46
A096 3500	x/o MB1 (A095/A096)	61- *
A096 3510	x/o MB7 (A095/A096)	61- *
A096 3558	PTL Cover	61-39
A096 3565	Cleaning Blade Bracket	61- 14
A096 3575	Blade Release Lever	61- 2
A096 3581	Cleaning Blade	61- 12

Part No.	Description	Page and Index No.
A096 3586	Cleaning Brush Drive Shaft	61- 25
A096 3588	Gear - 19Z	61- 7
A096 3594	Joint Gear - 14Z	61- 23
A096 3606	Cleaning Brush Seal x/o MB11	61- 16
A096 3607	Brush Roller Bracket	61- 16
A096 3621	Entrance Seal	61-33
A096 3624	Drum Grounding Plate	61- 4
A096 3631	Cleaning Seal	61- 15
A096 3642	Pick-off Pawl Bracket	61-29
A096 3646	Pick-off Pawl Shaft	61-34
A096 3656	Gear Bracket	61- 11
A096 3661	Gear - 15/35Z	61- 9
A096 3664	Toner Receiving Pipe	61- 21
A096 3666	Harness Cover	61- 38
A096 3677	PTL Harness Cover	61- 45
A096 3681	Front Collection Casing	79- 12
A096 3688	Rear Collection Casing	79- 11
A096 3697	Ratch	79- 17
A096 3710	Collection Tank Guide	97-25
A096 3711	Collection Tank Holder	101- 18
A096 3712	Ratch	101- 19
A096 3715	Tank Cover	83-30
A096 3722	Toner Collection Bracket ‘	83- 7
A096 3729	Toner Collection Joint	83- 5
A096 3736	Steel Ball - M11 MB4 (ADDED)	83- 33
A096 3742	Sensor Bracket	83- 15
A096 3752	Shutter Plate	83- 9
A096 3763	Push Switch Bracket	83- 17
A096 3851	x/o MB1	63- 1
A096 3852	Transfer Belt	63- 1
A096 3853	Transfer Belt Frame	63- 13
A096 3856	Grounding Plate	63- 8
A096 3857	Grounding Terminal	63-44
A096 3859	Front Spring Plate	63- 14
A096 3860	Rear Spring Plate	63- 16

Part No.	Description	Page and Index No.
A096 3861	Front Arm	63- 6
A096 3862	Rear Arm	63- 3
A096 3863	Spacer - 4x6x1	63- 10
A096 3864	Transfer Belt Terminal	63- 15
A096 3865	Terminal Cover	63- 18
A096 3867	Front Bushing - 4.5x6x21	63- 9
A096 3868	Rear Bushing - 4.5x6x13.5	63- 17
A096 3870	Transfer Bias Roller	63- 12
A096 3871	Belt Driven Roller	63- 19
A096 3875	Belt Drive Roller	63- 2
A096 3901	Transfer Belt Casing	63-32
A096 3906	Rear Casing Guide	63-29
A096 3907	Spring Plate	63-34
A096 3911	Transfer Belt Solenoid	63-22
A096 3915	Transfer Belt Lever	63-21
A096 3916	Belt Lever Arm	63-20
A096 3918	Solenoid Bracket	63-23
A096 3929	Gear Cover	63-40
A096 3931	Belt Cleaning Blade	63-27
A096 3934	Cleaning Blade Stay	63-28
A096 3935	Transport Guide Holder	63-37
A096 3936	Blade Stay Bushing	63-41
A096 3951	Belt Unit Holder	99- 14
A096 3955	Front Holder	99- 15
A096 3956	Heater Cover	99- 23
A096 3958	Release Arm	99- 19
A096 3961	Belt Unit Knob	99- 16
A096 3966	Belt Unit Support Plate	93- 18
A096 4003	Fusing Unit - 115V (A095/A096)	65- *
A096 4005	Fusing Unit - 220/230V (A095/A096)	65- *
A096 4041	Fusing Exit Unit	67- *
A096 4080	Oil Supply Unit (A097 EU)	65-60
A096 4101	Front Fusing Bracket	65-32
A096 4105	Rear Fusing Bracket	65-21
A096 4111	Fusing Right Stay	65-25

Part No.	Description	Page and Index No.
A096 4115	Fusing Left Stay	65- 8
A096 4121	Fusing Unit Rail	65- 4
A096 4131	Upper Entrance Guide	65-29
A096 4135	Lower Entrance Guide	65-26
A096 4141	Upper Guide Bracket (A095/A096 EU,A097 NA)	65-28
A096 4142	Spring Plate (A095/A096 EU,A097 NA)	65-58
A096 4151	Fusing Cover	65- 5
A096 4155	Rail Cover	65- 1
A096 4161	Lower Fusing Cover	65-27
A096 4171	Front Heater Holder	65-35
A096 4173	Rear Heater Holder	65- 13
A096 4175	Front Pressure Lever	65-31
A096 4177	Rear Pressure Lever	65-22
A096 4181	Front Release Bracket	65-30
A096 4185	Rear Release Bracket	65-23
A096 4221	Thermistor	65- 3
A096 4224	Thermistor Pressuer Plate	65-36
A096 4225	Thermofuse 169°	65- 2
A096 4231	Fusing Connector Bracket	65- 14
A096 4251	Fusing Unit Rail	99- 12
A096 4261	Fusing Lock Lever	99- 11
A096 4271	Fusing Unit Stopper	99- 13
A096 4301	Fusing Exit Cover	67- 1
A096 4303	Fusing Exit Grip	67- 7
A096 4304	Grip Spring Plate	67- 3
A096 4309	Lower Fusing Exit Guide	67- 19
A096 4313	Stripper Stay	67- 13
A096 4316	Stripper Release Slider	67- 11
A096 4319	Exit Roller Holder	67- 16
A096 4322	Upper Fusing Exit Guide	67- 18
A096 4406	Rear Exit Bracket	71- 9
A096 4408	Front Exit Bracket	71- 30
A096 4417	Exit Cover	71- 4
A096 4423	Upper Exit Guide	69- 7
A096 4427	Pulley Tightener	71- 18

Part No.	Description	Page and Index No.
A096 4434	Inner Inverter Guide	71- 23
A096 4441	Inverter Weight	71- 28
A096 4446	Sensor Feeler	71- 27
A096 4453	Upper Inverter Guide	71-21
A096 4457	Outer Inverter Guide	71- 8
A096 4461	3rd Inverter Drive Roller (A095/A096)	71- 7
A096 4468	Exit Sensor Bracket	71- 1
A096 4472	Junction Gate	69- 11
A096 4473	Junction Gate Solenoid	69- 19
A096 4477	Lower Exit Guide	69- 14
A096 4487	Upper Exit Guide	69- 8
A096 4488	Entrance Sensor Bracket	69- 16
A096 4492	Lever Release Arm	93- 3
A096 4493	Release Arm Bracket	93- 1
A096 4495	Inverter Guide Lever .	69-22
A096 4497	Front Exit Unit Bracket	93- 4
A096 4498	Rear Exit Unit Bracket	99- 8
A096 4501	Duplex Unit (A095/A096)	73- *
A096 4587	Left Duplex Rail	99- 6
A096 4591	Right Duplex Rail	99-22
A096 4595	Duplex Guide	77-38
A096 4611	Feed Roller Stay	73- 16
A096 4622	Feed Roller Arm (A095/A096)	73- 18
A096 4630	Feed Roller Shaft	73-21
A096 4646	Pressure Plate Arm	73- 9
A096 4649	Paper End Feeler (A095/A096)	73- 7
A096 4650	Pressure Plate	73- 8
A096 4657	Solenoid Bracket	73-37
A096 4658	Feed Roller Solenoid	73-36
A096 4665	Release Lever - Pressure Plate	73-31
A096 4666	Release Lever - Feed Roller	73-35
A096 4673	Pressure Plate Solenoid	73-30
A096 4674	Solenoid Bracket	73-38
A096 4693	Jogger Motor bracket	77-33
A096 4705	Lower Jogger Stay	77- 12

Part No.	Description	Page and Index No.
A096 4711	Jogger Guide	77- 13
A096 4715	Jogger Support Bracket	77- 11
A096 4718	Wire Fixing Plate	77- 10
A096 4731	Jogger Table	75- 20
A096 4732	Right Sensor Bracket	75- 22
A096 4733	Sensor Harness Bracket	75- 23
A096 4742	Front Jogger Fence	73- 10
A096 4745	Front Jogger Fence Guide	73- 39
A096 4750	Front Paper Flatenner	73- 11
A096 4760	Rear Jogger Fence	73- 17
A096 4765	Rear Paper Flatenner	73- 22
A096 4805	Gear Bracket	77- 25
A096 4810	Inner Separation Guide	75- 19
A096 4819	Lower Turn Guide	75- 24
A096 4836	Separation Belt Stay	75- 4
A096 4840	Hook	75- 6
A096 4844	Release Lever	75- 2
A096 4848	Front Turn Guide (A095/A096)	75- 8
A096 4849	Rear Turn Guide (A095/A096)	75- 3
A096 4861	Friction Belt Bracket	75- 14
A096 4865	Friction Belt Lever	75- 11
A096 4867	Separation Entrance Guide	75- 15
A096 4876	Front Support Bracket	73- 19
A096 4882	Release Bracket	73- 2
A096 4883	Duplex Lock Lever	73- 3
A096 4884	Duplex Release Lever	73- 1
A096 4891	Lever Exit Guide	77- 15
A096 4894	Duplex Harness Bracket	75- 26
A096 4896	Rear Left Harness Bracket	77- 18
A096 4897	Harness Cover	73- 13
A096 4901	Transport Tightener	77- 31
A096 4912	Duplex Inner Cover	73- 5
A096 4923	Right Spring Plate	75- 28
A096 4924	Guide Plate Stopper	75- 32
A096 4925	Driven Roller Holder	75- 41

Part No.	Description	Page and Index No.
A096 4926	Roller Holder Bracket	75- 42
A096 4927	Lower Transport Guide	75- 29
A096 4928	Guide Plate Band	75-33
A096 4929	Guide Plate Lever	75- 37
A096 4933	Guide Plate Lever Hook	75-38
A096 4935	Transport Guide Holder	75- 18
A096 4936	Guide Positioning Plate	77- 37
A096 4937	Driven Roller Guide	75- 40
A096 4941	Upper Transport Guide	77- 8
A096 5110	x/o MB12	89- 10
A096 5110	x/o MB12	105- *
A096 5112	Main Control Board - 115V (A096)	89- 10
A096 5112	Main Control Board - 115V (A096)	105- *
A096 5115	x/o MB12	89- 10
A096 5115	x/o MB12	105- *
A096 5117	Main Control Board - 115/230V (A096 EU/A097)	89- 10
A096 5117	Main Control Board - 115/230V (A096 EU/A097)	105- *
A096 5121	IC - AM27C020-150DC	89-22
A096 5121	IC - AM27C020-150DC x/o MB12	105- 1
A096 5123	IC - AM27C512-120DC	89-23
A096 5123	IC - AM27C512-120DC x/o MB12	105- 2
A096 5125	RAM Board	89- 11
A096 5125	RAM Board .	105- 4
A096 5129	IC - M37409M2-155FP	105- 3
A096 5130	High Voltage Control Board	89- 9
A096 5140	Optics Control Board (A095/A096)	89- 1
A096 5151	IC - AM27C040-150DC	105- 1
A096 5153	IC - AM27C010-120DC	105- 2
A096 5175	AC Drive Board - 115V	89-20
A096 5195	Lightning Arrester Board - 115V	91- 7
A096 5200	Registration Sensor Board	35- 1
A096 5210	Erase Lamp Unit	59- 2
A096 5220	ID Sensor Board	61-30
A096 5230	ADS Board	23- 18
A096 5300	Tandem Tray Motor - DC11W	47- 18

Part No.	Description	Page and Index No.
A096 5301	Tandem Tray Motor - DC17W	45- 4
A096 5305	Development Drive Motor-DC4.1W(A095/A096)	79- 1
A096 5306	Brushless Motor -DC 16W (A095/A096)	79- 19
A096 5307	Paper Feed Motor - DC 10.7/8.22W	79- 2
A096 5308	Bank Drive Motor - DC23.5W	83- 29
A096 5310	Auto Response Sensor	13- 5
A096 5315	Pre-transfer Lamp	61- 32
A096 5320	Quenching Lamp	59- 37
A096 5325	Bottle Drive Motor - DC5.2W	57- 20
A096 5330	Toner Collection Motor -DC12W	83- 18
A096 5335	Paper Size Switch	33- 15
A096 5400	DC Main Harness (A096)	95- 14
A096 5404	DF Harness - 230V	95- 1
A096 5405	By-pass Feed Harness	37- 17
A096 5406	Upper Switch Harness	93- 14
A096 5409	ARS Harness	13- 41
A096 5410	Paper Feed Control Harness (A095)	91- 3
A096 5411	Upper Feed Unit Harness	39- 1
A096 5412	Lower Feed Unit Harness	39- 30
A096 5413	Motor Control Harness (A096)	83- 32
A096 5414	Toner Collection Harness	83- 31
A096 5415	Tray Set Harness	85- 15
A096 5415	Tray Set Harness (A096/A097)	87- 22
A096 5416	Paper Size Harness	85- 14
A096 5417	Tandem Tray Harness (A096/A097)	87- 14
A096 5418	Left Tandem Tray Harness	47- 14
A096 5419	Right Tandem Tray Harness	45- 11
A096 5420	Fusing Unit Harness	65- 15
A096 5421	Exit Unit Harness	71- 32
A096 5422	Exit Sensor Harness	71- 3
A096 5430	Duplex Unit Harness (A095/A096)	75- 25
A096 5431	Duplex Extension Harness	95- 24
A096 5432	Duplex Relay Harness	37-45
A096 5432	Duplex Relay Harness (A095/A096)	73- 33
A096 5440	Drum Unit Harness	61- 44

Part No.	Description	Page and Index No.
A096 5441	Drum Unit Harness	95- 18
A096 5442	Corona Cleaner Harness	59- 5
A096 5443	Transfer Unit Harness	63- 24
A096 5444	Transfer Belt Harness	99- 18
A096 5446	Development Bias Cable	95- 21
A096 5450	AC Harness	93-23
A096 5450	AC Harness	95- 19
A096 5451	o/o MB23	95-23
A096 5452	Fusing Harness - 115V	95- 15
A096 5453	Anticondensation Heater Harness 1	99- 26
A096 5460	Paper Bank AC Harness - 115V	91- 14
A096 5461	Noise Filter Harness	91- 13
A096 5462	Circuit Breaker Harness	91- 11
A096 5463	Anticondensation Heater Harness 2	87-33
A096 5470	Right Optics Harness	29- 35
A096 5471	Lower Optics Harness - 230V	25- 23
A096 5472	Optics Harness	19- 7
A096 5473	Outer Optics Harness	23- 31
A096 5474	Platen Cover Harness	23- 30
A096 5476	Exposure Support Harness	27- 24
A096 5477	Exposure Lamp Harness	27- 14
A096 5482	Lens Drive Harness	31-28
A096 5501	Main Board Bracket	89- 12
A096 5505	Right Hnge - Main Board	95- 3
A096 5506	Left Hinge - Main Board	95- 5
A096 5507	Left Angle - Main Board	95- 4
A096 5508	Right Angle - Main Board	95- 13
A096 5509	Upper Support Plate	89- 2
A096 5510	Power Supply Bracket	91- 10
A096 5511	Circuit Breaker Bracket - 115V	91- 9
A096 5515	Board Bracket - Paper Feed	91- 1
A096 5516	AC Drive Board Bracket	89-21
A096 5517	Angle - DC PSU Board	83-20
A096 5518	Harness Cover	95-26
A096 5519	Relay Bracket	95- 7

Part No.	Description	Page and Index No.
A096 5520	Connector Support Plate	95- 10
A096 5521	AC Harness Bracket	95- 6
A096 5522	Connector Bracket - DC PSU	95- 11
A096 5523	Connector Bracket	95- 12
A096 5524	Option Connector Bracket	95- 8
A096 5525	DF Connector Bracket	95- 2
A096 5528	Micro Switch Sheet	101- 35
A096 5529	Micro Switch Bracket	101- 31
A096 5530	Upper Switch Bracket	93- 15
A096 5532	Upper Switch Lever	93- 17
A096 5533	Upper Switch Arm	93- 16
A096 5535	Key Counter Stay	97-28
A096 5536	ARS Harness Cover	21-25
A096 5590	Right Upper Harness Cover	99-25
A096 6075	Lower Rear Fixing Plate	97- 12
A096 6076	Upper Rear Fixing Plate	97- 10
A096 6077	Upper Front Fixing Plate	97- 22
A096 6078	Right Front Frame	97- 17
A096 6079	Right Rear Frame Joint	97- 13
A096 6080	Left Frame Joint	97- 18
A096 6081	Collection Bottle Stopper	97- 14
A096 6100	Lower Heat Sink	97- 24
A096 6101	Upper Heat Sink	87- 30
A096 6110	Harness Cover	97- 27
A096 6111	4th Tray Cover	97- 34
A096 6164	Push Switch Bracket	85- 11
A096 6164	Push Switch Bracket (A096/A097)	87- 20
A096 6168	Lift Motor Bracket	85- 4
A096 6168	Lift Motor Bracket (A096/A097)	87- 12
A096 6169	Lift Motor Joint	85- 7
A096 6169	Lift Motor Joint (A096/A097)	87- 8
A096 6170	Support Side Plate (A096/A097)	87- 10
A096 6171	Sensor Support Plate	85- 1
A096 6172	Volume Sensor Bracket	85- 2
A096 6174	Paper Tray Stopper	85- 13

Part No.	Description	Page and Index No.
A096 6174	Paper Tray Stopper (A096/A097)	87- 19
A096 6177	Paper Size Bracket	85- 8
A096 6177	Paper Size Bracket (A096/A097)	87- 16
A096 6181	Front Side Plate - P/B	97- 29
A096 6184	Bank Inner Cover	101- 12
A096 6186	Lower Tightener - P/B	83- 22
A096 6188	Upper Tightener - P/B	83- 11
A096 6190	Middle Guide Plate	101- 34
A096 6198	Paper Feed Drive Shaft	83- 27
A096 6241	Left Rail - Tandem Tray (A096/A097) MB14	97- 20
A096 6246	Left Rail Bracket MB14	97- 35
A096 6247	Tray Lock Arm - Tandem Tray(A096/A097) MB14	97- 19
A096 6250	Right Rail	97- 21
A096 6261	Left Rail	97- 20
A096 6266	Tray Lock Arm	97- 19
A096 6270	Tandem Tray Stay	87- 28
A096 6271	Middle Stay 1	87- 25
A096 6273	Middle Rail Stay	87- 24
A096 6274	Middle Rail 1	87- 23
A096 6276	Middle Stay 2	87- 27
A096 6277	Middle Slide Rail 2	87- 26
A096 6278	Middle Rail Stopper	87- 29
A096 6303	Separation Roller Stay	39- 44
A096 6306	Separation Drive Shaft	39- 34
A096 6307	Separation Driver Shaft	39-47
A096 6308	Separation Pressure Lever	39- 42
A096 6311	Release Lever	39- 36
A096 6315	Release Solenoid	39- 35
A096 6321	Position Sensor Bracket	39-50
A096 6322	Position Sensor Feeler	39-51
A096 6330	Rear Side Plate	39- 32
A096 6335	Front Side Plate	39-56
A096 6337	Paper Feed Guide	39- 14
A096 6338	Separation Guide	39- 22
A096 6342	Paper End Feeler	39- 9

Part No.	Description	Page and Index No.
A096 6344	Paper End Actuater	39- 2
A096 6345	End Sensor Bracket	39- 3
A096 6346	Paper Feed Stay	39- 8
A096 6351	Pick-up Arm	39- 15
A096 6352	Feed Roller Bracket	39- 16
A096 6353	Feed Roller Lever	39- 12
A096 6355	Pick-up Solenoid	39- 7
A096 6358	Photointerrupter Bracket	39- 6
A096 6360	Paper Flatenner	39-23
A096 6366	Clutch Stopper Arm	39- 27
A096 6369	Vertical Transport Guide	39- 40
A096 6375	Unit Fixing Plate	39-54
A096 6381	Unit Fixing Plate - 3rd	39-53
A096 6402	Pressure Plate Driven Roller	101- 7
A096 6403	Front Side Plate	101- 22
A096 6404	Rear Side Plate	101- 8
A096 6405	Lower Transport Guide	101- 10
A096 6408	Guide Pressure Stay	101- 20
A096 6411	Release Lever Bracket	101- 25
A096 6412	Spring Plate	101- 21
A096 6413	Release Lever Cover	101- 23
A096 6421	Upper Front Side Plate	101- 1
A096 6422	Upper Rear Side Plate	101- 3
A096 6423	Upper Transport Guide	101- 2
A096 6511	Universal Tray-LT	43- *
A096 6512	Universal Tray-A4	43- *
A096 6524	Lift Shaft	41- 10
A096 6524	Lift Shaft	43- 21
A096 6526	Lift Lever	41- 11
A096 6526	Lift Lever	43- 23
A096 6527	Paper Guide Feeler	41- 12
A096 6527	Paper Guide Feeler	43- 22
A096 6534	Front Side Fence	43- 8
A096 6536	Side Fence Cover	43- 28
A096 6537	Stopper Lever	43- 2

Part No.	Description	Page and Index No.
A096 6539	Side Fence Gear	43- 13
A096 6541	Rear Side Fence	43- 11
A096 6544	Side Fence Plate- A4	43- 12
A096 6545	Side Fence Plate - LT	43- 12
A096 6549	Front Side Fence	41- 1
A096 6550	Rear Side Fence	41- 7
A096 6551	Positioning Plate - Side Fence	41- 9
A096 6553	Side Fence Pad	43- 18
A096 6556	Tray Bottom Plate	41- 6
A096 6556	Tray Bottom Plate	43- 10
A096 6562	End Fence	43- 3
A096 6563	End Fence Cover	43- 1
A096 6564	End Fence Plate	43- 4
A096 6568	Positioning Plate - End Fence	41- 4
A096 6577	Size Sensor Slider	43- 16
A096 6578	Size Sensor Plate	43- 15
A096 6589	Paper Tray Cover - Short	41- 13
A096 6589	Paper Tray Cover - Short	43- 5
A096 6600	Tandem Tray	45- *
A096 6607	Rear Bottom Plate	47- 19
A096 6620	Paper Tray Cover - Long	41- 13
A096 6620	Paper Tray Cover - Long	47-25
A096 6629	Middle Bottom Plate	47- 4
A096 6632	Tandem Tray Slider	47- 8
A096 6633	Right Rod Holder	47- 7
A096 6634	Left Rod Holder	47- 5
A096 6636	Tightener Bracket	47- 17
A096 6640	Front Bottom Plate	47-21
A096 6641	Grounding Plate 1	47- 3
A096 6642	Grounding Plate 2	47- 20
A096 6644	Left Rear Side Fence	47- 10
A096 6645	Right Front Side Fence	45-23
A096 6646	Front End Fence Guide	45-25
A096 6647	Rear End Fence Guide	45- 12
A096 6648	Right Rear Side Fence	45- 17

Part No.	Description	Page and Index No.
A096 6649	Grounding Spring Plate	47- 28
A096 6652	Lift Shaft	45- 8
A096 6653	Lift Shaft Bracket	45- 10
A096 6654	Lift Lever	45- 7
A096 6655	x/o MB1	45- 9
A096 6656	Paper Volume Feeler	45- 9
A096 6658	Rear End Fence Gear	45- 2
A096 6659	Front End Fence Gear	45- 3
A096 6662	Right Front End Fence	45- 24
A096 6666	Right Rear End Fence	45- 13
A096 6668	Release Pawl	45- 15
A096 6669	LCT Stopper	45- 21
A096 6669	LCT Stopper	49- 16
A096 6670	Timing Belt Roller	47- 24
A096 6671	Paper Guide Plate	45- 18
A096 6672	Motor Cover	45- 1
A096 6673	Bottom Plate	45- 6
A096 6674	Right Tandem Tray	45- 22
A096 6676	Side Fence Support Plate	45- 27
A096 6681	Lock Solenoid Bracket (A096/A097)	87- 3
A096 6683	Tray Lock Solenoid (A096/A097)	87- 5
A096 6687	Lock Solenoid Arm (A096/A097)	87- 1
A096 6689	Right Connector Bracket (A096/A097)	87- 13
A096 6690	Left Connector Bracket (A096/A097)	87- 15
A096 6691	Sensor Bracket (A096/A097)	87- 6
A096 6736	Front Side Plate	51- 2
A096 6741	Rear Side Plate	51- 14
A096 6745	Right Side Plate	49- 14
A096 6752	End Fence Rail	49- 8
A096 6753	Rail Shaft	49- 9
A096 6758	End Fence Slider	49-23
A096 6760	End Fence	49- 7
A096 6765	Tray Bottom Plate	49- 10
A096 6770	Bottom Plate Stay	51- 8
A096 6782	Motor Bracket	49- 6

Part No.	Description	Page and Index No.
A096 6784	LCT Drive Shaft	49- 3
A096 6789	Lower Sensor Bracket	51- 11
A096 6794	Upper Sensor Bracket	51- 13
A096 6799	Paper Sensor Bracket	51- 10
A096 6806	LCT Front Cover	49- 18
A096 6808	LCT Inner Cover	49- 17
A096 6811	Push Switch Bracket	49- 19
A096 6815	Harness Bracket	91- 16
A096 6818	Stopper Bracket	97-26
A096 7450	Paper Feed Board (A096/A097)	91- 2
A096 7500	Lightning Arrester Board - 220/230V	91- 7
A096 7560	Operation Panel Board - 115V	17- 23
A096 7570	Operation Panel Board (ASIA)	17- 23
A096 7571	Operation Panel Board - 220/230V	17- 23
A096 7580	AC Drive Board - 230V	89-20
A096 7600	Power Supply Cord - 115V	91- 8
A096 7601	Power Supply Cord - 220/230V	91- 8
A096 7605	Paper Bank AC Harness - 220/230V	91- 14
A096 7606	Fusing Harness - 230V	95- 15
A096 7630	LCT Harness (A096/A097)	91- 3
A096 7631	LCT Relay Harness	91- 15
A096 7632	LCT Harness	51- 7
A096 7633	Lower Optics Harness - 115V	25- 23
A096 7634	Total Counter Harness	93- 13
A096 7635	Main Relay Harness - 115/230V	95-23
A096 7636	DF Harness - 115V	95- 1
A096 7660	Total Counter Bracket	93- 11
A096 7661	Bracket - Power Supply Cord	91- 12
A096 7662	Circuit Breaker Bracket - 220/230V	91- 9
A096 7701	IC-AM27C4096-150DC (115V)	17- 17
A096 7702	IC-AM27C1024-150DC (115V)	17-21
A096 7704	IC-AM27C010-150DC (115V)	17-22
A096 7711	IC - AM27C4096-150DC (ASIA)	17- 17
A096 7712	IC - AM27C1024-150DC (ASIA)	17-21
A096 7714	IC - AM27C010-150DC (ASIA)	17- 22

Part No.	Description	Page and Index No.
A096 8607	Operating Instructions - English LT	107- 25
A096 9500	Hot Roller Stripper 5pcs/set	67- 14
A096 9501	Duplex Friction Belt - 3pcs/set	75- 17
A096 9510	OPC Drum	61- 6
A096 9520	Editing Sheet-A4 MB3 (ADDED)	13- 51
A096 9521	Editing Sheet-LT MB3 (ADDED)	13- 51
A096 9533	Fuse-125V/4A MB10 (ADDED)	49- 24
A097 1368	Right Door(A097)	13- 17
A097 1727	Cooling Fan Filter	21- 2
A097 1860	1st Scanner Position Bracket	27- 8
A097 3050	Development Unit (A095/A096/A097)	53- *
A097 3510	Lower Drum UnitA095/A096)	61- *
A097 3511	Lower Drum Unit (A097)	61- *
A097 3644	Transport Guide Bracket (A097)	61- 54
A097 4007	Fusing Unit-220/230V (A097)	65- *
A097 4009	Fusing Unit- 115V(A097)	65- *
A097 4080	Oil Suppiy Unit(A097 EU)	65- 60
A097 4122	Cleaning Roller Bracket (A097)	65-53
A097 4126	Left Holder (A097)	65-54
A097 4129	Right Holder (A097)	65-55
A097 4132	Upper Guide Bracket - 115V (A095/A096)	65-28
A097 4133	Lock Lever	65-41
A097 4141	Upper Guide Bracket (A097 EU)	65-28
A097 4142	Spring Plate (A097 EU)	65-58
A097 4143	Cleaning Roller Blade (A097 EU)	65-59
A097 4170	Front Heater Holder - 120V (A097)	65-35
A097 4173	Rear Heater Holder - 120V (A097)	65- 13
A097 4225	Thermofuse 169°C - 120V (A097)	65- 2
A097 4252	Cleaning Roller Bracket MB1 (OBS)	65-45
A097 4254	Front Hinge Bracket MB1 (OBS)	65-49
A097 4256	Spring Plate - Cleaning Roller MB1 (OBS)	65-46
A097 4258	Rear Hinge Bracket MB1 (OBS)	65-48
A097 4261	Fusing Cleaning Roller (A095/A096) MB1	65-50
A097 4461	3rd Inverter Drive Roller (A097)	71- 7
A097 4502	Duplex Unit (A097)	73- *
A097 4622	Feed Roller Arm (A097)	73- 18
A097 4735	Harness Cover (A097)	75- 50
A097 4848	Front Turn Guide (A097)	75- 8
A097 4849	Rear Turn Guide (A097)	75- 3
A097 5140	Optics Control Board (A097)	89- 1
A097 5305	Development Drive Unit (A097)	79- 1
A097 5306	Brushless Motor -DC 24V 29.6W (A097)	79- 19
A097 5400	DC Main Harness (A097)	95- 14
A097 5420	Fusing Unit Harness - 120V (A097)	65- 15
A097 5540	Fan Motor Bracket (A097)	89-26
A097 5541	Filter Bracket (A097)	89- 28
A097 5550	Fan Motor Bracket (A097)	101- 38
A097 5551	Fan Motor Duct (A097)	101- 40
A097 5552	Fan Plate (A097)	101- 37
A097 5553	Cooling Fan Motor - DC24V 9.6W (A097)	101- 39
A097 6000	Separation Torque Limiter (A097)	39- 48
A097 7630	Duplex Unit Harness (A097)	75- 25
A097 7631	Duplex Relay Harness (A097)	75- 51

Part No.	Description	Page and Index No.
AA00 0059	Caution Decal - English	101- 16
AA00 0059	Caution Decal - English	107- 7
AA00 0134	Decal - Tray Universal	43- 7
AA00 0134	Decal - Tray Universal	107- 24
AA00 0136	Decal - Left Tandem Tray	47- 2
AA00 0136	Decal - Left Tandem Tray	107- 8
AA00 0137	Decal - Tandem Tray 1	47-26
AA00 0137	Decal - Tandem Tray 1	107- 9
AA00 0138	Decal - No.2	43- 6
AA00 0138	Decal - No.2	107- 10
AA00 0139	Decal - No.3	41- 14
AA00 0139	Decal - No.3	49-21
AA00 0139	Decal - No.3	107- 11
AA00 0143	Decal - No.1	41- 14
AA00 0144	Decal - Right Tandem Tray	45- 29
AA00 0144	Decal - Right Tandem Tray	107- 12
AA00 0149	Decal - Fuse - 115V	95-25
AA00 1213	Decal - B2	37-44
AA00 1213	Decal - B2	107- 13
AA00 1322	Decal - Bottle Set	57-28
AA00 1322	Decal - Bottle Set	107- 14
AA00 1323	Decal - Bottle Shutter	57-27
AA00 1323	Decal - Bottle Shutter	107- 15
AA00 1324	Decal - Duplex Lever	75- 46
AA00 1324	Decal - Duplex Lever	107- 16
AA00 1326	Decal - A1	101- 33
AA00 1326	Decal - A1	107- 17
AA00 1327	Decal - Misfed Removal A2	107- 18
AA00 1331	Decal - E2	69-23
AA00 1331	Decal - E2	107- 26
AA00 2010	Decal - Paper Level	41- 8
AA00 2010	Decal - Paper Level	43- 17
AA00 2010	Decal - Paper Level	45- 19
AA00 2010	Decal - Paper Level	47- 11
MOO 2010	Decal - Paper Level	107- 19

Part No.	Description	Page and Index No.
AA00 2175	Decal - Paper Size - A4	33- 11
AA00 2175	Decal - Paper Size - A4	107-23
AA00 2176	Decal - Side Fence - A4	43-29
AA00 2176	Decal - Side Fence - A4	107-20
AA00 2177	Decal - Side Fence - LT	43-29
AA00 2177	Decal - Side Fence - LT	107-20
AA00 2178	Decal - End Fence - A4	43-20
AA00 2178	Decal - End Fence - A4	107-21
AA00 2179	Decal - End Fence - LT	43-20
AA00 2179	Decal - End Fence - LT	107-21
AA00 2181	Decal - LT	43- 19
AA00 2181	Decal - LT	107-22
AA00 2184	Decal - A4	43- 19
AA00 2184	Decal - A4	107-22
AA00 2192	Decal - Paper Size - LT	33- 11
AA00 2192	Decal - Paper Size - LT	107-23
AA01 2060	Development Filter	53- 2
AA01 2061	o/o MB5	21- 1
AA01 2073	Filter	21- 1
AA01 2075	Filter (A097)	89-29
AA02 0001	Drawer Tray Magnet	71-33
AA02 1025	Magnet Catch	33- 5
AA02 1025	Magnet Catch	75-27
AA02 1026	Magnet Catch	67- 12
AA03 2020	Toner Collection Tank	101- 13
AA04 2008	Pick-Up Belt	73- 20
AA04 3219	Timing Belt - B40S2M1066	25- 4
AA04 3220	Timing Belt - B40S2M560	31- 17
AA04 3221	Timing Belt - B40S2M280	29-32
AA04 3222	Timing Belt - 525P3M6	81- 18
AA04 3223	Timing Belt - 426P2M4	81- 17
AA04 3224	Timing Belt - 310P2M3	81-31
AA04 3227	Timing Belt -	23- 14
AA04 3228	Timing Belt - 71P2M6	77- 29
AA04 3229	Timing Belt - 302P2M	71- 10

Part No.	Description	Page and Index No.
AA04 3344	Timing Belt - P3M675	83- 25
AA04 3345	Timing Belt - B30S3M888	47- 12
AA04 3346	Timing Belt - 560P2M6	79- 18
AA05 0058	Jogger Drive Wire	77- 40
AA05 0077	Front Scanner Drive Wire	23- 8
AA05 0078	Rear Scanner Drive Wire	23- 7
AA05 0083	LCT Drive Wire - 1785mm	51- 17
AA06 0244	Spring	79- 22
AA06 0262	Spring	57-33
AA06 0276	Spring x/o MB1	75- 10
AA06 0291	Spring	55- 9
AA06 0328	Pressure Spring	77- 30
AA06 0386	Pressure Spring	23- 6
AA06 0469	Lock Spring	75- 5
AA06 0514	Tension Spring - 21.5mm	25- 21
AA06 0515	Tension Spring - 23.4mm	29- 11
AA06 0516	Tension Spring - 42mm	31- 3
AA06 0517	Pick-up Release Spring	35- 19
AA06 0518	Pick-up Pressure Spring	35-25
AA06 0519	Tension Spring - 62mm	19- 3
AA06 0520	Lever Spring - 24.4mm	39-43
AA06 0521	Lower Release Spring	39-59
AA06 0522	Stopper Spring	39- 13
AA06 0523	Pick-up Pressure Spring	39- 10
AA06 0524	Tension Spring - 24.8mm	83-23
AA06 0525	Tension Spring - 43MM	83- 10
AA06 0530	Belt Tension Spring - 29.3mm	23- 12
AA06 0532	Tension Spring - 24.5mm	81-29
AA06 0534	Tray Lock Spring - 19mm	97-30
AA06 0535	Lock Solenoid Spring (A096/A097)	87- 4
AA06 0536	Release Spring - Feed Roller	73- 34
AA06 0537	Release Spring - Pressure Plate	73-32
AA06 0539	Stripper Pawl Spring	67- 9
AA06 0540	Pressure Spring (A095/A096)	65-24
AA06 0541	Bushing Lock Spring	99- 10

Part No.	Description	Page and Index No.
AA06 0542	Tension Spring	47- 16
AA06 0543	Tension Spring - 34.4mm	81- 30
AA06 0562	Pressure Spring (A097)	65- 24
AA06 0570	Tray Lock Spring - 20mm (Tandem) x/o MB14	97-30
AA06 0581	Spring - 18.8mm	75- 10
AA06 0592	Lock Spring - Tandem Tray	97- 30
AA06 3052	Turret Spring	93-24
AA06 3068	Spring Connector	95- 17
AA06 3164	Pressure Spring	37-38
AA06 3167	Pressure Spring	85- 6
AA06 3167	Pressure Spring (A096/A097)	87- 9
AA06 3170	Drive Change Spring	57- 16
AA06 3248	Charge Terminal Spring	59- 21
AA06 3249	Grid Terminal Spring	59- 22
AA06 3253	Tension Spring - 20mm	31- 19
AA06 3254	Driven Roller Spring	37- 41
AA06 3255	Exit Roller Spring	37- 43
AA06 3259	Connector Spring	91- 17
AA06 3263	o/o MB19	53- 18
AA06 3266	Pressure Spring -1KGF (A095/A096 EU,A097 NA)	65-40
AA06 3268	Connector Spring	87- 32
AA06 3272	Grounding Spring	53- 18
AA06 3280	Pressure Spring - 1.8KGF (A097 EU)	65- 40
AA06 3373	Spring - 60mm x/o MB17	61- 3
AA06 3374	Toner Receiving Spring	61-20
AA06 3375	Spring - 24.3mm	83- 3
AA06 3378	Driven Roller Spring	75- 35
AA06 3379	Stopper Spring - 22mm	43- 27
AA06 3380	Spring - 16mm	61- 19
AA06 3384	Pick-off Pawl Shaft Spring	61- 3
AA06 3487	Spring -10mm	39-41
AA06 3487	Spring -10mm	101- 6
AA06 3489	Spring - 45mm	63-26
AA06 3490	Spring - 21.6mm	79- 8
AA06 3490	Spring - 21.6mm	81- 11

Part No.	Description	Page and Index No.
AA06 6110	Grip Spring	13- 34
AA06 6189	Feed Sensor Spring	39-46
AA06 6209	Shutter Spring	57- 11
AA06 6211	Rear Lock Spring	37- 10
AA06 6213	Feeler Spring	35-23
AA06 6214	Front Pawl Spring	61-37
AA06 6215	Rear Pawl Spring	61- 36
AA06 6216	Release Spring	39-37
AA06 6217	x/o MB2	63-38
AA06 6218	Unit Release Spring	99- 17
AA06 6219	Tray Lock Spring	45- 14
AA06 6220	Tension Spring -0.3	81-27
AA06 6222	Hook Spring	75- 7
AA06 6223	Grip Spring	73- 4
AA06 6224	Arm Release Spring	93- 2
AA06 6229	Left Guide Spring	69- 9
AA06 6230	Right Guide Spring	69- 10
AA06 6232	Lock Lever Spring MB1 (OBS)	65-43
AA06 6239	Cleaning Blade Spring	63-38
AA08 0034	Bushing - 4x5x7	37- 5
AA08 0034	Bushing - 4x5x7	69- 2
AA08 0034	Bushing - 4x5x7	71- 26
AA08 0037	Bushing -6 mm	37-37
AA08 0147	Front Bushing	59- 15
AA08 0148	Rear Bushing	59- 11
AA08 0150	Bushing - 6x16x12.8	53- 19
AA08 0152	Bushing - 4x12x13	53- 14
AA08 0154	Rear Bushing	61-40
AA08 0155	Rear Pawl Bushing	61- 1
AA08 0156	Bushing - M4	39-39
AA08 0156	Bushing - M4	101- 5
AA08 0157	Bushing - 8x32x9	63- 4
AA08 0158	Bushing - 12x16x12.1	99-21
AA08 0184	Bushing - Fusing Unit	67- 6
AA08 2045	Cleaning Brush Bushing	61-22

Part No.	Description	Page and Index No.
AA08 2046	Bushing - 6x12x6	39-31
AA08 2046	Bushing - 6x12x6	69- 17
AA08 2046	Bushing - 6x12x6	71- 31
AA08 2047	Bushing - 8x16x7	39- 17
AA08 2059	Agitator Bushing MB11 (ADDED)	61- 47
AA08 2063	Bushing - 8x10x5 (A097)	65-52
AA08 3003	Bushing - 6x18x5mm	75-43
AA08 3005	Roller Clutch - 8x18x11	77- 2
AA08 4043	Rear Development Unit Holder	95- 9
AA10 0006	Flat Nut - 3.6x9.5x0.8	13- 45
AA10 0007	Ring - 7x13x5.5	25- 24
AA10 1010	Plate Nut - M5	23- 27
AA12 0005	Antistatic Brush	65- 12
AA12 0064	Antistatic Spacer	65- 19
AA12 0065	Antistatic Brush - Duplex	71- 20
AA13 2017	Pressuer Roller	99-27
AA13 2024	Spacer - M6	53-32
AA13 2024	Spacer - M6	61-27
AA13 2024	Spacer - M6	67- 15
AA13 2024	Spacer - M6	81- 12
AA13 2024	Spacer - M6	83- 2
AA13 2025	Spacer - 1x8x12	53-34
AA13 2025	Spacer - 1x8x12	61- 41
AA13 2129	Spacer - 8x12x4.5	35-37
AA13 2158	Collar	57- 17
AA13 2161	Lens Roller	31- 10
AA13 2163	Idler Shaft	19- 23
AA13 2169	Spacer - 5.7x16x1.5	45- 28
AA13 2171	Spacer - 6x20x1	75- 48
AA14 0486	Lock Shaft	37- 6
AA14 0488	Separation Drive Shaft	37-25
AA14 0489	Shaft - Feed	35-22
AA14 0498	Feed Roller Shaft	39- 11
AA14 0499	Guide Rod	47- 6
AA14 0503	Separation Roller Shaft	77- 4

Part No.	Description	Page and Index No.
AA14 0504	Release Lever Shaft	73- 6
AA14 0529	Drive Wire Shaft	51- 1
AA14 3020	Stepped Screw - M4	69- 21
AA14 3037	Development Cover Screw	67- 20
AA14 3062	Shoulder Screw - M4	29- 36
AA14 3074	Stepped Screw - M4x5	71- 19
AA14 3074	Stepped Screw - M4x5	77- 42
AA14 3183	Stepped Screw	75- 44
AA14 3290	Stepped Screw - M4	57- 26
AA14 3307	Stepped Screw - M3x4	75- 45
AA14 3416	Stepped Screw - M4x3	13- 43
AA14 3416	Stepped Screw - M4x3	19- 22
AA14 3416	Stepped Screw - M4x3	53- 15
AA14 3417	Shoulder Screw - M4x4	19- 24
AA14 3426	Stopped Screw - M4x17	53- 31
AA14 3430	Shoulder Screw - M4x16	53- 17
AA14 5201	Friction Belt Shaft	75- 13
AA14 5203	Registration Drive Shaft	81- 33
AA14 5204	Cleaning Drive Shaft	81- 8
AA14 5205	Cleaning Relay Shaft	81- 10
AA14 5212	Upper Drive Shaft - P/F	83-26
AA14 5213	Duplex Drive Shaft	79- 7
AA14 5214	Fusing Drive Shaft	79- 16
AA14 8361	Click Guide	57- 30
AA15 0305	Seal - 20mm	19- 6
AA15 0332	Seal - 0.19x18x22	23- 29
AA15 0333	Seal - 0.19x14x74	21- 22
AA15 0334	Seal - 0.19x40x48	21-23
AA15 0336	Front Shielding Mylar	31- 7
AA15 0337	Rear Shielding Mylar	31- 6
AA15 0344	Mylar Seal - 11x350	61-26
AA15 0350	Seal - 40x130	59-39
AA15 0355	Handle Bracket Cover	57- 4
AA15 0357	Seal - 31x35	75- 47
AA15 0361	Slitter Cover Seal	55- 15

Part No.	Description	Page and Index No.
AA15 0628	Seal - 0.19x15x34	19- 17
AA15 0629	Seal - 0.19x28x108	19- 20
AA15 0632	Mylar Seal - 0.05x80x145	63- 43
AA15 1770	Middle Duct Seal	89- 8
AA15 1771	Seal - 5x10x138	89-25
AA15 1772	Duct Seal	99- 3
AA15 1773	Rear Duct Seal	99- 4
AA15 1774	Rear Duct Seal	89- 15
AA15 1780	Potential Sensor Cover	59- 41
AA15 1791	Hopper Entrance Seal	55- 2
AA15 1792	Seal - 3x15x85	55- 5
AA15 1793	Seal - 3x35x211	55- 6
AA15 1794	Seal - 3x5x322	55- 4
AA15 1795	Holder Seal	57- 32
AA15 1796	Stopper Seal	57- 31
AA15 1797	Holder Base Seal	57- 8
AA15 1798	Seal - 2x40x63	57- 3
AA15 1802	Eraser Cover Seal	59-40
AA15 1804	Lever Cushion	41- 15
AA15 1804	Lever Cushion	43- 25
AA15 1805	Bottom Plate Cushion	41- 16
AA15 1805	Bottom Plate Cushion	43- 24
AA15 1811	Inner Casing Seal	61-46
AA15 1814	Joint Seal - 21x32x10	79- 13
AA15 1816	Seal - 5x14x212	21- 3
AA15 1862	Bottle Shield	13- 49
AA15 1877	Outer Inverter Guide Seal	71- 35
AA15 1902	Belt Exit Seal	63-31
AA15 1925	Cleaning Seal 1 MB15 (ADDED)	61-50
AA15 1926	Cleaning Seal 2 MB15 (ADDED)	61-51
AA15 1927	Cleaning Seal 3 MB15 (ADDED)	61-52
AA15 1928	Cleaning Seal 4 MB15 (ADDED)	61-53
AA15 2142	Seal - 11x7x3.8mm	53-24
AA15 2225	Brush Seal - 6x10 - 288	31-24
AA15 2226	Front Drum Seal	53-30

Part No.	Description	Page and Index No.
AA15 2227	Rear Drum Seal	53- 8
AA15 2228	Brush Seal - 4x5x120	31- 12
AA15 2229	Seal - 9x114	19- 25
AA15 2314	Front Drum Seal	61- 28
AA15 2315	Tank Seal	101- 17
AA15 2323	Rear Drum Seal	61-31
AA15 3376	Brush Seal - 4.5x17x358	63-30
AA15 3377	Brush Seal-7x7.1x358 x/o MB2	63- 31
AA16 1014	Cushion Motor	79- 21
AA16 1014	Cushion Motor	81- 20
AA16 1014	Cushion Motor	83- 24
AA16 1034	Cleaner Cushion MB18 (ADDED)	59- 42
AA16 1070	Cushion - 5x6.5x12	71- 34
AA16 1076	Scanner Stopper	19- 16
AA16 1095	Pad - 2x8x8x	39-61
AA16 1096	Stopper Cushion	85- 10
AA16 1096	Stopper Cushion (A096/A097)	87- 18
AA16 2053	Platen Cover Pad	15- 2
AA16 2056	Pad - 7x12x22	71- 22
AA16 2062	Bottom Plate Cushion	45- 26
AA17 2012	Heat Shielding Sheet	65- 7
AA17 2013	Heater Cover	99- 28
AB01 0087	Gear - 20Z	59- 32
AB01 0089	Gear -352	73- 41
AB01 0333	Gear -262	63- 5
AB01 0334	Gear -342	63-35
AB01 0335	Gear - 22/482	63-36
AB01 0336	Gear - 22/362	63-39
AB01 0340	Gear -322 MB11 (ADDED)	61- 48
AB01 1127	Gear -522	37- 13
AB01 1128	Gear - 40Z	37- 15
AB01 1129	Gear -452	83- 4
AB01 1131	Gear -482	79- 3
AB01 3420	Gear -182	37- 24
AB01 3467	Gear - 30Z	77- 41

Part No.	Description	Page and Index No.
AB01 3492	Gear -16Z	33- 17
AB01 3492	Gear -16Z	43- 14
AB01 3569	Gear - 20Z	73- 42
AB01 3729	Gear -18Z	39- 45
AB01 3747	Gear -16Z	55- 11
AB01 3748	Joint Gear -15Z	55- 12
AB01 3749	Gear -15Z	55- 10
AB01 3770	Gear -24Z	81- 35
AB01 3771	Gear -32Z	81- 34
AB01 3772	Gear - 20Z	81- 9
AB01 3773	Gear -18Z	39- 33
AB01 3774	Gear -18Z	39- 26
AB01 3775	Gear -33Z	39- 25
AB01 3776	Gear - 30Z	39- 29
AB01 3777	Gear -32Z	39- 28
AB01 3778	Gear -32Z	39- 60
AB01 3779	Gear -32Z	39-55
AB01 3780	Gear - 28/16Z	39-58
AB01 3781	Gear - 30Z	83- 28
AB01 3783	Gear -34Z	53- 13
AB01 3785	Gear -43Z	53- 27
AB01 3786	Gear -18Z	53- 11
AB01 3788	Gear -23Z	53- 12
AB01 3790	Gear -25Z	53-35
AB01 3791	Gear -17Z	53- 10
AB01 3792	Gear -49Z	65- 18
AB01 3793	Gear -19Z	67- 4
AB01 3794	Gear -19Z	67- 5
AB01 3795	Gear -38Z	71- 14
AB01 3796	Gear -38Z	71- 15
AB01 3802	Gear - 30Z	73- 28
AB01 3807	Gear - 20Z	63- 7
AB01 5011	Gear -32Z	57-23
AB01 7039	Gear - 24/48T	29- 31
AB01 7039	Gear - 24/48T	31-23

Part No.	Description	Page and Index No.
AB01 7278	Gear - 14/40Z	57- 24
AB01 7284	Gear - 34/68Z	25- 6
AB01 7287	Joint Gear - 16Z	81- 13
AB01 7288	Cam Gear - 35Z	61- 10
AB01 7289	Gear - 17/45Z	83- 8
AB01 7290	Joint Gear -31 Z	79- 9
AB01 7291	Gear - 36Z	77- 19
AB01 7292	x/o MB8	65- 16
AB01 7293	Pulley Gear - 27/29Z	71- 11
AB01 7294	Pulley Gear - 18/20Z	71- 13
AB01 7296	Gear - 30/47Z	61- 8
AB01 7297	Gear - 21/32z	73- 29
AB01 7298	Gear - 21/55Z	73- 27
AB01 7299	Pulley - 77Z	25- 5
AB01 7300	Lens Drive Pulley	31-20
AB01 7301	Pulley - 25Z	29-30
AB01 7323	Cam Gear - 35Z	61- 5
AB01 7357	Gear - 31Z	65- 16
AB01 9474	Gear - 20Z	69- 18
AB03 0391	Timing Pulley - 22Z	83- 19
AB03 0392	Pulley - 18Z	71- 12
AB03 0395	Idle Pulley	71- 17
AB03 0412	Pulley - 25Z	29-33
AB03 0414	Pulley - 25Z	81-32
AB03 0415	Pulley - 25Z	81- 5
AB03 0416	Timing Pulley - 40Z	79- 14
AB03 0417	Timing Pulley - 32Z	47- 13
AB03 0418	Timing Pulley - 12Z	47- 15
AB03 0424	Timing Pulley - 40Z	23- 13
AB03 0425	Belt Tension Pulley	23- 11
AB03 0427	Pulley - 81Z	79- 6
AB03 0428	Timing Pulley - 20Z	77- 28
AB03 0429	Timing Pulley - 22Z	77- 26
AB03 0430	Pulley - 16Z	77- 27
AB03 0431	Transport Pulley	77- 32

Part No.	Description	Page and Index No.
AB03 0450	Timing Pulley - 24Z	23- 23
AB03 0458	Pulley - 28Z	81-37
AB03 2030	Pulley	77- 36
AB03 2031	Jogger Pulley	77- 34
AB03 2058	Wire Pulley - M10	51- 3
AB03 2716	Idle Pulley - M18	81- 19
AB03 2716	Idle Pulley - M18	83- 21
AB03 3048	Timing Pulley - 31/32Z	81- 22
AB03 3052	Pick-Up V Pulley	73- 25
AC01 2034	Exposure Glass (A095)	19- 4
AC01 2035	Exposure Glass (A096)	19- 4
AC03 0089	1st Mirror	27- 4
AC03 0090	2nd Mirror	29- 2
AC03 0091	3rd Mirror	29- 8
AC03 0092	4th Mirror	29- 13
AC03 0093	5th Mirror	29- 14
AC03 0094	6th Mirror	25- 14
AC03 5041	Front Spring Plate - 2nd	29- 1
AC03 5042	Rear Spring Plate - 2nd	29- 3
AC03 5043	Front Spring Plate - 3rd	29- 7
AC03 5044	Rear Spring Plate - 3rd	29- 6
AC03 5045	Front Spring Plate - 4th	29- 15
AC03 5046	Rear Spring Plate - 4th	29- 16
AC03 5047	Front Spring Plate - 5th	29- 18
AC03 5048	Rear Spring Plate - 5th	29- 17
AC03 5049	Front Spring Plate - 6th	25- 17
AC03 5050	Rear Spring Plate - 6th	25- 13
AC04 2072	Rear Scale - A4	19- 2
AC04 2076	Rear Scale - LT	19- 2
AC05 1013	Lens Guide Rod - X	25- 2
AC05 1014	Lens Guide Rod - Y	31- 15
AC05 1015	Guide Rod - 3rd Scanner	29- 25
AD00 4069	Charge Corona Unit	59- 9
AD02 0053	Charge Corona Wire	59- 19
AD02 1091	Charge Corona Receptacle	59-34

Part No.	Description	Page and Index No.
AD02 2283	Front End Block	59-29
AD02 2284	Front End Block Cover	59-27
AD02 2285	Rear End Block	59-20
AD02 2286	Rear End Block Cover	59-23
AD02 3106	Charge Corona Casing	59- 18
AD02 5015	x/o MB7	61-35
AD02 5018	Pick-pawl	61-35
AD03 1247	Upper Development Roller	53- 5
AD03 1248	Lower Development Roller	53- 6
AD03 6047	Back Spill Plate (A095/A096/A097)	53-33
AD03 7035	Mixing Auger	53-25
AD03 8052	Paddle Roller	53- 7
AD03 8053	Mixing Paddle Roller	53-20
AD03 9057	Cleaning Agitator MB11 (ADDED)	61- 49
AD04 2023	Cleaning Brush	61- 24
AD04 3030	Toner Collection Coil	61- 17
AD04 3030	Toner Collection Coil	63-33
AD04 3031	Toner Collection Coil	79- 10
AD04 3032	Toner Collection Coil	83- 6
AE01 1020	Hot Roller	65- 10
AE02 0037	Pressure Roller	65- 11
AE03 0017	Ball Bearing - 35x50x10	65- 17
AE03 0018	Ball Bearing - 12x28x8	65- 20
AE03 0020	Ball Bearing - 4x10X4 MB1 (OBS)	65-47
AE03 1014	Bushing - Oil Supply Roller	65-39
AE03 1018	Bushing - 4x6x10 (A095/A096 EU,A097)	65-56
AE03 2011	o/o MB5	65-37
AE03 2014	Bushing - 30x35x13.5	65-37
AE04 0006	Oil Supply Roller (A095/A096)	65-38
AE04 0009	Oil Supply Roller (A095/A096 EU,A097)	65-38
AE04 2005	Fusing Cleaning Roller MB1 (OBS)	65-44
AE04 2007	Upper Cleaning Roller (A095/A096 EU,A097)	65-57
AE04 2012	Lower Cleaning Roller (A097)	65-51
AF01 0063	Left Tandem Tray	47- 27
AF01 3002	Bottom Plate Pad	43- 26

Part No.	Description	Page and Index No.
AF01 3002	Bottom Plate Pad	45- 30
AF01 6057	Side Fence	49- 13
AF01 6062	Left Front Side Fence	47- 1
AF01 7010	End Fence	41- 3
AF01 7011	Left End Fence	47- 9
AF02 0242	Lower Registration Roller	35- 6
AF02 0255	Upper Registration Roller	35- 5
AF02 0280	Driven Roller	39-38
AF02 0286	Transport Drive Roller	37- 23
AF02 0287	Transport Driven Roller	37-21
AF02 0288	Duplex Exit Roller	37- 4
AF02 0289	Grip Drive Roller	39-21
AF02 0290	3rd Grip Roller	39-20
AF02 0291	2nd Inverter Drive Roller	71- 6
AF02 0293	Transport Drive Roller - Grip	77- 6
AF02 0294	Transport Drive Roller	77- 14
AF02 0295	Vertical Driven Roller	101- 4
AF02 0296	Pick-up Roller	77- 5
AF02 0297	Friction Belt Roller	75- 9
AF02 0301	Guide Driven Roller	75- 36
AF02 0302	Lower Fusing Exit Roller	67- 8
AF02 0303	Exit Transport Roller	69- 12
AF02 1016	Lower Fusing Exit Roller	67- 17
AF02 2065	2nd Inverter Driven Roller	71-24
AF02 2066	Transport Driven Roller	71- 29
AF02 2066	Transport Driven Roller	75- 30
AF02 2067	Guide Stopper Roller	75-31
AF02 2073	Exit Driven Roller	69- 1
AF03 0020	Pick-up Roller	39- 19
AF03 0021	Pick-up Roller	35-27
AF03 1001	Duplex Positioning Roller	73-23
AF03 1021	Paper Feed Roller	35-28
AF03 1022	Paper Feed Roller	39- 18
AF03 2021	Separation Roller	37-30
AF03 2023	Separation Roller	39-49

Part No.	Description	Page and Index No.
AF03 2024	Separation Roller - Duplex	77- 3
AF04 0048	Exit Drive Roller	71- 5
AG05 0066	Fusing Unit Knob	65-33
AG05 0067	Knob - Transport Roller	101- 11
AG07 0004	Magnetic Catch	13- 27
AG07 0004	Magnetic Catch	101- 30
AG07 0007	Magnet Catch	57-29
AH01 3008	Leveling Foot Guide	97-32
AW01 0033	Original Sensor Asss'y - H =3-50	19- 11
AW01 0035	original Sensor Ass'y - H =3-125	25- 11
AW01 0035	original Sensor Ass'y - H =3-125 (A4)	25- 12
AW01 0038	original Sensor Ass'y - H = 125 (LT)	25- 12
AW01 0050	Paper End Sensor (A097)	75- 52
AW02 0008	Photointerrupter	47- 23
AW02 0008	Photointerrupter	51- 9
AW02 0008	Photointerrupter	71- 2
AW02 0056	Photointerrupter - EE-SX4235A-P1	23-32
AW02 0056	Photointerrupter - EE-SX4235A-P1	35- 14
AW02 0056	Photointerrupter - EE-SX4235A-P1	37- 11
AW02 0056	Photointerrupter - EE-SX4235A-P1	39- 4
AW02 0056	Photointerrupter - EE-SX4235A-P1	45- 16
AW02 0056	Photointerrupter - EE-SX4235A-P1	47- 22
AW02 0056	Photointerrupter - EE-SX4235A-P1	51- 12
AW02 0056	Photointerrupter - EE-SX4235A-P1 (A095/A096)	73- 14
AW02 0056	Photointerrupter - EE-SX4235A-P1	77-23
AW02 0056	Photointerrupter - EE-SX4235A-P1	83- 14
AW02 0056	Photointerrupter - EE-SX4235A-P1	85- 3
AW02 0056	Photointerrupter - EE-SX4235A-P1 (A096/A097)	87- 7
AW02 0057	Paper Exit Sensor	69- 5
AW02 0058	Photointerrupter	37-27
AW02 0059	Duplex Paper Sensor	75-21
AW02 0059	Duplex Paper Sensor	77- 7
AW02 0060	Entrance Exit Sensor	69- 13
AW02 0061	Photointerrupter - EE - SX4019-P1	25- 19
AW02 0061	Photointerrupter - EE - SX4019-P1	31-32

Part No.	Description	Page and Index No.
AW02 0061	Photointerrupter - EE - SX4019-P1	39- 52
AW02 0062	Photointerrupter - EESX4019 - P15	15- 16
AW02 0064	Duplex Entrance Sensor	69- 15
AW02 0067	Photointerrupter - EESX4019 - P15	15- 15
AW02 0067	Photointerrupter - EESX4019 - P15	29- 10
AW03 0029	Fiber Cable -800	95-20
AW03 0030	Fiber Cable -400	95-22
AW10 0022	Optics Thermistor	19- 19
AW11 0011	Thermostat 140° AC120V 15A	27- 23
AW23 0006	Toner Density Sensor	53-23
AW31 0003	Toner End Sensor	55- 3
AW33 0003	Drum Potential Sensor	59-36
AW50 0010	Push Switch	85- 9
AW50 0010	Push Switch (A096/A097)	87- 17
AW50 0012	Push Switch	33- 4
AW50 0012	Push Switch	83- 16
AW50 0012	Push Switch	85- 12
AW50 0012	Push Switch (A096/A097)	87- 21
AW50 0016	Touch Panel	17- 19
AX04 0061	Cleaner Motor - DC 0.5W	59-31
AX04 0063	Tray Lift Motor - DC 3.6W	85- 5
AX04 0063	Tray Lift Motor - DC 3.6W (A096/A097)	87- 11
AX04 0065	Stepped Motor - DC 13W	31-29
AX05 0061	Jogger Motor - DC 6.5W	77-35
AX05 0063	Stepping Motor -11W	25- 7
AX05 0064	Stepping Motor - DC 7W	29- 12
AX06 0051	DC Motor - 24V 11.2W	49- 2
AX06 0072	Main Motor - DC 21W (A095/A096)	81-23
AX06 0095	Main Motor - DC 24V 27W (A097)	81-23
AX07 0008	DC Motor - 53W	23- 16
AX20 0090	Magnetic Clutch - By-pass	35- 13
AX20 0091	Magnetic Clutch - Transport	77-20
AX20 0092	Magnetic Clutch - Separation	77- 17
AX21 0036	Magnetic Clutch - Registration	35- 12
AX21 0037	Magnetic Clutch	39-24

Part No.	Description	Page and Index No.
AX30 0001	LCD Display	17- 20
AX31 0018	Total Counter	93- 12
AX40 0021	Anti-condensation Heater-115V 18W	87-31
AX40 0021	Anti-condensation Heater - 115V 18W	97-23
AX40 0022	Anti-condensation Heater - 240V 18W	87-31
AX40 0047	Anticondensation Heater - 15W 115V	21- 15
AX40 0047	Anticondensation Heater -15W 115V	99-24
AX40 0048	Anticondensation Heater - 15W 220/230V	21- 15
AX40 0048	Anticondensation Heater - 15W 220/230V	99-24
AX40 0049	Anti-condensation Heater - 240V 18W	97-23
AX43 0021	Heater - 550W(120V) (A097)	65- 9
AX44 0069	Heater - 950W(115V) (A095/A096)	65- 9
AX44 0070	Heater - 950W (220/230V) (A095/A096)	65- 9
AX45 0014	Heater -1100W (220/230V) (A097)	65- 9
AX52 0016	Exposure Lamp - 115V	27- 6
AX52 0018	Exposure Lamp - 220/230V (A095/A096)	27- 6
AX52 0022	Exposure Lamp - 220/230V (A097)	27- 6
AX64 0045	Fan Motor - DC24V 1.68W (A097)	89-30
AX64 0049	Fan Motor - DC24V 2.4W (A097)	89-27
AX65 0013	Optics Cooling Fan	21- 6
AZ24 0019	DC Power Supply Unit -115V (A095/A096)	91- 6
AZ24 0021	DC Power Supply Unit - 220/230V (A095/A096)	91- 6
AZ24 0023	DC Power Supply Unit -115V (A097)	91- 6
AZ24 0024	DC Power Supply Unit - 220/230V (A097)	91- 6
AZ30 0036	High Voltage Supply Board - T	63-25
AZ32 0067	High-voltage Supply Board - C	59- 3
A007 1868	Spacer - Lamp Terminal	27- 18
A007 1920	Cushion - Exposure Glass	19- 15
A007 2803	Manual Feed Table Holder	33- 2
A007 3751	Cap Large - Toner Collection Tank	101- 15
A007 6156	Lower Rear Cap	13- 39
A008 9502	Silicone Grease - G40M	109- 2
A024 1367	Small Cap - Left Cover	13- 26
A027 1769	Exposure Adjusting Plate - Side	27- 1
A028 3146	Paper Feed Guide Spacer	89-24

Part No.	Description	Page and Index No.
A028 3356	Rear Wire Tightener	51- 6
A028 9300	Grease KOK Barrierta - JFE5 5/2	109- 1
A029 2858	Release Lever	101- 26
A029 2984	Decal - Grip	101- 24
A029 2984	Decal - Grip	107- 3
A029 7904	Pad - CFF	41- 2
A048 1721	Spring Plate A	27- 5
A048 2274	Front Transport Bracket (A097)	61-55
A048 2277	Rear Transport Bracket (A097)	61-56
A048 2838	Nylon Rivet	41- 5
A048 2838	Nylon Rivet	43- 9
A048 2838	Nylon Rivet	45- 5
A053 1725	Lens Bracket Cam	31- 9
A053 1957	Flex Hinge - Platen Cover	15- 6
A053 2135	Development Unit Holder	93- 21
A053 2770	Holder - Manual Feed Table	33- 1
A053 2773	Holder - Manual Feed Table	33-20
A053 2837	Paper Guide - Manual Feed	33- 16
A053 2916	Friction Pad - B	37- 19
A060 2512	Registration Roller Knob	35- 29
A060 2512	Registration Roller Knob	37-33
A060 2617	Separation Torque Limiter	37-31
A060 2617	Separation Torque Limiter (A095/A096)	39-48
A060 2633	Guide Plate Holder	77- 16
A069 1854	Bushing - 5mm o/o MB6	27-21
A069 1854	Bushing - 5mm o/o MB6	29- 5
A069 1855	Exposure Adjusting Plate - Center	27- 2
A069 1883	Shoe - Scanner	27-21
A069 1883	Shoe - Scanner	29- 5
A069 2645	Seal - 0.2x16x47	33-21
A069 5352	Harness - Ground Wire - Scanner	89- 19
A079 1693	Guide Feeler	25-26
A079 5794	Push Switch - Paper Tray	49- 20
A100 1310	Platen Cover Hinge Ass'y	15- 9
A100 1321	Front Platen Cover	15- 1

Part No.	Description	Page and Index No.
A100 1322	Rear Platen Cover	15- 5
A100 1323	Original Holder	15- 4
A100 1324	Positioning Sensor Shutter	15- 8
A100 1325	Hinge Spacer	15- 10
A300 2134	Guide Roller - B	99- 5
A316 4513	Lower Exit Sensor Bracket	69- 4
A352 2138	Slide Collar -0.6x4.5x6	61-43
A406 9505	Platen Cover Sheet -10Sheet/1 Set	15- 3
A413 1670	Antistatic Brush	65- 34
A423 4432	Shoulder Screw - M2.5	83- 12
A423 4432	Shoulder Screw - M2.5	101- 32
A423 4433	Spring	83- 13
A423 4433	Spring	101- 14
A469 2123	Rubber Cushion- 1x10x10mm	37- 2
A469 2123	Rubber Cushion- 1x10x10mm	73- 15
A469 2123	Rubber Cushion- 1x10x10mm	77- 39
A499 1135	Tension Roller	75- 12
A509 0010	Key Counter Holder Ass'y	13- 50
	MB3 (ADDED) MB24 (OBS)	
C201 5125	Shoulder Screw - M4	97-33
G004 9668	Grease: KS660:SHIN-ETSU	109- 9
G013 4566	Thermistor Spring	63- 11
G619 4028	Slider Pressure Spring	67- 2
GB01 3035	Gear - 28Z	73- 40
GB01 3035	Gear - 28Z	77- 43
H006 1091	Pin - Contact Point - Front	75- 1
5053 0223	Bushing - 8mm	35-35
5053 0223	Bushing - 8mm	37-40
5053 0223	Bushing - 8mm	49- 4
5053 0223	Bushing - 8mm	77- 21
5053 0419	Bushing - 10mm	51- 15
5053 0447	Bushing - 6mm	37-36
5053 0447	Bushing - 6mm	73- 26
5053 0447	Bushing - 6mm	75-49
5053 0447	Bushing - 6mm	77-24

Part No.	Description	Page and Index No.
5053 0709	Bushing - 6x10x6mm	83- 1
5201 1796	Stepped Screw - M4	101- 36
5201 2858	Friction Pad	49- 12
5203 9501	Grease 501	109- 3
5205 1694	Adjusting Cam - Start Lever	25-25
5205 1694	Adjusting Cam - Start Lever	29-22
5205 1853	Mylar Seal - Base	23- 28
5205 2697	Bushing - Upper Registration Roller	35-32
5205 2697	Bushing - Upper Registration Roller	37- 16
5205 2777	Cushion - Lower Pick up Guide	45- 20
5205 2865	Bushing - Paper Feed Roller	35-36
5205 4527	Spring - Exit	69- 3
5205 4527	Spring - Exit	71- 25
5206 2686	Snap Ring	73- 12
5206 2808	Antistatic Brush - Duplex Transport	69- 6
5206 2876	Spring - Wire	77- 9
5206 4478	Spring - Driven Roller	75- 34
5209 1694	Guide Roller - 1st Scanner	29- 20
5209 1694	Guide Roller - 1st Scanner	31- 14
5215 1667	Platen Cover Stud	15- 13
5215 1700	Exposure Lamp Terminal - Fix	27- 16
5215 1702	Clip - Exposure Lamp	27- 7
5215 2621	Snap Ring - M6	77- 1
5215 2672	Bushing	35- 11
5215 2838	Rubber Magnet	15- 7
5215 4444	Pin	65-42
5216 4145	Thermofuse Decal	65- 6
5216 4145	Thermofuse Decal	107- 1
5301 1662	Hexagon Bolt	97-31
5324 1658	Bushing- 4x8x4.5mm	61-42
5360 1711	Pressure Spring	71- 16
5403 1030	Tension Spring	51- 5
5403 6246	Stepped Screw - Cleaning	101-28
5408 2035	Stepped Screw - M4	49-22
5409 1855	Mounting Pin	59-38

Part No.	Description	Page and Index No.
5413 1812	Spring - Drum Return Arm	69-20
5415 1053	Caster	97- 16
5415 2642	Lock Arm	51- 16
5420 1682	Supporter - Lamp Terminal	27- 17
5420 9516	Test Chart - OS - A3 (10pts/set)	109- 4
5424 1064	Screw Stand	97- 15
5424 4142	Bushing - Cleaning Roller o/o MB5	67- 6
5442 1659	Stepped Screw - M4	35-34
5442 1659	Stepped Screw - M4	93-25
5442 1705	Exposure Lamp Terminal - Release	27-25
5442 2108	Spring - Corona Wire	59-28
5442 2117	Shoulder Screw - Hinge	49- 11
5442 2754	Spring - Registration Roller	35-31
5442 9101	Setting Powder	109- 5
5442 9103	Launa Oil	109- 6
5443 2668	Bushing - 4x6x7mm	35-24
5443 2668	Bushing - 4x6x7mm	37- 9
5446 1086	o/o MB5	97-32
5446 1865	Bushing - 5x9x5.5mm	23- 26
5446 2560	Cushion - Paper Tray	97- 11
5446 2638	Decal - Paper Lower Limit	49- 15
5446 2638	Decal - Paper Lower Limit	107- 2
5446 2671	Drive Pulley - Paper Tray	51- 4
5446 2698	Worm Gear	49- 1
5446 2702	Gear - 22T	49- 5
5446 2846	Release Spring - Vertical Transport	101- 27
5446 3648	Stepped Screw - M4	99- 9
5446 5832	Connector Guide Pin	95- 16
5447 2681	Snap Ring	35-38
5447 2681	Snap Ring	37-42
5447 2681	Snap Ring	39- 5
5447 2681	Snap Ring	63-42
5447 2681	Snap Ring	73- 24
5447 2681	Snap Ring	75- 16
5447 2681	Snap Ring	99-20

Part No.	Description	Page and Index No.
5447 2706	Gear - 15T	35- 8
5447 2706	Gear - 15T	39-57
5447 9078	Heat Resisting Grease MT-78	109- 7
5506 6111	Stepped Screw - M4	67- 10
5853 1190	Spring - Click Plate	61- 13
5887 4162	Screw - Driven Guide Plate	77-22
5894 2540	Arm Screw	61- 18
6754 2866	Roller - Positioning Guide	99- 7

Part No.	Description	Page and Index No.
0313 0040B	PhilipsPan Head Screw-M3x4	57-110
0313 0040B	PhilipsPan Head Screw-M3x4	73-102
0313 0050B	Philips Pan Head Screw -M3x5	65-105
0313 0050B	Philips Pan Head Screw -M3x5	77-107
0313 0050B	Philips Pan Head Screw -M3x5	87-111
0313 0050B	Philips Pan Head Screw -M3x5	99-108
0313 0050W	Philips Pan Head Screw -M3x5	19-107
0313 0050W	Philips Pan Head Screw-M3x5	23-107
0313 0050W	Philips Pan Head Screw-M3x5	25-102
0313 0050W	Philips Pan Head Screw -M3x5	27-101
0313 0050W	Philips Pan Head Screw - M3x5	29-113
0313 0050W	Philips Pan Head Screw - M3x5	31-101
0313 0060B	Philips Pan Head Screw - M3x6	41-104
0313 0060B	Philips Pan Head Screw - M3x6	43-108
0313 0060B	Philips Pan Head Screw - M3x6	63-105
0313 0060B	Philips Pan Head Screw - M3x6	95-105
0313 0060W	Philips Pan Head Screw - M3x6	29-101
0313 0080B	Philips Pan Head Screw - M3x8	37-110
0313 0080B	Philips Pan Head Screw - M3x8	51-104
0313 0080B	Philips Pan Head Screw - M3x8	65-110
0313 0080B	Philips Pan Head Screw - M3x8	75-110
0313 0080W	Philips Pan Head Screw - M3x8	27-105
0313 0120W	Philips Pan Head Screw - M3x12	27-106
0313 0120W	Philips Pan Head Screw - M3x12	95-104
0314 0040W	Philips Pan Head Screw - M4x4	19-104
0314 0040W	Philips Pan Head Screw - M4x4	21-104
0314 0050B	Philips Pan Head Screw - M4x5	55-105
0314 0060B	Philips Pan Head Screw - M4x6	33-101
0314 0060B	Philips Pan Head Screw - M4x6	35-106
0314 0060B	Philips Pan Head Screw - M4x6	37-111
0314 0060B	Philips Pan Head Screw - M4x6	53-105
0314 0060B	Philips Pan Head Screw - M4x6	61-102
0314 0060B	Philips Pan Head Screw - M4x6	65-102
0314 0060B	Philips Pan Head Screw - M4x6	67-102
0314 0060B	Philips Pan Head Screw - M4x6	83-104

Part No.	Description	Page and Index No.
0314 0060B	Philips Pan Head Screw - M4x6	87-103
0314 0060B	Philips Pan Head Screw - M4x6	89-102
0314 0060B	Philips Pan Head Screw - M4x6	95-103
0314 0060B	Philips Pan Head Screw - M4x6	97-103
0314 0060B	Philips Pan Head Screw - M4x6	99-103
0314 0060W	Philips Pan Head Screw - M4x6	19-101
0314 0060W	Philips Pan Head Screw - M4x6	21-103
0314 0060W	Philips Pan Head Screw - M4x6	23-116
0314 0060W	Philips Pan Head Screw - M4x6	25-105
0314 0060W	Philips Pan Head Screw - M4x6	29-107
0314 0060W	Philips Pan Head Screw - M4x6	31-102
0314 0060W	Philips Pan Head Screw - M4x6	93-112
0314 0080B	Philips Pan Head Screw - M4x8	35-111
0314 0080B	Philips Pan Head Screw - M4x8	37-105
0314 0080B	Philips Pan Head Screw - M4x8	41-105
0314 0080B	Philips Pan Head Screw - M4x8	43-109
0314 0080B	Philips Pan Head Screw - M4x8	45-106
0314 0080B	Philips Pan Head Screw - M4x8	53-101
0314 0080B	Philips Pan Head Screw - M4x8	65-103
0314 0080B	Philips Pan Head Screw - M4x8	75-106
0314 0080B	Philips Pan Head Screw - M4x8	89-104
0314 0080B	Philips Pan Head Screw - M4x8	99-104
0314 0080W	Philips Pan Head Screw - M4x8	29-108
0314 0080W	Philips Pan Head Screw - M4x8	45-109
0314 0100B	Philips Pan Head Screw - M4x10	65-112
0314 0100W	Philips Pan Head Screw - M4x10	15-102
0314 0120B	Philips Pan Head Screw - M4x12	39-110
0314 0120W	Philips Pan Head Screw - M4x12	25-106
0314 0120W	Philips Pan Head Screw - M4x12	29-106
0314 0120W	Philips Pan Head Screw - M4x12	31-106
0314 0140B	Philips Pan Head Screw - M4x14	89-113
0314 0140W	Philips Pan **Head** Screw - M4x14	93-113
0314 0300B	Philips Pan Head Screw - M4x30	89-112
0323 0050B	Screw - M3x5	73-110
0323 0050W	Philips Sunken Head Screw - M3x5	19-108

Part No.	Description	Page and Index No.
0324 0080W	Philips Sunken Head Screw - M4x8	13-107
0344 0060W	Philips Truss Head Screw - M4x6	73-101
0344 0080W	Philips Truss Head Screw - M4x8	13-104
0344 0080W	Philips Truss Head Screw - M4x8	15-103
0344 0080W	Philips Truss Head Screw - M4x8	57-102
0353 0040W	Philips Pan Head Bind Screw -M3x4	27-102
0354 0050F	Philips Pan Head Bind Screw-M4x5	41-107
0354 0050F	Philips Pan Head Bind Screw-M4x5	43-104
0354 0050F	Philips Pan Head Bind Screw-M4x5	45-108
0354 0050F	Philips Pan Head Bind Screw-M4x5	47-104
0413 0062B	Tapping Screw - M3x6	61-104
0413 0062W	Tapping Screw - M3x6	23-115
0413 0062W	Tapping Screw - M3x6	81-102
0413 0062W	Tapping Screw - M3x6	93-111
0413 0082B	Tapping Screw - M3x8	43-102
0413 0082B	Tapping Screw - M3x8	61-101
0413 0082B	Tapping Screw - M3x8	75-111
0413 0082W	Tapping Screw - M3x8	55-101
0413 0082W	Tapping Screw - M3x8	59-101
0414 0080B	Tapping Screw - M4x8	49-102
0414 0082B	Binding Self Tapping Screw - M4x8	13-108
0414 0082B	Binding Self Tapping Screw - M4x8	75-102
0414 0082B	Binding Self Tapping Screw - M4x8	79-106
0414 0082B	Binding Self Tapping Screw - M4x8	81-101
0414 0082B	Binding Self Tapping Screw - M4x8	89-106
0414 0082B	Binding Self Tapping Screw - M4x8	99-101
0414 0082F	Philips Truss Head Screw - M4x8	41-101
0414 0082F	Philips Truss Head Screw - M4x8	43-101
0414 0082F	Philips Truss Head Screw - M4x8	47-101
0414 0082W	Tapping Screw With Flat Washer-M4x8	13-105
0414 0082W	Tapping Screw With Flat Washer-M4x8	25-110
0414 0082W	Tapping Screw With Flat Washer-M4x8	29-103
0414 0082W	Tapping Screw With Flat Washer-M4x8	67-103
0414 0082W	Tapping Screw With Flat Washer-M4x8	69-102
0414 0142W	Tapping Screw - M4x14	15-101

Part No.	Description	Page and Index No.
0432 0060B	Philips Tapping Screw - M2x6	17-101
0432 0080B	Philips Tapping Screw - M2x8	17-103
0432 0100B	Philips Tapping Screw - M2x10	17-102
0433 0060W	Tapping Screw - M3x6	25-104
0433 0082B	Tapping Screw - M3x8	43-107
0434 0060B	Philips Tapping Screw - M4x6	19-103
0434 0060B	Philips Tapping Screw - M4x6	21-108
0434 0060B	Philips Tapping Screw - M4x6	23-112
0434 0060B	Philips Tapping Screw - M4x6	33-102
0434 0060B	Philips Tapping Screw - M4x6	35-101
0434 0060B	Philips Tapping Screw - M4x6	37-102
0434 0060B	Philips Tapping Screw - M4x6	39-101
0434 0060B	Philips Tapping Screw - M4x6	49-101
0434 0060B	Philips Tapping Screw - M4x6	51-102
0434 0060B	Philips Tapping Screw - M4x6	69-105
0434 0060B	Philips Tapping Screw - M4x6	71-106
0434 0060B	Philips Tapping Screw - M4x6	73-103
0434 0060B	Philips Tapping Screw - M4x6	75-108
0434 0060B	Philips Tapping Screw - M4x6	79-101
0434 0060B	Philips Tapping Screw - M4x6	87-110
0434 0060B	Philips Tapping Screw - M4x6	99-102
0434 0060B	Philips Tapping Screw - M4x6	101-101
0434 0060W	Tapping Screw - M4x6	21-101
0434 0060W	Tapping Screw - M4x6	23-103
0434 0060W	Tapping Screw - M4x6	25-103
0434 0060W	Tapping Screw - M4x6	29-104
0434 0060W	Tapping Screw - M4x6	89-107
0434 0080B	Philips Tapping Screw - M4x8	13-111
0434 0080B	Philips Tapping Screw - M4x8	21-110
0434 0080B	Philips Tapping Screw - M4x8	57-108
0434 0080B	Philips Tapping Screw - M4x8	69-103
0434 0080B	Philips Tapping Screw - M4x8	71-102
0434 0080B	Philips Tapping Screw - M4x8	73-108
0434 0080B	Philips Tapping Screw - M4x8	75-107
0434 0080B	Philips Tapping Screw - M4x8	77-101

Part No.	Description	Page and Index No.
0434 0080B	Philips Tapping Screw -M4x8	79-102
0434 0080B	Philips Tapping Screw -M4x8	81-109
0434 0080B	Philips Tapping Screw -M4x8	83-103
0434 0080B	Philips Tapping Screw -M4x8	85-101
0434 0080B	Philips Tapping Screw -M4x8	87-105
0434 0080B	Philips Tapping Screw -M4x8	89-101
0434 0080B	Philips Tapping Screw - M4x8	91-103
0434 0080B	Philips Tapping Screw - M4x8	93-101
0434 0080B	Philips Tapping Screw - M4x8	95-101
0434 0080B	Philips Tapping Screw - M4x8	97-101
0434 0080B	Philips Tapping Screw - M4x8	99-110
0434 0080B	Philips Tapping Screw - M4x8	101-104
0434 0080W	Tapping Screw - M4x8	21-109
0434 0080W	Tapping Screw - M4x8	23-109
0434 0080W	Tapping Screw - M4x8	93-104
0434 0082B	Tapping Screw - M4x8	75-105
0434 0082W	Tapping Screw - M4x8	13-106
0573 0040B	Hexagon Headless Set Screw - M3x4	39-112
0573 0050E	Hexagon Headless Set Screw - M3x5 MB3 (ADDED)	81-112
0574 0050E	Hexagon Headless Set Screw - M4x5	39-108
0574 0050E	Hexagon Headless Set Screw - M4x5	49-103
0574 0050E	Hexagon Headless Set Screw - M4x5	77-108
0574 0050E	Hexagon Headless Set Screw - M4x5	81-104
0574 0050W	Hexagon Headless Set Screw - M4x5	23-104
0574 0060E	Hexagon Headless Set Screw - M4x6	29-111
0574 0060E	Hexagon Headless Set Screw - M4x6	35-110
0575 0050E	Hexagon Headless Set Screw - M5x5	51-103
0622 5160E	Spring Pin - 2.5x16	53-106
0623 0140E	Spring Pin - 3x14mm	79-105
0632 0100G	Pin - 2x10mm	37-112
0633 0160E	Pin - 3x16mm	81-106
0701 0030B	Flate Washer - M3	73-112
0701 0040B	Flat Washer - M4 MB22 (ADDED)	35-112
0707 4050	Bushing - 4x5	79-108

Part No.	Description	Page and Index No.
0707 4050	Bushing - 4x5	81-110
0707 4050	Bushing - 4x5	83-109
0710 0050W	Hexagon Nut - M5	23-111
0720 0025B	Retaining Ring - M2.5	59-105
0720 0025B	Retaining Ring - M2.5	71-104
0720 0030B	Retaining Ring - M3	37-109
0720 0030B	Retaining Ring - M3	39-111
0720 0030B	Retaining Ring - M3	53-104
0720 0030B	Retaining Ring - M3	61-105
0720 0030B	Retaining Ring - M3	69-104
0720 0030B	Retaining Ring - M3	71-105
0720 0030B	Retaining Ring - M3	73-107
0720 0030B	Retaining Ring - M3	93-102
0720 0030E	Retaining Ring - M3	35-109
0720 0040B	Retaining Ring - M4	37-101
0720 0040B	Retaining Ring - M4	39-106
0720 0040B	Retaining Ring - M4	47-103
0720 0040B	Retaining Ring - M4	51-101
0720 0040B	Retaining Ring - M4	53-102
0720 0040B	Retaining Ring - M4	55-104
0720 0040B	Retaining Ring - M4	57-103
0720 0040B	Retaining Ring - M4	61-103
0720 0040B	Retaining Ring - M4	63-101
0720 0040B	Retaining Ring - M4	65-101
0720 0040B	Retaining Ring - M4	67-101
0720 0040B	Retaining Ring - M4	69-101
0720 0040B	Retaining Ring - M4	71-101
0720 0040B	Retaining Ring - M4	73-104
0720 0040B	Retaining Ring - M4	75-104
0720 0040B	Retaining Ring - M4	77-102
0720 0040B	Retaining Ring - M4	79-110
0720 0040B	Retaining Ring - M4	81-107
0720 0040B	Retaining Ring - M4	83-101
0720 0040B	Retaining Ring - M4	87-101
0720 0040B	Retaining Ring - M4	93-109

Part No.	Description	Page and Index No.
0720 0040B	Retaining Ring - M4	97-102
0720 0040B	Retaining Ring - M4	99-109
0720 0040E	Retaining Ring - M4	29-110
0720 0040E	Retaining Ring - M4	31-105
0720 0050B	Retaining Ring - M5	35-107
0720 0050B	Retaining Ring - M5	75-114
0720 0060B	Retaining Ring - M6	35-105
0720 0060B	Retaining Ring - M6	37-104
0720 0060B	Retaining Ring - M6	39-102
0720 0060B	Retaining Ring - M6	41-106
0720 0060B	Retaining Ring - M6	43-110
0720 0060B	Retaining Ring - M6	45-104
0720 0060B	Retaining Ring - M6	57-109
0720 0060B	Retaining Ring - M6	63-104
0720 0060B	Retaining Ring - M6	65-108
0720 0060B	Retaining Ring - M6	71-108
0720 0060B	Retaining Ring - M6	73-105
0720 0060B	Retaining Ring - M6	77-109
0720 0060B	Retaining Ring - M6	79-103
0720 0060B	Retaining Ring - M6	81-105
0720 0060B	Retaining Ring - M6	83-108
0720 0060E	Retaining Ring - M6	23-101
0720 0060E	Retaining Ring - M6	49-104
0720 0070E	Retaining Ring - M7	29-114
0725 0120B	Retaining Ring - M12	57-106
0725 0300E	Retaining Ring C - M30	65-104
0727 0080	C-ring - M8	55-103
0727 0080	C-ring - M8	85-103
0727 0080	C-ring - M8	87-104
0742 3808	Ball Bearing - 8x16x5	39-103
0742 3808	Ball Bearing - 8x16x5	83-111
0801 0146	Bind Screw - M4x4	49-107
0801 1185	Philips Truss Head Screw - M4x8	13-110
0802 5094	Tapping Truss Head Screw - M4x8	13-102
0802 5094	Tapping Truss Head Screw - M4x8	73-106

Part No.	Description	Page and Index No.
0802 5094	Tapping Truss Head Screw - M4x8	93-103
0802 5124	Tapping Screw - M3x8	13-103
0803 0058	Stepped Screw	87-107
0803 0058	Stepped Screw	91-114
0805 0073	Retaining Ring - M5	43-106
0805 0083	Retaining Ring - M4	45-103
0805 0083	Retaining Ring - M4	75-103
0805 3145	Ball Bearing - 6x12x4mm	39-107
0805 3291	Ball Bearing - 8x16x5mm	77-111
0805 3341	Ball Bearing - 10x22x6	23-102
0805 3384	Bushing - 5mm	69-107
0805 3389	Bushing - 8x10x6mm	45-105
0807 3092	Spacer - 4x5x3	61-109
0807 5056	Washer -8.1 mm	65-107
0930 0400G	Parallel Key - 4x4x1O	49-105
0950 3005M	Philips Screw With Lock Washer M3x5	65-109
0950 4008M	Screw - M4x8	87-108
0951 3005B	Philips Screw With Flat Washer M3x5	61-108
0951 3005W	Philips Screw With Flat Washer-M3x5	21-102
0951 3005W	Philips Screw With Flat Washer-M3x5	23-114
0951 3006B	Philips Screw With Flat Washer-M3x6	53-103
0951 3006B	Philips Screw With Flat Washer-M3x6	61-106
0951 3006B	Philips Screw With Flat Washer-M3x6	63-107
0951 3008B	Philips Screw With Flat Washer-M3x8	63-102
0951 3008B	Philips Screw With Flat Washer-M3x8	85-105
0951 3012W	Philips Screw With Flat Washer-M3x1	27-104
0951 4006B	Philips Screw With Washer- M4x6	55-102
0951 4006B	Philips Screw With Washer- M4x6	67-104
0951 4006W	Philips Screw With Flat Washer-M4x6	19-106
0951 4006W	Philips Screw With Flat Washer-M4x6	25-101
0951 4006W	Philips Screw With Flat Washer-M4x6	27-103
0951 4006W	Philips Screw With Flat Washer-M4x6	29-102
0951 4006W	Philips Screw With Flat Washer-M4x6	31-108
0951 4008B	Philips Screw With Washer- M4x8	23-110
0951 4008B	Philips Screw With Washer- M4x8	35-104

Part No.	Description	Page and Index No.
0951 4008B	Philips Screw With Washer - M4x8	37-103
0951 4008B	Philips Screw With Washer - M4x8	53-107
0951 4008B	Philips Screw With Washer - M4x8	77-103
0951 4008B	Philips Screw With Washer - M4x8	89-105
0951 4008B	Philips Screw With Washer - M4x8	99-106
0951 4008W	Philips Screw With Flat Washer-M4x8	21-105
0951 4008W	Philips Screw With Flat Washer-M4x8	25-111
0951 4008W	Philips Screw With Flat Washer-M4x8	29-112
0951 4008W	Philips Screw With Flat Washer-M4x8	65-106
0951 4010B	Philips Screw With Washer - M4x10	79-107
0951 4010B	Philips Screw With Washer - M4x10	81-111
0951 4010W	Philips Screw Wtih Flatwasher-M4x10	31-104
0951 4010W	Philips Screw With Flatwasher-M4x10	59-103
0951 4012W	Philips Screw With Washer - M4x12	31-107
0951 4016W	Philips Screw W/ Flat Washer-M4x16	13-109
0952 4008W	Philips Screw - M4x8	29-109
0952 4008W	Philips Screw - M4x8	41-103
0952 4008W	Philips Screw - M4x8	43-105
0960 3005B	Philips Flange Screw - M3 X 5	61-107
0960 3006B	Philips Flange Screw - M3 X 6	45-101
0960 4006B	Philips Flange Screw - M4x6	59-107
0960 4006B	Philips Flange Screw - M4x6	79-109
0960 4006B	Philips Flange Screw - M4x6	83-102
0960 4006B	Philips Flange Screw - M4x6	101-103
0960 4006W	Philips Flange Screw - M4x6	23-105
0960 4008W	Philips Flange Screw - M4x8	67-105
0960 4012B	Philips Flange Screw - M4 X 12	**83-110**
0960 4012B	Philips Flange Screw - M4 X 12	97-106
0964 4008B	Tapping Screw With Flat Washer-M4x8	37-106
0964 4008B	Tapping Screw With Flat Washer-M4x8	57-104
0964 4008B	Tapping Screw With Flat Washer-M4x8	75-112
0964 4008B	Tapping Screw With Flat Washer-M4x8	79-104
0964 4008B	Tapping Screw With Flat Washer-M4x8	81-108
0964 4008B	Tapping Screw With Flat Washer-M4x8	91-108
0964 4008B	Tapping Screw With Flat Washer-M4x8	97-104

Part No.	Description	Page and Index No.
0964 4012B	Tapping Screw With Flat Washer-M4	57-107
0964 4012B	Tapping Screw With Flat Washer-M4	81-103
0965 3006B	Tapping Screw With Washer - M3x6	63-108
0965 3008B	Tapping Screw With Washer - M3x8	33-103
0965 3008B	Tapping Screw With Washer - M3x8	63-103
0965 3008B	Tapping Screw With Washer - M3x8	73-109
0965 3008F	Tapping Screw With Washer - M3x8	33-104
0965 3008W	Tapping Screw With Washer - M3x8	59-102
0965 3010W	Tapping Screw With Flat Washer-M3x1	47-107
0965 3012W	Tapping Screw With Flat Washer - M3	45-107
0965 3012W	Tapping Screw With Flat Washer - M3	47-105
0965 4008B	Tapping Screw - M4 X 8	41-102
0965 4008B	Tapping Screw - M4 X 8	43-103
0965 4008B	Tapping Screw - M4 X 8	45-102
0965 4008B	Tapping Screw - M4 X 8	47-102
0965 4008B	Tapping Screw - M4 X 8	49-106
0965 4008B	Tapping Screw - M4 X 8	75-101
0965 4008W	Tapping Screw With Flat Washer - M4x8	57-101
0965 4010B	Tapping Screw - M4x10	47-108
0965 401OB0	Tapping Screw - M4 X 10	85-102
0965 4010B	Tapping Screw - M4 X 10	87-106
0971 4006A	Philips Polycarbonate Screw - M4x6	59-106
0972 4006W	Philips Polycarbonate Screw - M4x6	13-101
1101 0473	Connector - 3P	65-111
1102 6245	Connector - 2P	23-117
1102 6245	Connector - 2P	39-113
1102 6245	Connector - 2P	47-106
1102 6245	Connector - 2P	59-104
1102 6245	Connector - 2P	77-105
1102 6245	Connector - 2P	87-102
1102 6246	Connector - 3P	35-103
1102 6246	Connector - 3P	75-109
1102 6246	Connector - 3P	77-110
1102 6247	Connector - 4P	23-120
1102 6247	Connector - 4P	35-102

Part No.	Description	Page and Index No.
1102 6247	Connector-4P	93-107
1102 6248	Connector-5P	37-108
1102 6248	Connector-5P	83-107
1102 6249	Connector-6P	77-104
1102 6249	Connector-6P	85-104
1102 6249	Connector-6P	99-105
1102 6250	Connector-7P	37-115
1102 6250	Connector-7P	39-105
1102 6250	Connector-7P	83-106
1102 6251	Connector-8P	99-112
1102 6254	Connector-11P	95-110
1102 6256	Connector-13P	37-116
1102 6256	Connector-13P	95-111
1102 6260	Connector-Red3P	23-119
1102 6265	Connector-Red8P	39-104
1102 6268	Connector-Red 11P	95-112
1102 6274	Connector-Yellow 3P	23-118
1102 6418	FiberCable-CA1002	95-106
1104 0224	Relay Bracket	95-108
1105 0005	Nylon Clip-3N	37-107
1105 0009	Nylon Clip-5N	93-108
1105 0087	Clamp	23-108
1105 0087	Clamp	29-105
1105 0087	Clamp	37-113
1105 0087	Clamp	39-109
1105 0087	Clamp	89-109
1105 0192	Locking Support	89-103
1105 0192	Locking Support	91-102
1105 0196	Harness Clamp	63-106
1105 0199	Clamp	21-111
1105 0263	Wire Saddle	57-105
1105 0267	Wire Clamp	19-102
1105 0278	Harness Clamp	19-105
1105 0278	Hamess Clamp	21-106
1105 0278	Harness Clamp	23-106

Part No.	Description	Page and Index No.
1105 0278	HarnessClamp	25-109
1105 0278	HamessClamp	31-103
1105 0278	HamessClamp	35-108
1105 0278	Harness Clamp	51-105
1105 0278	HamessClamp	71-103
1105 0278	Harness Clamp	73-111
1105 0278	Harness Clamp	75-113
1105 0278	HamessClamp	77-106
1105 0278	Harness Clamp	99-107
1105 0283	Clamp	69-106
1105 0283	Clamp	71-107
1105 0291	Wire Saddle	23-113
1105 0291	Wire Saddle	25-108
1105 0291	Wire Saddle	37-114
1105 0291	Wire Saddle	51-106
1105 0291	Wire Saddle	87-109
1105 0291	Wire Saddle	91-105
1105 0291	Wire Saddle	95-107
1105 0291	Wire Saddle	97-105
1105 0292	Wire Saddle	25-107
1105 0292	Wire Saddle	89-108
1105 0310	Wire Clamp	91-104
1105 0310	Wire Clamp	99-111
1105 0316	Clamp	95-102
1105 0328	Harness Clamp - ES-0505	93-106
1105 0367	Spacer	89-110
1105 0367	Spacer	91-101
1105 0378	Clamp	89-111
1106 0459	Bushing-20.2mm .	21-107
1107 0391	Fuse - 5A 125V (115V)	91-110
1107 0392	Fuse - 6.3A (115V)	91-111
1107 0693	Circuit Bresker - 18A 250V	91-106
1107 0752	Fuse - 5A 250V (230V)	91-112
1107 0753	Fuse - 6.3A 250V (230V)	91-113
1107 0785	Fuse - 125V 10A (115V)	91-109

Part No.	Description	Page and Index No.
1107 0794	Fuse - 6.3A 250V(115V) (A097)	91-115
1204 1542	Dip Switch	105-101
1204 1545	Main Switch	93-105
1204 2277	Push Switch	93-110
1204 2355	Microswitch-AM51632A531	101-102
1204 2363	Microswitch-AH735454N	83-105
1208 0479	PowerRelay-DC24V	95-109
1400 0528	Transistor-DTB113EK	105-102
1401 0298	Transistor-2SC2712Y	105-103
1401 0835	Diode-1SS190	105-104
1401 0986	Transistor-μPA1552H	105-105
1402 0476	Diode-1SS184	105-106
1402 0492	Diode-DICA20	105-107
1402 0687	Diode-RD12P	105-108
1402 1122	Diode-MA159A	105-109
1402 1152	Diode-RD7.5P	105-110
1403 0558	LED-SEI2110RTP3	105-111
1407 1311	IC - LS32	105-112
1407 1596	IC-SN74LS14NS	105-113
1407 1925	IC-SN15189ANS	105-114
1407 1926	IC-SN75188NS	105-115
1407 2052	IC-SN74LS7ANS	105-116
1407 2081	IC-SN74LS08NS	105-117
1407 2135	TTLIC-74F74SJ	105-118
1407 2137	lC-74F138SJ:TTL	105-119
1407 2138	TTLIC-74F139SJ	105-120
1407 2187	IC-SN74LS07NS	105-121
1407 2218	IC-SN74LS06NS	105-122
1407 2231	IC-TD62308AF	105-123
1407 2344	IC-TD62382F	105-124
1407 2463	IC-SN74ALS08NS	105-125
1407 2464	IC-SN74ALS7ANS	105-126
1407 2588	IC-SN74ALS04BNS	105-127
1407 2817	IC-SN74ALS32NS	105-128
1407 3224	IC-LH5164LN-10	105-129

Part No.	Description	Page and Index No.
1407 3852	IC-MB89371AH	105-130
1407 4137	IC-MM1035XF	105-131
1407 4143	IC-MC68331FC	105-132
1407 4144	IC-H81532-HD6435328A00M	105-133
1407 4146	LSI-MB89255AHPFS	105-134
1407 4147	IC-M66320FP	105-135
1408 0595	IC-NJM2904M	105-136
1408 0826	IC-TA8428K	105-137
1503 0194	Crystal Oscillator-32.768 KHz	105-138
1503 0261	Oscillator - 9.8304MHz	105-139
1503 0307	Oscillator - 20MHz	105-140
1601 7374	Resistor Array - 4.7K OHM	105-141
1602 0897	Noise Filter (115V)	91-107
1602 0946	Noise Filter - VC-210FA (220/230V) (A097)	91-107
1602 7068	Noise Filter - VC-210FA (220/230V) (A095/A096)	91-107
1604 1377	Capacitor - 0.47μF 50V	105-142
1604 1382	Capacitor - 10μF 50V	105-143
1604 1385	Capacitor - 47μF 50V	105-144
1604 1386	Capacitor - 100μF ±20% 50V	105-145
1605 0113	Capacitor - 4700PF 50V	105-146
1605 0233	Capacitor - 15PF 50V	105-147
1605 0636	Capacitor - 0.1μF	105-148
1606 1135	Capacitor - 470PF 50V	105-149
1606 1450	Capacitor - 10PF 50V	105-150
1606 1452	Capacitor - 0.01μF 50V	105-151
1607 0551	Inductor - BIM32A07PB	105-152
1610 0286	Capacitor - 100PF 50V ±10%	105-153
1630 1101	Resistor -100 OHM 1/4W ±5%	105-154
1630 1151	Resistor - 150 OHM ±5% 1/4W	105-155
1630 2102	Resistor -1K OHM 1/8W ±5%	105-156
1630 2103	Resistor - 10K OHM 1/8W	105-157
1630 2104	Resistor - 100K OHM 1/8W ±5%	105-158
1630 2105	Resistor -1M OHM 1/8W	105-159
1630 2121	Resistor -120 OHM ±5% 1/8W	105-160
1630 2123	Resistor - 12K OHM 1/8W ±5%	105-161

Part No.	Description	Page and Index No.
1630 2154	Resistor - 150K OHM ±50% 1/8W	**105-162**
1630 2206	Resistor - **20M OHM 1/8W ±5%**	**105-163**
1630 2220	**Resistor - 22 OHM 1/8W ±5%**	**105-164**
1630 2221	**Resistor - 220 OHM**	**105-165**
1630 2222	**Resistor - 2.2K OHM 1/8W**	**105-166**
1630 2223	**Resistor - 22K OHM 1/8W ±5%**	**105-167**
1630 2330	**Resistor - 33 OHM 1/8W ±5%**	**105-168**
1630 2331	**Resistor - 330 OHM 1/8W ±5%**	**105-169**
1630 2472	**Resistor - 4.7K OHM 1/8W ±5%**	**105-170**
1630 2473	**Resistor - 47K OHM 1/8W ±5%**	**105-171**
1630 2910	**Resistor - 91 OHM 1/8W ±5%**	**105-172**

Part No.	Description	Page and Index No.